

POLLUTE and MIGRATE

Version 10

User Guide



© 2025 GAEA Technologies Ltd.

POLLUTE and MIGRATE

Version 10

User Guide

GAEA Technologies Ltd,

*221 Laurel St.
Cambridge, Ontario
Canada
N3H 3Y6*

Tel: (613) 900-1950

*Email:
sales@gaeatech.com
support@gaeatech.com*

www.gaeatech.com

POLLUTE and MIGRATE

Version 10

© 2025 GAEA Technologies Ltd.

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of GAEA Technologies.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. GAEA Technologies makes no claim to these trademarks.

While every precaution has been taken in the preparation of this document, GAEA Technologies assumes no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs that may accompany it. In no event shall GAEA Technologies be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: October 2025 in Canada.

Table of Contents

Chapter 1 Introduction	14
1.1 Theory	16
1.1.1 Transport Mechanisms	16
Advection	16
Diffusion	17
Advective-Diffusive Transport	18
Dispersion	18
1.1.2 Retardation Mechanisms	19
Sorption	19
Radioactive or Biological Decay	21
1.1.3 POLLUTEv10 Phase Change	21
1.1.4 POLLUTEv10 One-Dimensional Contaminant Migration	22
1.1.5 MIGRATEv10 Two-Dimensional Contaminant Migration	23
1.1.6 POLLUTEv10 Boundary Conditions	24
Zero Flux Top Boundary	24
Constant Concentration Top Boundary	24
Finite Mass Top Boundary	24
Zero Flux Bottom Boundary	25
Constant Concentration Bottom Boundary	25
Fixed Outflow Velocity	26
Infinite Thickness	26
1.1.7 MIGRATEv10 Boundary Conditions	26
Constant Surface Concentration	26
Finite Mass Surface Concentration	27
Impermeable Surface with Buried Source	27
Zero Surface Concentration with Buried Source	27
Zero Flux Bottom Boundary	27
Zero Concentration Bottom Boundary	28
Aquifer Bottom Boundary	28
1.2 Installation	29
1.2.1 Single User Installation	29
1.2.2 Network Installation	30
1.3 Purchasing and Registration	31
1.3.1 Single User Registration	31
Purchasing a License	31
Registering a License	33
Exporting the Serial Number	35
Importing Registration Codes	36
Transferring a License	37
1.3.2 Network Registration	39
1.4 Upgrading from POLLUTEv8	40
1.5 Using the Application	41
1.5.1 Geographic Information System	43
Web Map Services	44
Selecting Web Map Services	44

Adding a Web Map Service.....	44
Using the GIS.....	45
GIS Toolbar	45
Compass Control.....	52
1.5.2 No GIS	52
1.6 Preferences.....	53
1.6.1 Appearance	54
1.6.2 Backups	55
1.6.3 Company	56
1.6.4 Datasources	58
1.6.5 Defaults	59
1.6.6 GIS	60
1.6.7 Internet	62
1.6.8 Maintenance	64
1.6.9 Network License	65
1.6.10 Pollute and Migrate	66
1.7 Symbol Libraries.....	68
1.7.1 Creating a Library	68
1.7.2 Editing a Library	69
Symbols.....	70
1.7.3 Deleting a Library	72
1.8 Units.....	74
1.8.1 Unit Precision	74
1.8.2 Unit Conversion	74
1.9 Help and Support.....	76
1.9.1 Help System	76
1.9.2 Technical Support	76
1.9.3 Updates	77
 Chapter 2 Projects	 78
2.1 Creating a Project.....	80
2.1.1 Project Info Tab	81
2.1.2 Boundary Tab	82
2.1.3 Local Coordinates Tab	83
Georeferenced.....	83
Local.....	84
2.1.4 Category Tab	86
2.2 Locating a Project.....	87
2.3 Opening a Project.....	88
2.4 Editing a Project.....	90
2.5 Deleting a Project.....	91
2.6 Georeferencing a Project.....	92
2.6.1 Georeferencing to a Point	93
2.6.2 Georeferencing Manually	93
2.7 Assigning Local Coordinates.....	94
2.8 Exporting a Project.....	96
2.8.1 Exporting a Project to Access Database	96
2.8.2 Exporting a Project to XML	96

2.9 Importing a Project.....	97
2.9.1 Importing Access Project Databases	97
2.9.2 Importing XML Projects	97
2.10 Importing POLLUTEv7 Data.....	98
2.10.1 Importing an individual POLLUTEv7 project	98
2.10.2 Importing a list of POLLUTEv7 projects	99
2.11 Importing POLLUTEv8 Data.....	102
2.11.1 Importing an individual POLLUTEv8 project	102
2.11.2 Importing a list of POLLUTEv8 projects	102
2.12 Querying Projects.....	107
2.13 Editing Project Categories.....	109
2.14 Changing a Project Number.....	111

Chapter 3 Pollute Models 113

3.1 Creating a New Model.....	115
3.2 Opening a Model.....	117
3.3 Editing a Model.....	118
3.3.1 Editing a Normal Model	118
General Data.....	118
Layers.....	121
Select Symbol	124
Boundaries.....	125
3.3.2 Editing a Primary Landfill Model	131
General Data.....	132
Source and Hydraulic Heads	133
Geomembranes.....	134
Clay Liners	138
Aquitard.....	138
Aquifer	139
3.3.3 Editing a Primary and Secondary Landfill Model	140
General Data.....	141
Source and Hydraulic Heads	143
Collection System.....	143
Geomembranes.....	144
Clay Liners	145
Aquitard.....	146
Aquifer	147
3.3.4 Editing a Vertical Migration Model	148
General Data.....	148
Source and Hydraulic Heads	149
Geomembranes.....	150
Clay Liners	151
Aquitard.....	151
Aquifer	152
3.3.5 Editing a Horizontal Migration Model	152
General Data.....	154
Source and Hydraulic Heads	155
Geomembranes.....	156
Clay Liners	157
Aquitard.....	157

3.3.6 Editing Special Features	158
Initial Concentration Profile.....	158
Maximum Sublayer Thickness.....	160
Non-linear Sorption.....	161
Passive Sink.....	162
Print Mass in Base.....	164
Radioactive/Biological Decay	164
Time Varying Properties.....	165
Monte Carlo Simulation.....	170
Sensitivity Analysis.....	173
3.3.7 Displaying the Subsurface Model	174
Subsurface Model Options.....	175
3.4 Running a Model.....	177
3.5 Displaying Model Output.....	178
3.5.1 Displaying Model Listing	178
3.5.2 Displaying Charts	179
Chart Types.....	180
Depth vs Concentration.....	180
Concentration vs Time.....	181
Concentration vs Depth vs Time.....	182
Depth vs Time	184
Flux vs Time	184
Probability vs Concentration.....	186
Probability vs Time.....	186
Probability vs Variable Value.....	187
Editing Chart Format.....	188
Editing Chart Line Options	189
Editing Chart Grid Options	190
Printing the Chart.....	191
Exporting Chart Data.....	192
3.6 Exporting to Excel.....	194
3.7 Exporting to a Migrate Model.....	195
3.8 Importing Output Data.....	196
3.8.1 Importing Other Model Output Data	196
3.8.2 Importing Output Data from Excel	197
3.8.3 Creating an Imported Dataset	198
3.8.4 Editing an Imported Dataset	200
3.8.5 Deleting an Imported Dataset	202
3.9 Saving a Model.....	203
3.10 Deleting a Model.....	205
3.11 Converting a Model.....	206
3.12 Exporting a Model.....	207
3.13 Importing a Model.....	208
Chapter 4 Migrate Models	209
4.1 Creating a New Model.....	211
4.2 Opening a Model.....	213
4.3 Editing a Model.....	214

4.3.1 Editing a Normal Model	214
General Data.....	215
Boundaries.....	217
Top Boundary	218
Bottom Boundary.....	223
Layers.....	224
Fractures	227
Select Symbol	227
Time Varying Properties.....	228
4.3.2 Editing a Primary Landfill Model	230
General Data.....	231
Source and Hydraulic Heads	233
Geomembranes.....	234
Clay Liners.....	235
Aquitard.....	236
Aquifer	237
4.3.3 Editing a Primary Leakage Rate Model	238
Geomembranes.....	239
4.3.4 Editing a Primary and Secondary Landfill Model	241
Source and Hydraulic Heads	242
Collection System.....	244
Geomembranes.....	245
Clay Liners.....	245
4.3.5 Editing Special Features	246
Passive Sink.....	247
Time Varying Properties.....	249
4.3.6 Displaying the Subsurface Model	253
Subsurface Model Options.....	254
4.4 Running a Model.....	256
4.5 Displaying Model Output.....	257
4.5.1 Displaying Model Listing	258
4.5.2 Displaying Charts	259
Chart Types.....	260
Depth vs Concentration.....	261
Concentration vs Time.....	262
Concentration vs Distance.....	263
Mass vs Time	264
Depth vs Time	265
Depth vs Distance.....	266
Editing Chart Format.....	267
Editing Chart Line Options	268
Editing Chart Grid Options	268
Printing the Chart.....	269
Exporting Chart Data.....	270
4.6 Exporting to Excel.....	272
4.7 Exporting to a Pollute Model.....	274
4.8 Importing a MIGRATEv9 Model.....	275
4.9 Importing Output Data.....	276
4.9.1 Importing Other Model Output Data	276
4.9.2 Importing Output Data from Excel	277
4.9.3 Creating an Imported Dataset	279
4.9.4 Editing an Imported Dataset	280

4.9.5 Deleting an Imported Dataset	282
4.10 Saving a Model.....	283
4.11 Deleting a Model.....	285
4.12 Converting a Model.....	286
4.13 Exporting a Model.....	287
4.14 Importing a Model.....	288

Chapter 5 Templates 289

5.1 Creating a Template.....	291
5.1.1 Creating from an Existing Template	291
5.1.2 Creating from an Existing Model	291
5.2 Opening a Template.....	293
5.3 Editing a Template.....	294
5.3.1 Editing Listing Formatting and Options	294
5.3.2 Editing Chart Formatting	295
Editing the Series Format.....	296
Editing the Chart Format.....	298
Editing the Chart Title.....	298
Editing the Chart Axes.....	300
Editing the Chart Legend.....	301
Editing the Chart Data.....	303
Editing the Print Preview	303
5.3.3 Editing Chart Line Options	304
5.3.4 Editing Chart Grid Options	305
5.4 Deleting a Template.....	308
5.5 Exporting a Template.....	309
5.6 Importing a Template.....	310

Chapter 6 Data and User Management 311

6.1 Security and User Administration.....	313
6.1.1 User Administration	313
Adding a Local User.....	314
Editing a Local User.....	314
Removing a Local User.....	315
User Privilege Level Functionality.....	315
6.1.2 Project Security	316
6.2 Database Management.....	318
6.2.1 Backing up a database	318
6.2.2 Restoring a database	318
Restoring the Main Database.....	318
Restoring a project database.....	319
6.3 Network License Management.....	321
6.3.1 Installation	321
Server Installation.....	321
Starting the Service.....	321
Uninstalling the Service.....	322
Client Installation.....	322

Setting the Database and Datastore Folders	322
Setting Network Options	323
6.3.2 License Manager	324
Manage Licenses	325
Purchasing a License	326
Register License	328
Export Serial Number	330
Import Unlock Codes	331
Update Maximum Users	332
Transferring the License	333
Manager Users	333
Adding a User	334
Editing a User	335
Removing a User	335
Export User Accounts	336
Import User Accounts	336
Active Locks	336
Show Log	337
Display Event Details	337
Settings	338

Appendix A Examples

339

7.1 Pollute Examples	341
7.1.1 Case 1: Subtitle D Landfill	341
7.1.2 Case 2: Pure Diffusion	341
7.1.3 Case 3: Advective Diffusive Transport	341
7.1.4 Case 4: Finite Mass Source	342
7.1.5 Case 5: Hydraulic Trap - Finite Mass Source	343
7.1.6 Case 6: Fractured Layer and Sorption	343
7.1.7 Case 7: Fractured Rock and Radioactive Decay	344
7.1.8 Case 8: Diffusion with Initial Concentration Profile	344
7.1.9 Case 9: Freundlich Non-linear Sorption	344
7.1.10 Case 10: Time-varying Transport	344
7.1.11 Case 11: Time-varying Source Concentration	345
7.1.12 Case 12: POLLUTE vs. Analytical Solution	346
7.1.13 Case 13: Comparison with Analytical Method	346
7.1.14 Case 14: Primary and Secondary Collection	346
7.1.15 Case 15: Leachate Collection with Failure	347
7.1.16 Case 16: Monte Carlo Simulation	348
7.1.17 Case 17: Landfill with Composite Primary Liner	349
7.1.18 Case 18: Phase Change	349
7.1.19 Case 19: Multiphase Diffusion Test	350
7.1.20 Case 20: Sensitivity Analysis	350
7.2 Migrate Examples	351
7.2.1 Case 1: Subtitle D Landfill	351
7.2.2 Case 2: Primary and Secondary Liner Landfill	351
7.2.3 Case 3: Pure Diffusion	351
7.2.4 Case 4: Advective Diffusive Transport - Finite Mass	352
7.2.5 Case 5: Integration Effects	353
7.2.6 Case 6: Integration Effects - Talbot Integration	353
7.2.7 Case 7: Integration Effects - Gauss Integration	353
7.2.8 Case 8: Buried Landfill	353

7.2.9 Case 9: Comparison with TDAST	353
7.2.10 Case 10: Fractured Layer and Sorption	354
7.2.11 Case 11: Two Landfills	354
7.2.12 Case 12: Two Landfills - Different Source Histories	355
7.2.13 Case 13: Termination of a Leachate Collection System	355

Appendix B Research Reports 356

8.1 1-D Pollutant Migration.....	358
8.2	
A Finite Layer Technique for Calculating Three-Dimensional.....	359
8.3 Pollutant Migration in Soil	
A Semi-Analytic Model for Contaminant Migration in a.....	360
8.4 An Efficient Analysis of Pollutant Migration through Soil.....	361
Conservative Contaminants	
8.5	
Analysis of Contaminant Transport Through Fractured Rock.....	362
8.6 Background Documentation for POLLUTE and MIGRATE.....	363
8.7 Calculating Leakage through Composite Liner Systems.....	364
8.8 Composite Liners as Barriers: Critical Considerations.....	365
8.9	
Consideration of Uncertainty regarding the Service lives of.....	366
8.10 Engineered Systems in Assessing Potential Contaminant	
Contaminant Impact Assessment and the Contaminating.....	367
8.11 Contaminant Impact Due to Clogging.....	368
8.12	
Contaminant Migration through Fractured till into an.....	369
8.13 Underlying Aquifer	
Effect of multiple contaminant migration on diffusion and.....	370
8.14 Evaluation of the Hydraulic Conductivity of Aquitards ^a	371
natural clayey soil	
8.15	
Fractured till: Its Implications for Contaminant Impact.....	372
8.16 Assessment	
Geosynthetics: Environmental Applications in Waste.....	373
8.17 Containment	
Laboratory Determination of Chloride Diffusion Coefficient in.....	374
8.18 Leachate Characteristics for MSW Landfills.....	375
8.19 Long-term performance of containinant barrier systems.....	376
8.20	
Modeling of 2D Contaminant Migration in a Layered and.....	377
8.21 Movement of Pollutants through Clayey Soil.....	378
8.22 Municipal Solid Waste Landfilling.....	379
8.23 Pollutant Transport Through Barriers.....	380
8.24 Two-dimensional pollutant migration in soils of finite depth.....	381

8.25	Waste Disposal Facility Site Selection and Design.....	382
	Considerations	

Pollute & Migrate

User Guide

Chapter 1 Introduction

Chapter 1 Introduction

The contaminant impact from sources such as landfills and spills will be dependent on the interaction between the engineered systems and the hydrogeology. Computer modeling may be used to simulate this interaction and to assess the probable contaminant impact of a contaminant source. In addition, computer modeling may be used to examine the effects of changes in the design and performance of the engineered systems, or the local hydrogeology.

POLLUTEv10 and MIGRATEv10 are used to provide fast, accurate, and comprehensive contaminant migration analysis capabilities. The POLLUTEv10 program implements a one and a half dimensional solution to the advection-dispersion equation. And the MIGRATEv10 program implements a two-dimensional solution to the advection-dispersion equation.

Models that can be considered range from simple systems on a natural clayey aquitard to landfill designs with composite liners, multiple landfills (MIGRATEv10 only), multiple barriers, and multiple aquifers.

POLLUTEv10 and MIGRATEv10 are modules within the POLLUTE and MIGRATE application. This allows for easier sharing of data between the modules and a more consistent user experience.

The program is based upon the project concept for data storage, where the user has numerous projects and within each project there are numerous models. Using this method, a Microsoft Access database is used to store each project. Each project is stored in a separate directory, which can be on the same computer or spread across a network. A master database is used to keep track of projects and their locations, so that there is no need to remember the location of data files.

1.1 Theory

The movement or migration of contaminants through the soil is of interest in the prediction of contaminant impact from sources such as landfills and spills. There are three main mechanisms for contaminant transport, these are advection, diffusion, and dispersion.

Unlike finite element and finite difference formulations, POLLUTEv10 and MIGRATEv10 do not require a time-marching procedure, and thus involves relatively little computational effort while also avoiding the numerical problems of alternate approaches. These programs use a finite-layer formulation that provides numerically accurate results for a given idealization while requiring relatively little computational and data entry effort.

POLLUTEv10

In many applications the movement of contaminants will be primarily in one direction, and can be predicted using the one-dimensional dispersion-advection equation for a layered deposit [Rowe and Booker, 1985, 1991b; Rowe et al, 1994]. POLLUTEv10 is a computer program that implements a solution to the one-dimensional dispersion-advection equation for a layered deposit of finite or infinite extent [Rowe & Booker, 1991b]. Using this solution POLLUTEv10 calculates the concentrations of a contaminant at user specified times and depths.

MIGRATEv10

MIGRATEv9 is a computer program that implements a solution to the two-dimensional dispersion-advection equation for a layered system. The analytical solution is developed for the case of two-dimensional contaminant transport for a single solute, and for a layered deposit of finite thickness (Rowe and Booker, 1985, 1986, 1987, 1991; Rowe et al, 1994). A Laplace transform and a Fourier transform are used to find the solution of the advection-dispersion equation. The solution is then inverted numerically using a technique proposed by Talbot (1979). Using this solution POLLUTEv10 calculates the concentrations of a contaminant at user specified times, distances, and depths.

1.1.1 Transport Mechanisms

The migration of dissolved contaminants through the subsurface involves different transport mechanisms depending upon the type of soil, presence of fractures, degree of saturation, and soil - contaminant interaction. For a saturated clay or silt the primary mechanisms are advection and diffusion, whereas for a saturated sand the primary mechanisms are advection and dispersion. In a fractured soil the primary mechanisms are advection and dispersion along the fractures and diffusion from the fractures in the matrix. Soils with clay particles or organic matter may also act to retard the migration of contaminants by adsorbing the contaminant. These transport mechanisms are described in detail below.

1.1.1.1 Advection

When water flows through the soil it will carry contaminants along with it in solution, this process is called advection. The amount of contaminant mass transported in the x (distance) or z (depth) direction by advection is proportional to the groundwater (seepage) velocity, v_x or v_z , and the concentration, c , of the contaminant. This mass can be measured in the x and z directions during a unit of time, this is called the flux, f_x and f_z . The mass is measured in a plane perpendicular to the direction of groundwater flow. The flux is then the mass of contaminant transported per unit area per unit time and is given by:

$$f_x = n v_x c = v_{ax} c \quad (\text{MIGRATEv10})$$

$$f_z = n v_z c = v_{az} c \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where,

n = effective porosity of the soil,

v_x and v_z = groundwater (seepage) velocity in the x and z directions,

v_{ax} and v_{az} = Darcy velocities.

c = concentration of the contaminant at the time of interest.

The total mass of contaminant transported from a contaminant source into the ground can then be obtained by integrating the flux over the time period of interest viz.

$$m_{ax} = A \int n v_x c \, dt \quad (\text{MIGRATEv10})$$

$$m_{az} = A \int n v_z c \, dt \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where,

m_{ax} and m_{az} = total mass of contaminant transported in x and z directions,

A = cross-sectional area of the landfill.

It should be noted that the velocity that the contaminant moves through the soil is the groundwater velocity and not the Darcy velocity. If the groundwater velocity is zero (i.e., there is no flow) then there would be no advection.

1.1.1.2 Diffusion

Diffusion is the process where chemicals contaminants in the soil will migrate from areas of high chemical concentration (potential) to areas of low chemical concentration (potential). The mass flux transported by diffusion is proportional to the concentration gradient and is given by:

$$f_x = -n D_{ex} dc/dx \quad (\text{MIGRATEv10})$$

$$f_z = -n D_{ez} dc/dz \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where,

n = effective porosity of the soil,

D_{ex} and D_{ez} = effective diffusion coefficients in the x and z directions,

dc/dx and dc/dz = concentration gradients in the x and z directions.

The negative sign in the above equation arises from the fact that contaminants move from areas of high concentration to areas of low concentrations. By convention if the velocity in the z direction is positive the flow is out of the landfill, and if the velocity is negative the flow is into the landfill. The direction of transport for diffusion and advection can be in the same direction or in opposite directions. If the direction of diffusive transport is in the same direction as that of advective transport, then diffusion will increase the amount of contaminant transported and decrease the time taken for the contaminant to move to a given point. Diffusion can also occur in the opposite direction to advection. For example, even if groundwater is flowing into a landfill, the high concentration of contaminant in the leachate can cause diffusive transport out from the landfill. Thus, even though the groundwater flow is into a landfill contaminants can still escape from the landfill by diffusion.

By integrating the above equation the total mass of contaminant transported by diffusion from a landfill can be obtained viz.:

$$m_{dx} = A \int (-n D_{ex} dc/dx) dt \quad (\text{MIGRATEv10})$$

$$m_{dz} = A \int (-n D_{ez} dc/dz) dt \quad (\text{POLLUTEv10 and MIGRATEv10})$$

1.1.1.3 Advective-Diffusive Transport

For unfractured clayey and silty soils the primary transport mechanisms will be generally be advection and diffusion (i.e., advective-diffusive transport). The flux of mass, f , is obtained by adding the advective flux and the diffusive flux viz.:

$$f_x = n v_x c - n D_{ex} dc/dx \quad (\text{MIGRATEv10})$$

$$f_z = n v_z c - n D_{ez} dc/dz \quad (\text{POLLUTEv10 and MIGRATEv10})$$

and the total mass, m , transported from the landfill is given by:

$$m_{dx} = A \int (n v_x c - n D_{ex} dc/dx) dt \quad (\text{MIGRATEv10})$$

$$m_{dz} = A \int (n v_z c - n D_{ez} dc/dz) dt \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where the parameters are the same as those defined previously. By convention if the velocity is positive the flow is out of the landfill, and if the velocity is negative the flow is into the landfill. The direction of transport for diffusion and advection can be in the same direction or in opposite directions. If the direction of diffusive transport is in the same direction as that of advective transport, then diffusion will increase the amount of contaminant transported and decrease the time taken for the contaminant to move to a given point. Diffusion can also occur in the opposite direction to advection. For example, even if groundwater is flowing into a landfill, the high concentration of contaminant in the leachate can cause diffusive transport out from the landfill. Thus, even though the groundwater flow is into a landfill contaminants can still escape from the landfill by diffusion.

1.1.1.4 Dispersion

In a granular layer (eg. an aquifer) or a fractured layer there can be significant localized variations in the groundwater flow. These variations will cause mechanical mixing within the layer, this process is called dispersion [Freeze and Cherry, 1979]. Although the process is very different to diffusion it can be modeled mathematically in the same manner, and the two processes can be grouped together as the "coefficient of hydrodynamic dispersion", D_{xx} and D_{zz} , viz.:

$$D_{xx} = D_{ex} + D_{mdx} \quad (\text{MIGRATEv10})$$

$$D_{zz} = D_{ez} + D_{mdz} \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where,

D_{ex} and D_{ez} = effective diffusion coefficients in x and z directions,

D_{mdx} and D_{mdz} = coefficients of mechanical dispersion in x and z directions.

In unfractured clayey soils the coefficient of hydrodynamic dispersion is often controlled by the diffusion coefficient, and the coefficient of mechanical dispersion is negligible. In sandy soils and fractured layers the opposite is generally true and dispersion dominates [Gillham and Cherry, 1982; Rowe, 1987; Rowe et al, 2004]. The mass flux for advective-dispersive transport (including diffusion) is given by:

$$f_x = n v_x c - n D_{xx} dc/dx \quad (\text{MIGRATEv10})$$

$$f_z = n v_z c - n D_{zz} dc/dz \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where the parameters are the same as those defined previously and D_{xx} and D_{zz} are the coefficients of hydrodynamic dispersion. Dispersion is often modeled as a linear function of velocity [Bear, 1979; Freeze and Cherry, 1979; Rowe et al, 2004] given by:

$$D_{mdx} = \alpha v_x \quad (\text{MIGRATEv10})$$

$$D_{mdz} = \alpha v_z \quad (\text{POLLUTEv10 and MIGRATEv10})$$

where,

α = dispersivity,

v_x and v_z = groundwater (seepage) velocity in the x and z directions.

The dispersivity tends to be scale dependent and is not a true material property [Gillham and Cherry, 1982].

1.1.2 Retardation Mechanisms

In addition to the transport mechanisms mentioned above, the migration of contaminants is also controlled by retardation mechanisms. There are two types of retardation mechanisms, sorption and radioactive or biological decay, that can be modeled in POLLUTEv10 and MIGRATEv10. These mechanisms both serve to slow the migration of contaminants by reducing the mass of contaminant available for transport. Both mechanisms are discussed below.

1.1.2.1 Sorption

Sorption is the process whereby contaminants are removed from solution by interaction with solid matter in the soil. Typical interactions are cation exchange in clays and the attraction of organic contaminants to organic matter in the soil. Sorption can be modeled as a function of the concentration of the contaminants in the soil. POLLUTEv10 can model three types of sorption; linear sorption, Freundlich non-linear sorption, and Langmuir non-linear sorption. And MIGRATEv10 can model linear sorption.

Freundlich Non-Linear Sorption (POLLUTEv10 only)

Freundlich Non-Linear Sorption is represented by the relationship:

$$S = K_f c^E$$

where,

S = mass of solute sorbed per unit mass of soil,

K_f = empirically determined parameter,
 E = empirically determined exponent.

The parameters K_f and E are best determined by performing batch tests on samples. When non-linear sorption is used, the program splits the deposit into sublayers and uses an iterative technique to determine an equivalent linear distribution coefficient (K) value of each layer. Since this is an empirical equation, particular care is required ensuring correct units, especially when E is not unity. Large errors can result from the use of mixed units or errors in converting from one set of units to another. This is done by:

(a) calculating the concentration at the top and bottom of each sublayer based on an estimated linear K value for each sublayer.

(b) determining a new secant K for each sublayer.

$$K = K_f c'^{E-1}$$

where,

c' = the average of the previous estimates of the concentration at the top and bottom of the sublayer.

(c) repeating steps (a) and (b) using the new estimate of K for each sublayer until the process converges.

The number of sublayers should be experimented with to ensure that the results obtained are sufficiently accurate.

Langmuir Non-Linear Sorption (POLLUTEv10 only)

Langmuir Non-Linear Sorption is represented by the relationship:

$$S = (S_m b c) / (1 + b c)$$

where,

S_m = solid phase concentration corresponding to all available sorption sites being occupied,

b = parameter representing the rate of sorption,

S = mass of solute sorbed per unit mass of soil,

c = concentration of solute.

The parameters S_m and b are best determined by performing batch tests on samples of the deposit.

When non-linear sorption is used, the program splits the deposit into sublayers and uses an iterative technique to determine an equivalent linear distribution coefficient (K) value of each layer. This is done by:

(a) calculating the concentration at the top and bottom of each sublayer based on an estimated linear K value for each sublayer.

(b) determining a new secant K for each sublayer:

$$K = (S_m b) / (1 + b c')$$

where,

c' = the average of the previous estimates of the concentration at the top and bottom of the sublayer.

(c) repeating steps (a) and (b) using the new estimate of K for each sublayer until the process converges.

The number of sublayers should be experimented with to ensure that the results obtained are sufficiently accurate.

1.1.2.2 Radioactive or Biological Decay

Some contaminant species experience radioactive decay or biological degradation and the concentration of these contaminants may decay as a function of time. The rate of radioactive decay is very predictable and is controlled by the half-life of the contaminant species. Whereas, the rate of biological decay is a function of several factors, including the presence of the appropriate bacteria, the presence of a suitable substrate, and the temperature. Both types of decay are often modelled by first order decay, with the controlling parameter being the half-life of the species.

The decay can take place in the source, the deposit, or the base. First order (exponential) decay is used for both radioactive and biological decay, eg.

$$c(t) = c(0) e^{-\lambda \cdot t}$$

where,

$c(t)$ = concentration at time t ,

$c(0)$ = initial concentration,

λ = decay constant = $.693147/\text{half life}$.

1.1.3 POLLUTEv10 Phase Change

Many practical problems involve a phase change as a compound (eg. volatile organic compounds such as dichloromethane, benzene, toluene, etc.) migrate through a multiphased system. A common example is diffusion migration from a dissolved phase (eg. in contaminated water) into the gaseous phase (eg. in air in an unsaturated secondary leachate collection system). Under these conditions it is well known (eg. see Schwartzbach et. al., 1993) that there is usually a concentration 'jump' at the interface between the contaminated water and the air, and that equilibrium is reached at the interface such that:

$$c_{a/w} = K_H' c_{w/a}$$

where.

$c_{a/w}$ = concentration in air at the interface,

$c_{w/a}$ = concentration in water at the interface,

K_H' = dimensionless Henry's Law Constant, and is related to the Henry's Law Constant K_H by the relationship

$$K_H' = K_H / (R T)$$

(R is the gas constant and T is the absolute temperature).

More generally, there is potential for phase change at interfaces other than air-water. For example, the migration of an organic compound from a dissolved phase in leachate through a “solid” geomembrane, may involve a phase change defined by [Rowe et al, 2004]:

$$c_g = S_{gf} c_f$$

where,

S_{gf} is the dimensionless ratio of the concentration at the geomembrane and water interface, typical values have been reported by Rowe et al, 2004. Thus, in general the concentration ratio at an interface where there is a phase change can be written as:

$$c_{n/w} = \Delta c_{w/n}$$

where,

$c_{n/w}$ is the gas or solid concentration (mol. m⁻³) in the n phase (i.e. gas or solid), $c_{w/n}$ is the concentration (mol. m⁻³) dissolved in the solvent of interest (eg. water), and Δ is the dimensionless phase parameter (mol. m⁻³ mol.⁻¹ m³).

1.1.4 POLLUTEv10 One-Dimensional Contaminant Migration

The theory implemented by the POLLUTEv10 program, in its basic mode of operation, is described in detail by Rowe and Booker [1985, 1987, 1991b] and Rowe et al [1994]. According to this theory contaminant migration in one-dimension, for an intact material, is governed by:

$$n \, dc/dt = n \, D \, d^2c/dz^2 - n \, v \, dc/dz - \rho \, K_d \, dc/dt - n \, \lambda \, c$$

where,

c = concentration of contaminant at depth z at time t ,

D = coefficient of hydrodynamic dispersion at depth z ,

v = groundwater (seepage) velocity at depth z ,

n = porosity of the soil at depth z ,

ρ = dry density of the soil at depth z ,

K_d = distribution/partitioning (sorption) coefficient at depth z ,

$v_a = n \, v$ = Darcy velocity,

λ = decay constant of the contaminant species (i.e., the reciprocal of the species mean half life times $\ln 2$).

Contaminant migration in a fractured layer is primarily in one direction along the fracture (e.g. either horizontally or vertically), but contaminants can migrate from the fractures into the intact material in all three co-ordinate directions. Thus contaminant migration along the fractures is governed by [Rowe et al, 2004]:

$$n_f \, dc_f/dt = n_f \, D_f \, d^2c_f/dz^2 - n_f \, v_f \, dc_f/dz - \Delta \, K_f \, dc_f/dt - q - n_f \, \lambda \, c_f$$

where,

c_f = concentration in a fracture at depth z and time t ,

D_f = coefficient of hydrodynamic dispersion of the fractures,

v_f = fracture (groundwater) velocity in the fractures,

n_f = fracture porosity in the plane of flow = $h1/H1 + h2/H2$,

Δ = surface area of fractures per unit volume of soil/rock,
 K_f = fracture distribution coef. [Freeze and Cherry, 1979],
 q = contaminant transported into the intact matrix material, from the fractures, by matrix diffusion,
 λ = decay constant of the contaminant species.

Note: the program automatically calculates n_f , v_f , and q from other information provided by the user.

1.1.5 MIGRATEv10 Two-Dimensional Contaminant Migration

The theory implemented by the MIGRATEv10 program, in its basic mode of operation, is described in detail by Rowe and Booker [1985, 1987, 1991b] and Rowe et al [1994]. According to this theory contaminant migration in two-dimensions, for an intact material, is governed by:

$$n \, dc/dt = n \, D_{xx} \, d^2c/dx^2 + n \, D_{zz} \, d^2c/dz^2 - n \, v_x \, dc/dx - n \, v_z \, dc/dz - \rho \, K_d \, dc/dt - n \, \lambda \, c$$

where,

c = concentration of contaminant at depth z at time t ,

D_{xx} and D_{zz} = coefficients of hydrodynamic dispersion at depth z ,

v_x and v_z = groundwater (seepage) velocities at depth z ,

n = porosity of the soil at depth z ,

ρ = dry density of the soil at depth z ,

K_d = distribution/partitioning (sorption) coefficient at depth z ,

$v_a = n \, v$ = Darcy velocity,

λ = decay constant of the contaminant species (i.e., the reciprocal of the species mean half life times $\ln 2$).

Contaminant migration in a fractured layer is primarily in one direction along the fracture (e.g. either horizontally or vertically), but contaminants can migrate from the fractures into the intact material in all three co-ordinate directions. Thus contaminant migration along the fractures is governed by [Rowe et al, 2004]:

$$n_f \, dc_f/dt = n_f \, D_f \, d^2c_f/dz^2 - n_f \, v_f \, dc_f/dz - \Delta \, K_f \, dc_f/dt - q - n_f \, \lambda \, c_f$$

where,

c_f = concentration in a fracture at depth z and time t ,

D_f = coefficient of hydrodynamic dispersion of the fractures,

v_f = fracture (groundwater) velocity in the fractures,

n_f = fracture porosity in the plane of flow = $h1/H1 + h2/H2$,

Δ = surface area of fractures per unit volume of soil/rock,

K_f = fracture distribution coef. [Freeze and Cherry, 1979],

q = contaminant transported into the intact matrix material, from the fractures, by matrix diffusion,

λ = decay constant of the contaminant species.

Note: the program automatically calculates n_f , v_f , and q from other information provided by the user.

1.1.6 POLLUTEv10 Boundary Conditions

The POLLUTEv10 program solves the one-dimensional contaminant migration equation subject to boundary conditions at the top and bottom of the soil deposit being modelled. There are three possible top boundary (i.e., the usually the point of contact between the contaminant source and the soil deposit), these are zero flux, constant concentration, and finite mass. The bottom boundary (i.e., the point of contact between the soil deposit and either a much more or much less permeable strata) may be either zero flux, constant concentration, fixed outflow, or infinite thickness.

1.1.6.1 Zero Flux Top Boundary

The top boundary may be assumed to not allow any transmission of contaminant (i.e. zero flux). This option has some highly specialized applications and will be rarely used. The surface flux passing into the soil is given by:

$$f(z=0) = 0 \text{ for all } t$$

1.1.6.2 Constant Concentration Top Boundary

In this boundary condition the top boundary is assumed to maintain a constant concentration. The concentration at the boundary is given by:

$$c(z=0) = c_s \text{ for all } t$$

where c_s is the constant concentration at the top boundary.

1.1.6.3 Finite Mass Top Boundary

The top boundary may be assumed to have a finite mass, in which case the source concentration starts at an initial value c_0 , increases linearly with time at a rate c_r , and then decreases with time as contaminant is transported into the soil and collected by a leachate collection system, if present. The gradual conversion of waste into leachate can also be considered by providing a conversion rate half-life.

The concentration at the top boundary is given by:

$$c(t) = c_0 + c_r t - \lambda \int c(\tau) d\tau - 1/H_r \int f(c, \tau) d\tau - q_c/H_r \int c(\tau) d\tau + R_s/WC (1 - e^{-Kt})$$

where,

c_0 = initial source concentration at the start time.

c_r = rate of increase in concentration with time due to the addition of mass to the landfill.

$f(c, \tau, z=0)$ = the surface flux (mass per unit area per unit time) passing into the soil at the top boundary.

q_c = the volume of leachate collected per unit area of the landfill per unit time, if there is no leachate collection system $q_c=0$.

λ = first order decay coefficient calculated based on the half-life specified in the Special Features, Radioactive/Biological Decay option, such that $\lambda = \ln 2 / (\text{half-life for decay})$.

R_s = mass of contaminant in the waste available to be transformed into dissolved form over time (per unit volume of waste). The program calculates R_s as follows:

$$R_s = p \rho_w - c_0 WC$$

where,

p = available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste);

ρ_w = apparent density of the waste (i.e. mass of waste per unit volume of the landfill);

WC = volumetric water content of the waste.

κ = generation coefficient calculated based on the conversion rate half-life K , such that $\kappa = \ln 2 / K$. A value of $\kappa = 0$ implies no generation of concentration with time. In the program $\kappa = 0$ is obtained by specifying $K = 0$ (this is the default case).

H_r = reference height of leachate, and represents the volume of leachate (per unit area of landfill) which would contain the total mass of contaminant at a concentration c_0 . And may be defined in one of several ways depending on what other options are being used. Note that generally the program will calculate H_r (i.e. the user will generally not input any value for H_r , but the user does have the power to override the program).

Option (a). If the user specified K is not 0 and WC is not 0 then $H_r = WC H_w$ and represents the actual fluid in the landfill (generally WC corresponds to field capacity, but could vary with time).

Option (b). If the user specified K equals 0 or WC equals 0 then $H_r = p \rho_w H_w / c_0$ and this represents the volume of fluid (per unit area of landfill) required to dissolve the leachable mass of contaminant (i.e. $p \rho_w H_w$) at the initial concentration c_0 .

Option (c). If the user specifies H_r is not 0 then the user specified value overrides the values calculated under option (a) or (b). This is an advanced feature of the program and should not be used without very carefully checking your calculations.

If the rate of increase in concentration c_r is zero and the reference height of leachate H_r is very large, this boundary condition reduces to a constant concentration boundary condition.

1.1.6.4 Zero Flux Bottom Boundary

The bottom boundary may be assumed to not allow any transmission of contaminant, which corresponds to an impermeable base strata. The flux across the boundary is given by:

$$f(z=H_b) = 0 \text{ for all } t$$

where H_b is the depth of the base strata.

1.1.6.5 Constant Concentration Bottom Boundary

This boundary condition the bottom boundary is assumed to maintain a constant concentration. The concentration at the boundary is given by:

$$c(z=H_b) = c_b \text{ for all } t$$

where c_b is the constant concentration at the bottom boundary and H_b is the depth of the bottom boundary.

1.1.6.6 Fixed Outflow Velocity

The bottom boundary may be specified as fixed outflow to represent a base aquifer, where the concentration varies with time as mass is transported into the aquifer from the landfill and transported out from beneath the landfill by the base velocity v_b .

Consideration of the conservation of mass gives the base concentration as:

$$c(\tau, z = H_b) = \int [f(\tau, z=H_b, c)/n_b h_b - v_b c(\tau, z=H_b)/n_b L] d\tau$$

where,

$c(\tau, z=H_b)$ = the concentration in the base aquifer, averaged over the entire thickness of the base,

$f(\tau, z=H_b, c)$ = the mass flux into the aquifer,

n_b = porosity of the base aquifer,

h_b = thickness of the base aquifer,

v_b = Darcy velocity in the aquifer and down-gradient edge of the landfill,

L = length of the landfill parallel to the velocity v_b .

Note that the use of a very large base velocity will give the same results at using a constant base concentration of zero. If the base velocity is zero and the porosity is zero the bottom boundary is effectively a zero flux boundary.

1.1.6.7 Infinite Thickness

The bottom boundary may also be of infinite extent, in this option the properties of the bottom most layer are adopted for the infinite layer.

1.1.7 MIGRATEv10 Boundary Conditions

The MIGRATEv10 program solves the two-dimensional contaminant migration equation subject to boundary conditions at the top and bottom of the soil deposit being modelled. There are four possible top boundary (i.e., the usually the point of contact between the contaminant source and the soil deposit), these are constant surface concentration, finite mass surface concentration, impermeable surface with a buried source, or a zero surface concentration with a buried source. The bottom boundary (i.e., the point of contact between the soil deposit and either a much more or much less permeable strata) may be either zero flux, zero concentration, or an aquifer.

1.1.7.1 Constant Surface Concentration

In this boundary condition the top boundary is assumed to maintain a constant concentration. The concentration at the boundary is given by:

$$c(z=0) = c_s \text{ for all } t$$

where c_s is the constant concentration at the top boundary.

1.1.7.2 Finite Mass Surface Concentration

The top boundary may be assumed to have a finite mass, in which case the source concentration starts at an initial value c_0 , increases linearly with time at a rate c_r , and then decreases with time as contaminant is transported into the soil and collected by a leachate collection system, if present. The gradual conversion of waste into leachate can also be considered by providing a conversion rate half-life.

The concentration at the top boundary is given by:

$$c(t) = c_0 + c_r t - \lambda \int c(\tau) d\tau - 1/H_r \int f(c, \tau) d\tau - q_c/H_r \int c(\tau) d\tau$$

where,

c_0 = initial source concentration at the start time.

c_r = rate of increase in concentration with time due to the addition of mass to the landfill.

$f(c, \tau, z=0)$ = the surface flux (mass per unit area per unit time) passing into the soil at the top boundary.

q_c = the volume of leachate collected per unit area of the landfill per unit time, if there is no leachate collection system $q_c=0$.

λ = first order decay coefficient calculated based on the half-life specified in the Special Features, Radioactive/Biological Decay option, such that $\lambda = \ln 2 / (\text{half-life for decay})$.

H_r = reference height of leachate, and represents the volume of leachate (per unit area of landfill) which would contain the total mass of contaminant at a concentration c_0 . And may be defined in one of several ways depending on what other options are being used. Note that the program will calculate H_r .

If the rate of increase in concentration c_r is zero and the reference height of leachate H_r is very large, this boundary condition reduces to a constant concentration boundary condition.

1.1.7.3 Impermeable Surface with Buried Source

This boundary condition is used to represent a buried contaminant source, with the surface being, impermeable (i.e. zero flux). The surface flux passing into the soil is given by:

$$f(z=0) = 0 \text{ for all } t$$

Buried contaminants can move upward and be removed at the surface.

1.1.7.4 Zero Surface Concentration with Buried Source

This boundary condition is used to represent a buried contaminant source and the surface is assumed to maintain a constant zero concentration.

$$c(z=0) = 0 \text{ for all } t$$

Buried contaminants can move upward and be removed at the surface.

1.1.7.5 Zero Flux Bottom Boundary

The bottom boundary may be assumed to not allow any transmission of contaminant, which corresponds to an impermeable base strata. The flux across the boundary is given by:

$$f(z=H_b) = 0 \text{ for all } t$$

where H_b is the depth of the base strata.

1.1.7.6 Zero Concentration Bottom Boundary)

In this boundary condition the bottom boundary is assumed to maintain a zero concentration. The concentration at the boundary is given by:

$$c(z=H_b) = 0 \text{ for all } t$$

where H_b is the depth of the base strata.

1.1.7.7 Aquifer Bottom Boundary

The bottom boundary may be specified as an aquifer, where the concentration varies with time as mass is transported into the aquifer from the landfill and transported out from beneath the landfill by the base velocity v_b .

Consideration of the conservation of mass gives the base concentration as:

$$c(x, z = H_b, \tau) = \int [f(x, z=H_b, \tau)/n_b h_b - v_b] dc(x, z=H_b, \tau)/n_b dx + D_H d^2c(x, z=H_b, \tau)/d^2x] d\tau$$

where,

$c(\tau, z=H_b)$ = the concentration in the base aquifer,

$f(\tau, z=H_b, c)$ = the mass flux into the aquifer,

n_b = porosity of the base aquifer,

h_b = thickness of the base aquifer,

v_b = Darcy velocity in the aquifer and down-gradient edge of the landfill,

D_H = Coefficient of hydrodynamic dispersion in horizontal (x) direction in the aquifer.

Note that the use of a very large base velocity will give the same results as using a constant base concentration of zero. If the base velocity is zero and the porosity is zero the bottom boundary is effectively a zero flux boundary.

1.2 Installation

To get POLLUTEv10 and MIGRATEv10 up and running, the POLLUTE and MIGRATE application first needs to be installed on your computer. POLLUTEv10 and MIGRATEv10 are modules within the application.

There are two types of installation, single user and network user. The installation sections below will explain how to perform both types of installations.

1.2.1 Single User Installation

Installation

When installing the program you must be logged in as an administrator.

The following steps occur during the installation:

- The application is installed on your computer
- Files for the databases and datastore are copied to your computer
- Shortcuts are placed on your Start menu and desktop

After the application has been installed, there are a few more steps before it is ready for use. The datastore needs to be setup and a default basemap selected. All these steps are accomplished by running application for the first time. The program can be started using the icon on your desktop or the application menu on the Start menu.

First-Run and Program Setup

The first time that the program is run you must be logged in as an administrator so that the directories can be created.


When the program is started for the first time a setup wizard will run that guides you through the steps below.

1. Selection of a single user or network user installation.
2. After the above information is specified the databases and data store will be setup.
3. The next step is to specify a default basemap for the application.

After the above steps are completed, the application will start initially in demo mode. You can use the application in demo mode for up to 20 times before you need to [register](#) it.

Directory Permissions

The data for the application is stored in the database and data store directories. The location of these directories will depend on the operating system and is defaulted to the common application data directory. **All of the users must have full read and write access to these directories. When possible the install program will try to set the permissions of these directories properly.** For administrative users this will not be a problem; however, limited users may need to be given permission to read and write to these directories. The location and method of setting the permissions will vary with the type of Windows operating system.



1.2.2 Network Installation

The installation of the network version of the application on the server and client computers is described in the section [Network License Management](#)³²¹.

1.3 Purchasing and Registration

POLLUTEv10 and MIGRATEv10 can be licensed on individual computers, a network, or a combination of both. When licensed on a network the licensing is based on concurrent usage, where the number of concurrent users must be less than or equal to the maximum number of users licensed. When the application is run it will be in demo mode until it is licensed.

The method for licensing will depend upon whether it is a single user or network installation. The registration sections below discuss how to license the POLLUTEv10 and MIGRATEv10 modules and how to transfer the registration.

1.3.1 Single User Registration

To license the POLLUTEv10 or MIGRATEv10 module, a registration code must be entered. The registration code is based on the serial number. This serial number is unique for each computer. The serial number can be obtained by running the program and selecting the [Tools > Manage Licenses](#). The License Manager form will be displayed with a table that shows the current licensing. To get detailed information click on the program in the table. The detailed information will be displayed to the right.

Purchase

Register

Export

Import

Relock

Name	Version	Licensed	Networked
Pollute Module	8.08	☒	☐
Migrate Module	10.00	☒	☐

Module

Name:

Version:

Industry:

Installed On:

Registration

Licensed:

Licensed By:

Licensed On:

Invoice #:

Other

Developer:

Copyright:

Description

Close

Help

1.3.1.1 Purchasing a License

Licenses can be purchased by selecting the module and clicking on the Purchase button on the License Manager form. The Purchase License form will then be displayed. This form shows the selected module and the serial number for the module. These serial numbers are unique for each computer and module. Either perpetual or annual subscription licenses can be purchased.


Purchase License


Select the product, quantity, and license type then click on the Purchase button to purchase the license. To purchase a network license, the Network Monitor should be used.

Module Name:	Pollute Module
Module Version:	8.08
Installed On:	July 2, 2021

Serial Number:

License Type: ☒ Perpetual ☐ Annual Subscription



After the license type has been selected, click on the Purchase button to proceed with the purchase. A secure web page will then be opened in your browser where you can enter the purchase information.

Purchase License

Select the product, quantity, and license type then click on the Purchase button to purchase the license. To purchase a network license, the Network Monitor should be used.

Module Name:	Pollute Module
Module Version:	8.08
Installed On:	July 2, 2021

Serial Number:



License Type: ☒ Perpetual ☐ Annual Subscription



After purchase is complete enter the Order ID below and click on the Register button to register the license.

Order ID:




 

When the purchase has been completed, you will be provided by email with a unique order/purchase ID. Enter this ID on the form and click on the Register button to register the module. If the purchase or email is delayed, the license can later be registered as described in the [Registering a License](#)^[33] section.

If a subscription is purchased it can be automatically renewed and the renewal information will be sent to GaeaSynergy.

1.3.1.2 Registering a License

After a license has been purchased and not yet registered, it can be registered by selecting the module on the License Manager form and clicking the Register button. The Register form below will then be displayed.



The screenshot shows a 'Register' dialog box with a teal header. Inside, there is a yellow-highlighted section with the following information:

Module Name:	Pollute Module
Module Version:	8.08
Installed On:	July 2, 2021

Below this section are two tabs: 'Automatic' (selected) and 'Manual'. Under the 'Automatic' tab, there is a text label 'Order ID:' followed by an empty text input field. To the right of the input field is a button with a yellow key icon and the text 'Register'. At the bottom right of the dialog box are two buttons: 'OK' with a green checkmark icon and 'Help' with a blue question mark icon.

This form has two tabs, one for automatic registrations and one for manual registrations.

Automatic Registration

If you purchased the license online and have an order/purchase ID you can enter on the Automatic tab to register the license.

Manual Registration

To manually register the license, contact GAEA with your invoice number and the unique serial number shown on the form. GAEA can be contacted either by clicking on the Obtain Unlock Code button or by emailing us at codes@gaeatech.com. When the Obtain Registration button is used an email form will be displayed where you can enter your contact information and email it directly to GAEA.

After you receive the registration code from GAEA you can enter it on the form and then save it by clicking on the Store Unlock Code button.

1.3.1.3 Exporting the Serial Number

The serial number the module can be exported to a file and emailed to GAEA. After the file has been processed a registration file will be emailed back from GAEA. This registration file can then be imported and the registration codes saved.

To export the serial number file, select the unlicensed module on the License Manager form and then click on the Export button on the toolbar of the form. The Export Serial Number form will be displayed where you can enter the invoice number and your contact details. A file name must be specified to store the exported serial number.

After you enter the information you can either email the file directly to GAEA by clicking on the Email button or save it to your disk and email it yourself by clicking on the Save button.

Export Serial Numbers

Name	Serial Number
Pollute Module	P10-7145-8672-0010-5143

To register the modules and obtain unlock codes, enter the information below then select either email or export. When exporting to a file you need to email the file to codes@gaeatech.com.

Invoice Number:

Name:

Company Name:

Address:

City: Province/State:

Country:


Email:

File Name: 

 Email  Export  Cancel  Help


1.3.1.4 Importing Registration Codes

After the file has been received and processed by GAEA you will receive a registration file back by email. When you receive this file save it to your hard drive. To import the file click on the Import button on the License Manager form and the Import Registration Codes form will be displayed. Select the file you saved using the Open button on the form and the registration codes will be imported and saved by the program.



1.3.1.5 Transferring a License

If you need to transfer the license for a single user installation from one computer to another, select the module on the License Manager form and click on the Relock button. The Relock form will then be displayed.



The screenshot shows a 'Relock' dialog box with a teal header bar containing a close button (X). Below the header is a table with license information:

Module Name:	Pollute Module
Module Version:	8.08
Licensed On:	2025-02-02 2:41:46 PM

Below the table are two tabs: 'Automatic' (selected) and 'Manual'. The main area contains the following text:

In order to transfer the registration to a different computer, you must first relock it. Relocking a module reverts it to an unregistered state.

Centered below the text is a button with a yellow padlock icon and the text 'Relock'.

At the bottom right are two buttons: 'Close' (with a green checkmark icon) and 'Help' (with a blue question mark icon).

This form has two tabs, one to automatically transfer the license and the other to manually transfer the license.

Automatic Transfer

To automatically transfer the registration to a new computer click on the Relock button. The module will no longer be registered on this computer and the order/purchase ID can be used to register it on a different computer as described in the [Automatic Registration](#) section.

Manual Transfer

Relock

Module Name:	Pollute Module
Module Version:	8.08
Licensed On:	2025-02-02 2:41:46 PM

Automatic Manual

This process generates a relock code that you need to send to GAEA Technologies to confirm your eligibility for a new unlock code.

Details

Relock code:

Invoice #:

Name:

Company Name:

Address:

City: Province/State:

Country:

Email:

File Name:

Fill in the above information, to enable the Relock button

☒ Automatically email relock file to GAEA

Relock

Close Help

To manually transfer the license fill in all of the information on the form, including the file name. After the information is entered click on the Relock button to email the relock file to GAEA. After the button is clicked the Relock code will be displayed and the module will no longer be licensed on this computer.

After you have sent GAEA the relock file follow the instructions for [Manual Registration](#)^[33] on the new computer.

1.3.2 Network Registration

Prior to using the application on the client computers, the application should be registered on the server. The registration on the server is handled through the Network Monitor program and is described in the section on [Using the Network License Manager](#)^[32].

1.4 Upgrading from POLLUTEv8


If POLLUTEv8 is installed on the computer, you can upgrade by going to [Tools > Upgrade from POLLUTEv8](#). The upgrade will copy your projects and templates from POLLUTEv8 to version 10. This upgrade should be done before using version 10, any projects in version 10 will be removed before the upgrade. After the upgrade POLLUTEv8 should not be used anymore.

Alternatively, projects from POLLUTEv8 can be imported into version 10 by going to [File > Import > POLLUTEv8 Data](#). This will only import the projects and not any templates.

1.5 Using the Application

Login


All users must login to the application. When users are setup in the application they are assigned a username, password, and user type (privilege). Different privilege levels are used to control access to functions of the program and data. The different user types are administrator, power user, limited user, and guest. For more information on setting up users see [User Administration](#)³¹³.



To have the application remember your user name and password, check remember credentials. The next time the application is started you will not need to enter your login credentials. If you are using the network to login, the Network Settings button can be used to change the network properties. When the program is initially installed the default User name is "Admin" and the default password is "admin".

Initial Display

The initial display will consist of a Geographical Information System (GIS) or a list of projects depending on your settings in Preferences. The GIS shows your existing projects and any GIS data. To the left of the GIS the sidebar usually shows a list of your projects. And to the right of the GIS the sidebar usually shows a list of layers, scale, and an index map. At the top of the display there are also toolbars and menus for controlling and using the program. These are described briefly below and in detail in the chapters throughout this manual.



Menus


The main menu appears at the top of the screen and is composed of several submenus for Files, Tools, and Help. Depending upon what is open at the time, an Edit submenu may also be present. The File submenu is used to create, open, and delete projects, models, and model templates; import and export data; and set program preferences. Several types of tools are included in the Tools submenu for the GIS, projects, symbol libraries, databases, units, and managing the program licenses..

In this User's Guide menu items and paths have been abbreviated to make it easier to understand. All menu items are shown in *blue italics* and start with the uppermost menu then an arrow to the next menu or menu item. For example, the Project menu item of the Open submenu of the File menu is abbreviated as *File > Open > Project*.

A popup menu can also be displayed by clicking the right mouse button, the menu items in the popup menu will vary depending on what is being displayed and where on the screen the mouse is clicked. In this manual menu items that can be obtained from the popup menu are shown as *Popup > menu item*.

Toolbars

Initially two toolbars will be displayed, a Main toolbar and a GIS toolbar.



The Main toolbar is used to create, open, and close projects, questionnaires, and report templates. If a project is open you can also create and open report responses and reports. In addition it can be used to display different views, the help guide and exit the program.



The GIS toolbar is used to access various features and functionality of the GIS. This toolbar is described in the [GIS section](#) ⁴³.

Sidebars

The sidebars can be on the left, right, or both sides and contain the contents described below.

Projects

The projects region has a Find Project toolbar and a list of projects. You can locate a project in the list using the Find toolbar by entering the project name and pressing the Find button. The project will then be highlighted in the project list and be zoomed to in the GIS. You can also zoom to a project in the project list by selecting the [Popup > Locate](#) after the project has been highlighted in the list.

To open a project using the Project List, highlight the project and then select [Popup > Open](#) or double-click on it in the sidebar. If no project is selected, the Open Project form will be displayed. This form lists the projects and lets you select one to open.

For a detailed description of how to create and use projects see the section below and [Chapter 3](#) ⁷⁹.

Layers

The layers region lists the layers in the GIS. These layers can be turned on and off by checking and unchecking the box beside the layer. The order of the layers in the sidebar controls the order in which they are displayed in the GIS, with the layers at the top being drawn on the layers at the bottom.

Scale Bar

The scale bar displays the current scale of the GIS or project shown in the GIS window.

North Direction

The compass on the bottom right shows the current direction for North. When the application is started this is at the top of the screen. To change the direction slide the bar to the left or right below the compass. Sliding to the left will rotate the GIS windows to the West, sliding to the right will rotate to the East. Double-click on the slider to adjust the display so that North is at the top of the screen again.

1.5.1 Geographic Information System

The Geographical Information System (GIS) is used to organize, find, and select projects. The application can also be used with no GIS, in this case a list of projects is displayed instead. When the GIS is being displayed it obtains its geographical data from a Web Map Service.

The display of the GIS and default Web Map Service is specified in the [Preferences](#) ⁶⁰.

1.5.1.1 Web Map Services

Web map services use a standard protocol to serve georeferenced map images over the Internet. This protocol was developed and published by the Open Geospatial Consortium. Several web map services are available within the application and more are being added with each update.



The web map service displayed for the GIS can either be selected from the GIS toolbar or in [File > Preferences](#). If it is selected in Preferences it will be the default web map service and will be shown every time the application is started. When it is selected from the GIS toolbar it will be effective only until it is changed again or the application is closed. New web map services are being added all the time. If you would like to have a web map service added that is not in the list please contact us.

Before displaying the web map service the application checks to see if there is an Internet connection. If there is no connection a list of projects will be displayed.

Additional custom web map services (WMS) can be added to the application by selecting [Tools > GIS > Add Web Map Service](#). The form below will then be displayed. A custom web map service can be used to add user subscribed services such as First Base Solutions (a Canadian based service for high resolution orthoimagery).

The following information can be specified on this form:

Name: This is the name of the custom WMS. It will be displayed when selecting a WMS from the GIS toolbar.

URL: This is the URL for the custom WMS. The URL is usually specified by the service provider.

Copyright: This the copyright for the custom WMS. It will be displayed on the status bar at the bottom of the screen.

1.5.1.2 Using the GIS

The display of the GIS can be controlled using the GIS toolbar and compass control as described in the sections below. The use of the GIS to create and locate projects is described in the Chapter 3.



The GIS toolbar can be used to adjust the basemap display; find, identify and select features. The controls on this toolbar depend on whether the basemap is a static basemap or web map service.

Full Extent



The Full Extent button will display the full extent of the GIS or project

Zoom In



The Zoom In button is used to zoom in to a smaller scale on the GIS.

Zoom-out



The Zoom Out button is used to zoom out to a larger scale on the GIS.

Dynamic Zoom



The Dynamic Zoom button can be used to zoom in and out using the mouse.

To zoom in

1. Click on the View/Zoom mode menu item.
2. Within the Map area choose a rectangular area to which you would like to zoom in.
3. Move the mouse pointer to the top left corner of the area and press the left mouse button.
4. Move the mouse pointer to the bottom right corner of the area and release the left mouse button.

To zoom out

1. Click on the View/Zoom mode menu item.
2. Within the Map area decide how large should be the area containing the currently visible extent and where you would like to zoom out.
3. Move the mouse pointer to the bottom right corner of this area and press the left mouse button.
4. Move the mouse pointer to the top left corner of this area and release the left mouse button.

Drag



The Drag button is used to move the visible area on the screen. To move the visible area click on the screen and while holding the mouse button down move the cursor in the desired direction to see that area displayed.

Select Feature




The Select Feature button can be used to select a feature on the map. To select a feature click on the button and then click on the feature on the map. The attributes of the selected feature will then be displayed as shown below.

Information	
UID	18
ProjectID	g1
ProjectName	g1
MinX	-79.65501644
MaxX	-79.63224944
MinY	43.77735591
MaxY	43.79125891
LocalMinX	0
LocalMaxX	1843.52475184552
LocalMinY	0
LocalMaxY	1544.05133582046
LocalUnits	1
MapUnits	11

Display Hints



The Display Hints button can be used to select the layer and field used for hints. These hints can optionally be displayed when the mouse is over a feature on the map. For example, when the mouse is over a project the hint could display the project name. When the button is pressed the Map Hint Properties form below will be displayed. This form can be used to specify whether hints are shown, the hint color, layer and field to use for the hint.




The **Map Hints** dialog box has a blue header. It contains a checked checkbox labeled "Show map hints". Below it is a section titled "Select display hint data :" containing a dropdown menu with "Projects" selected. A list box below the dropdown shows the following items: UID, ProjectID, ProjectName (highlighted in blue), MinX, MaxX, MinY, and MaxY. At the bottom left is a "Hint color :" label next to a yellow color swatch. At the bottom right is a "Close" button with a green checkmark icon.

Search



The Search button can be used to search for features on the map that meet a specified criteria. When this button is pressed the Search form below will be displayed. This form can be used to specify the layer, field, and search criteria. When the Search button on this form is pressed any features that meet this criteria will be momentarily highlighted.



The **Search** dialog box has a blue header. It contains a "Layers :" label above a dropdown menu with "Projects" selected. Below this is a "Fields :" label above a dropdown menu with "ProjectID" selected. To the right of the "Fields" dropdown is an "Operation :" dropdown with "=" selected, followed by a "Value :" text input field. Below the "Fields" dropdown are two radio buttons: "Visible Extent" (selected) and "Full Extent". On the right side, there is a "Search" button with a magnifying glass icon and a "Close" button with a red "X" icon. At the bottom, there is a "Layer :" label followed by a dropdown menu with "Projects" selected.

Web Map Service



This drop down list can be used to select the current web map service being displayed.

North Arrow




The North arrow on the GIS can be turned on and off using the North Arrow button. The color of this arrow is specified in [Preferences](#) ⁶⁰.

Find Address



Addresses can be located on the GIS by clicking on the Find Address button. The form below will be displayed and can be used to find addresses by street address, latitude and longitude, or UTM coordinated.

A screenshot of the 'Find Address' dialog box. It has a blue title bar and three tabs: 'Address', 'Latitude/Longitude', and 'UTM'. The 'Address' tab is selected. Inside the dialog, there are five text input fields: 'Street Address:', 'City:' (containing 'Toronto'), 'Region:' (containing 'Ontario'), 'Country:' (containing 'Canada'), and 'Postal/ZIP Code:'. At the bottom, there are three buttons: 'Goto' (with a location pin icon), 'Cancel' (with a red X icon), and 'Help' (with a question mark icon).

Find Address at a Point



The address of a point on the GIS can be displayed using the find address at a point button. After this button is clicked, click on the point on the GIS and the address will be displayed.

Find Elevation at a Point




The elevation of a point on the GIS can be displayed using the find elevation at a point button. After this button is clicked, click on the point on the GIS and the elevation will be displayed.

Measure Distance




Distances can be measured on the GIS using the Measure Distance tool on the GIS toolbar. When this tool is selected the Ruler control below will be displayed. The distance units can be set using the drop down list on the right. To measure a distance click on the first point and then click on the second. To hide the Ruler control click on the Measure Distance tool again.

A screenshot of the 'Measure Distance' dialog box. It has a title bar with 'Measure Distance' and a close button. Inside, there is a text field labeled 'Distance:' containing the value '12.41'. To the right of this is a label 'Units:' followed by a dropdown menu currently showing 'km'.

Measure Area




Areas can be measured on the GIS using the Measure Area tool on the GIS toolbar. When this tool is selected the Ruler control below will be displayed. The area units can be set using the drop down list on the right. To measure an area click on the first point and then click on the next points. To hide the Ruler control click on the Measure Area tool again.

A screenshot of the 'Measure Area' dialog box. It has a title bar with 'Measure Area' and a close button. Inside, there is a text field labeled 'Area:' containing the value '1.93'. To the right of this is a label 'Units:' followed by a dropdown menu currently showing 'sq. km'.

Street View



A street view for a point on the GIS can be obtained by clicking on the down arrow of the Street View button and selected either Google or Bing. Then click on the point on the map to display the street view in the Street View form. Additional street views can be displayed by closing the form and clicking on other points on the map.



The following can be specified on this form:

Width: This is the width of the image in pixels.

Height: This is the height of the image in pixels.

Heading: This is the heading from North of the image.

Pitch: This is the vertical pitch on the image. Positive values are up and negative values are down.


Field of View: This is the field of view of the image

After the parameters above have been changed use the Refresh button to update the image. To save the image to a JPEG file click on the Save button and specify the file name.

Overlay Grid



If a local project is open, the overlay grid button on the toolbar can be used to overlay a grid on the project. When this button is pressed the Project Grid form is displayed.

The image shows a dialog box titled "Project Grid". At the top, there is a checked checkbox labeled "Show grid". Below this, there are two rows of input fields. The first row is for "Horizontal Grid Spacing" with a value of "100" and a "Starting Value" of "0". The second row is for "Vertical Grid Spacing" with a value of "100" and a "Starting Value" of "0". Below these is a "Line Style" dropdown menu set to "Solid". At the bottom of the main area is a "Line Color" button next to a grey color swatch. At the very bottom of the dialog are three buttons: "OK" with a checkmark icon, "Cancel" with an X icon, and "Help" with a question mark icon.

The following can be specified on this form:

Show Grid: Check this box to overlay a grid.

Horizontal Grid Spacing: This is the horizontal spacing between grid lines in local units.


Starting Value: This is the horizontal start value for the grid.

Vertical Grid Spacing: This is the vertical spacing between grid lines in local units.

Starting Value: This is the vertical start value for the grid.

Line Style: This is used to select the line style for the grid lines.


Line Color: Press this button to select the color for the grid lines.



The compass on the bottom right shows the current direction for North. When the application is started this is at the top of the screen. To change the direction slide the bar to the left or right below the compass. Sliding to the left will rotate the GIS windows to the West, sliding to the right will rotate to the East. Double-click on the slider to adjust the display so that North is at the top of the screen again.


1.5.2 No GIS

If no GIS is specified in Preferences the main window will display a list of projects as shown below. A project can be opened by double-clicking it in the list or by highlighting it and selecting *Popup > Open*.




1.6 Preferences

To set the program preferences no project can be open. Select [File > Preferences](#). The Preferences form will be displayed. This form has a list of preference categories on the left side and the details of the selected category are displayed on the right. Each of the categories are described in the sections below.



1.6.1 Appearance



The following can be edited in the Appearances category:

User Interface

Display new object prompts: Check this box to display prompts for new objects.

Open last project: Check this box to open the last opened project when the program is started.

Activate undo: Check this box to activate the undo feature so that some operations can be undone.

Status bar: Check this box to display a status bar on the main form.

Maximize form: Check this box to maximize some forms when they are displayed.

Show toolbar button text: Check this to show the text on buttons.

Projects


Show Project Boundary: Check this box to show the project boundary when a project is opened.

Project Margin: This is used to specify the margin between the project display and the project boundary as a percentage of the display width. The larger the margin the larger the area outside of the project boundary will be displayed.

Line Style: Click this button to change the line style, width, and color of the boundary line.

Look up new project addresses: Check this box to look up the project address when a new project is created using the GIS.

1.6.2 Backups



The following can be edited in the Backups category:

Main Database

Backup main database: If this checkbox is checked then the main databases will be backed up at regular intervals. If this checkbox is not selected then the main databases will not be backed up.

Interval: This is used to select the interval to use when backing up the main databases.

Number to maintain: This is the number of backups to maintain, older backups will be deleted.

Project Databases

Backup project database: If this checkbox is checked then the currently open project will be backed up at regular intervals. If this checkbox is not selected then the currently open project will not be backed up.

Interval: This is used to select the interval to use when backing up the project database.

Number to maintain: This is the number of backups to maintain, older backups will be deleted.

Backup on Project Close: Check this to create a backup of the project when it is closed.

1.6.3 Company

Preferences

Preferences for Company

Company Name:

Contact Name:

Phone Number:

Fax Number:

Email:

Street 1:

Street 2:

City:

State:

Country:

Postal Code:

Company information is used in different parts of the application for addressing emails, creating sample labels, etc. The following can be edited in the Company category:

Company Name: This is your company name.

Contact Name: This is the contact name to use in correspondence from the application.

Phone Number: This is the phone number for the company.

Fax Number: This is the fax number for the company.

Email: This is the main email address for the company.

Street 1: This is the first line of the street address.

Street 2: This is the second line of the street address.


City: This is the city for the company.

State: This is the state or province for the company.

Country: This is the country for the company.

Postal Code: This is the postal or zip code for the company.

1.6.4 Datasources



The following can be edited in the Databases category (these features should not be changed without consulting your database administrator):

Database Provider: This is used to select the type of database. Currently, only Microsoft Access is supported.

User name: This is the user name for the main database. Normally, it should be Admin.

Password: This is the password for the main database. Normally, it is blank.


Path: This is the path to the main database.

Show Folder: Click this button to show the database folder

Datastore folder: This is the folder containing the datastore.

Show Folder: Click this button to show the datastore folder.

1.6.5 Defaults



The following can be edited in the Defaults category:

Default printer: This is used to select the default printer to use in some modules.

Location Precision: This is the precision (number of decimal places) to use when displaying location information.

Depth Precision: This is the precision (number of decimal places) to use when displaying depth information.

Decimal Degree Precision: This is the precision (number of decimal places) to use when displaying decimal degrees.


Dictionary: This is used to select the dictionary to use for some modules when performing spell checking. One of the following dictionaries can be selected: American, British, Dutch, English, French, German, Italian, and Spanish.

Resolution: This is the resolution to save images in the datastore. The resolution can be set to low (100 dpi), medium (300 dpi), or high (600 dpi). These images are used when displaying or printing a page document. Typically, low or medium is sufficient. The higher the resolution the more disk space and time is required when images are saved.

Character Set: This is used to select the character set used by some modules. Normally, the default character set can be used.

Default Local Units: This is used to select whether to use feet or meters for the default local units.

1.6.6 GIS



The following can be edited in the GIS category:

Basemap

Type: Select the type of basemap to use for the default. The type of basemap can be a web map service or none.

Default Basemap: This is the basemap to use for a web map service.

Initial Display

This is used to select the initial display when the application is started. It can either show an area around where you are located based on your Internet IP, an area showing the extent of all of your projects, or an area based on the address specified on the Company tab..

GIS Display

Show GIS Sidebar: Check to show the GIS sidebar.

Show Compass: Check to show the GIS compass.

Display Units: This is used to select the units for the current cursor location shown in the status bar at the bottom of the display.

Map Scale

Number of Dividers: This is the number of dividers in the scale bar.

Divider Color 1: Click this button to change the color of the first divider in the scale bar.

Divider Color 2: Click this button to change the color of the second divider in the scale bar.

North Arrow

Color: Click this button to change the color of the North arrow on the map.

1.6.7 Internet

The screenshot shows the 'Preferences for Internet' dialog box. The sidebar on the left lists various categories, with 'Internet' selected. The main panel is divided into three sections: 'Incoming Email Settings', 'Outgoing Email Settings', and 'FTP Settings'. Each section contains input fields for Host, Username, Password, and Port, along with a 'Test Settings' button. The 'Incoming Email Settings' section has a Port of 110 and 'Use TLS / SSL' is unchecked. The 'Outgoing Email Settings' section has a Port of 25 and 'Use TLS / SSL' is checked. The 'FTP Settings' section has a Port of 21. At the bottom of the dialog are buttons for OK, Cancel, Apply, and Help.

The following can be specified for the Internet category:

Incoming Email Settings

Incoming email settings are not currently used by the program.

Host: This is the name of the host for incoming emails.

Port: This is the port to use for incoming emails.

Username: This is the username to use for incoming emails.

Password: This is the password to use for incoming emails.

Use TLS/SSL: Check this to use TLS or SSL for incoming emails.

Test Settings: Click this button to test the incoming email settings.

Outgoing Email Settings

Outgoing email settings are used to send email.

Host: This is the name of the host for outgoing emails.

Port: This is the port to use for outgoing emails.

Username: This is the username to use for outgoing emails.

Password: This is the password to use for outgoing emails.

Use TLS/SSL: Check this to use TLS or SSL for outgoing emails.

Test Settings: Click this button to test the outgoing email settings.

FTP Settings

FTP settings are used to send data directly to FTP.

Server: This is the name of the FTP server.


Port: This is the port to use for the FTP server.

Username: This is the username to use for the FTP server.

Password: This is the password to use for the FTP server.

Test Settings: Click this button to test the FTP settings.

1.6.8 Maintenance



The following can be edited in the Maintenance category:

Application Updates

Check for updates: Check this box to automatically check for program updates on the Internet.

Schedule: Select the schedule to check for program updates.

Application Maintenance

Perform maintenance tasks: This is used to select whether to perform maintenance tasks.

Delete expired cache objects: Check this box to delete cache images of objects when maintenance is performed.


Check for unassociated projects: Check this box to find and delete projects that are in the project database but not in the project list.

Schedule Tasks: Select the schedule to perform maintenance.

Perform every: If the schedule is custom, this is used to specify the number of days between maintenance tasks.

Run now: Click this button to run maintenance tasks now.

1.6.9 Network License



The following can be edited in the Network License category (these features should not be changed without consulting your database administrator):

Networked: This is used to indicate whether the program and licensing is running from a central database and server.

Network Settings

Name or IP Address: This is the name or IP address of the server.

Port Number: This is the port number for the server. If the program is not networked it will be disabled. It should be set to 3002.

Request network licenses for: This is the modules to request licenses from the server.

Clear auto-login: Click this button to clear the auto-login file. The next time you login you will be required to enter a username and password.

1.6.10 Pollute and Migrate

The following can be specified for the Internet category:

Defaults

Time Units: This is the default time units to use when creating a model.

Depth Units: This is the default depth units to use when creating a model.

Concentration Units: This is the default concentration units to use when creating a model.

Symbol Library: This is the default symbol library to use when creating a model.

Layer Defaults

Number of Sublayers: This is the default number of sublayers to use when adding a layer.

Porosity: This is the default porosity to use when adding a layer.

Thickness: This is the default thickness to use when adding a layer.

Dry Density: This is the default dry density to use when adding a layer.

Dispersion Coefficient: This is the default dispersion coefficient to use when adding a layer.

Subsurface Image

Draw text leaders: Check this box to draw leader lines from the text to the layers.

Width: This is the width of the image in pixels.

Height: This is the height of the image in pixels.

Leader Line Style: Press this button to select the line style for the leader lines.

Layer Line Style: Press this button to select the line style for the layers.

Model Title Font: Press this button to select the font for the model title.

Model Text Font: Press this button to select the font for the model text.

Results


Default Display: This is the default display to use for the results.

1.7 Symbol Libraries

Libraries are used to store symbols that can be used for layers and boundaries. Libraries contain 18 symbols each, the program comes with several previously defined libraries. In addition, any number of new libraries can be created, making the number of symbols available unlimited. Each symbol also has a default symbol description stored in the library, which is used when selecting the symbol.

1.7.1 Creating a Library

Libraries can be created and edited at any time (no project has to be open). To create a library select [Tools > Symbol Libraries > New](#). After this the Create New Symbol Library form will be displayed.



The following information can be entered on this form:

Unique Library ID: This is a unique id or name for the library (up to 100 characters).

Name: This is the name of the library (up to 255 characters).


After the above information has been entered a blank library will be created and displayed. This library will contain 18 blank symbols and descriptions, which can be [edited](#) ⁶⁹ as discussed below.

1.7.2.1 Symbols

Common Symbols

	Sand		Silty Sand		Sandy Silt
	Clayey Sand		Sand and Gravel		Gravel
	Silt		Clayey Silt		Clay
	Silty Clay		Sandy Silty Clay		Silty Sand and Gravel
	Silty Gravel		Silty Clay and Gravel		Topsoil
	Peat		Limestone		Shale

Each library can contain up to 18 symbols. The symbols in the library can be edited by clicking on them. After this the Edit Bitmap form will be displayed.



At the top of this form the symbol description can be entered. Underneath the description the bitmap of the symbol is displayed. The buttons at the top of the form can be used to edit the bitmap as described below.



The Clear button is used to erase the entire symbol.



The Import Picture button is used to import a bitmap picture from a file into the current symbol. When this button is pressed, the Open bitmap form will be displayed. Select the bitmap file to import and then press the Open button.



The **Erase** button is used to delete parts of the symbol. When this button is pressed the cursor will change to an eraser. To erase a part of the symbol, hold the left mouse button down and move the cursor over the area to be erased.



The Curve button is used to draw a curved line on the symbol. When pressed the cursor will change to a pencil. To draw a curve, hold down the left mouse button and move the mouse. When finished drawing the line, release the mouse button.



The Line button is used to draw a straight line on the symbol. When pressed the cursor will change to a pencil. To draw a line, press and hold down the left mouse button at the start of the line. Move the mouse to the end of the line and release the mouse button.



The Rectangle button is used to draw a hollow rectangle on the symbol. When pressed the cursor will change to a cross. To draw a rectangle, press and hold down the left mouse button at the upper left corner of the rectangle. Move the mouse to the lower right corner of the rectangle and release the mouse button.



The Ellipse button is used to draw a hollow ellipse on the symbol. When pressed the cursor will change to a cross. To draw an ellipse, press and hold down the left mouse button at the upper left corner of the ellipse. Move the mouse to the lower right corner of the ellipse and release the mouse button.



The Undo button is used to undo the previous edit operation.

1.7.3 Deleting a Library


To delete a library, select [Tools > Symbol Libraries > Delete](#). The Delete Libraries form will be displayed.

1.8 Units

Various types of units are used throughout the application. The precision and conversion of these units are described in the sections below.

1.8.1 Unit Precision

The precision (significant digits) used in the display of the units used in the application can be adjusted by selecting [Tools > Units > Unit Precision](#), the Unit Precision form will be displayed.




The Unit Precision dialog box is shown with a blue title bar. It contains a 'Unit Type:' dropdown menu set to 'Concentration'. Below this is a table with two columns: 'Unit' and 'Precision'. The first row is highlighted in blue. A tooltip 'Select the type of units' is visible over the 'Unit' column header. At the bottom are three buttons: 'OK' (with a green checkmark), 'Cancel' (with a red X), and 'Help' (with a blue question mark).

Unit	Precision
µg/L	8
mg/L	8
ppm	8
ppb	8
µg/kg	8
mg/kg	8
g/L	8
kg/L	8

To adjust the precision for a set of units, select the type of units and then change the precision for the unit. If the precision is specified as -1 then the precision (significant digits) is assumed to be infinite.

1.8.2 Unit Conversion

Values can be converted from one set of units to another using the unit conversion function by selecting [Tools > Units > Conversion](#), the Unit Conversion form will be displayed.



The image shows a 'Unit Conversion' dialog box with a blue title bar. It contains the following elements: a 'Unit Type' dropdown menu set to 'Concentration'; 'Input Units' and 'Output Units' dropdown menus set to 'mg/L' and 'ppb' respectively; an 'Input Value' text box containing '0'; an 'Output Value' text box containing '0'; a 'Convert' button with a circular arrow icon; and three buttons at the bottom: 'OK' with a green checkmark, 'Cancel' with a red X, and 'Help' with a blue question mark.

To convert a value select the type of units and then the input and output units. Then enter the input value (value to be converted) and press the Convert button. The converted value will be displayed using the number of significant digits specified for the type of units.

1.9 Help and Support

GAEA Technologies strives to make this application easy to use and learn. Several tools and features are provided to assist the user to learn the program and when necessary get technical support. These features can be found in the Help menu of the main menu and are described below.

1.9.1 Help System

In addition to the User's Guide in PDF format, context sensitive help can be found within the application. The help system can be displayed by either selecting [Help > Contents](#) or clicking on the Help button on a form. When the Help button on a form is used, the help displayed will be specific to that specific form.

1.9.2 Technical Support

Customers with a current technical maintenance agreement can receive technical support by selecting [Help > Email Technical Support](#). This is the preferred method of obtaining technical support since it provides us with the maximum amount of information and data concerning your problem. Before emailing technical support you will need to provide the [outgoing email settings in preferences](#) for the email to be sent by the application.

Email Technical Support

Sender's Information

Company:

Name:

Email: Phone:

Computer/Application Information

Operating System:

Name	Ver	Lic	Net
Pollute Module	8.00	☒	☐

Data

☒ Main Database

☒ Project Database

Error Description

Error:

Detailed Description of the Error (ie.. Steps to reproduce it)

The following is displayed and/or edited on this form:

Company: This is your company or organization name that has the license for the program.

Name: This is your name.

Email: This is your email address.

Phone: This is your phone number.

Operating System: This is Windows operating system of the computer. It is automatically filled in by the application and can not be changed.

Modules: This is a list of the modules, versions, licenses, and networking for the application. It is filled in automatically by the application and can not be changed.

Main Database: Check this to attach the main database for the application. It include project boundaries, templates and project documents. It is highly recommended that this database is included in your email.

Project Database: If a project is opened, this will be displayed. Check this to include the project database with your email. If your problem involves project specific data (boreholes, cross-sections, samples, etc.) please include this database.

Error: This is brief description of the error that will be shown in the subject of the email.

Description: This is a detailed description of the error or problem. Please provide as much information as possible.

1.9.3 Updates

Updates to the program are periodically published online and can be installed by selecting [Help > Check for Updates](#). If an update is available from the Internet, you will be asked whether to install it or not. We strongly recommend you install all updates.

Pollute & Migrate

User Guide

Chapter 2 Projects

Chapter 2 Projects

Projects are the primary building block of POLLUTE and MIGRATE application and are used to encapsulate all the data in the application. The sections below describe how to manage projects, import data into projects, and export data from projects.

The initial display will consist of a basemap (or project list) and sidebars on the left and right. The basemap shows your existing projects and any GIS data contained in the web map service. To the left of the basemap, the sidebar usually shows a list of your projects. And the right sidebar usually shows a list of layers in the basemap and an index map. Prior to use projects must either be created or imported. After this they can be selected from the basemap or sidebar and edited.

On the project tree sidebar, projects can be grouped into categories and subcategories. These groupings can be used to sort projects by things such as year, office, and client. The creation and editing of these categories and subcategories is described in the section on editing [project categories](#)^[109] below. In addition, the most recently opened projects are grouped at the top of the project tree.

Projects can be assigned to a category or subcategory when they are [created](#)^[80] or edited.

2.1 Creating a Project

There are two types of projects, georeferenced or local. Georeferenced projects have GIS based coordinates, normally in decimal degrees, and can be seen on basemaps. Whereas, local projects have coordinates in feet or meters and are not shown on basemaps.

Georeferenced Project

If the project is to be georeferenced, the area of the basemap where the project is located should be zoomed in on first before creating the project. To assign the project to a category or subcategory on the project tree, highlight the category or subcategory first and then create the project. To create a new georeferenced project either select [File > New > Project > Georeferenced](#) or click the New button on the main toolbar and select [Project > Georeferenced](#).

After this you will need to specify the boundaries of the project on the basemap. To do this click the left mouse button at each of the points on the project boundary, then double click or right click when done. Projects can be square or polygonal. The New Project form will then be displayed. This form has four tabs for a georeferenced project as described in the sections below.

Local Project

To create a new local project either select [File > New > Project > Local](#) or click the New button on the main toolbar and select [Project > Local](#). The New Project form will then be displayed. This form has three tabs for a local project as described in the sections below.

2.1.1 Project Info Tab

The screenshot shows a 'New Project' dialog box with a blue title bar. It has four tabs: 'Project Info' (selected), 'Boundary', 'Local Coordinates', and 'Category'. The 'Project Info' tab contains three sections: 'Project', 'Client', and 'Address'. The 'Project' section has 'Number:' and 'Name:' text boxes, and a 'Set password' checkbox. The 'Client' section has 'ID:' and 'Name:' text boxes. The 'Address' section has 'Address:', 'City:', 'State/Province:', 'Country:', and 'Postal/ZIP Code:' text boxes. At the bottom are 'OK', 'Cancel', and 'Help' buttons.

Section	Field	Type
Project	Number	Text Box
	Name	Text Box
	Set password	Checkbox
Client	ID	Text Box
	Name	Text Box
Address	Address	Text Box
	City	Text Box
	State/Province	Text Box
	Country	Text Box
	Postal/ZIP Code	Text Box

The following information can be specified on this tab:

Project Number: This is the unique project number.

Project Name: This is the name of the project.

Set Password: Check this box to set a password for the project.

Password: If Set Password is checked the password can be specified,

Client ID: This is an optional client identification.

Client Name: This an optional client name.

Address: This is the street address of the project.

City: This is the city of the project.

State/Province: This is the state or province of the project.

Country: This is the country of the project.

Postal/ZIP Code: This is the postal or ZIP code of the project.

2.1.2 Boundary Tab

This tab is shown for georeferenced projects only and used to specify the georeferenced boundary points.

New Project

Project Info | **Boundary** | Local Coordinates | Category

Coordinate System

☒ Geographic System ☐ Projected System

Geographic System: WGS 84 (epsg:4326)

Display

☐ Degrees Minutes Seconds ☒ Decimal Degrees

Boundary Points

Point	Longitude	Latitude
1	-79.614904	43.71396
2	-79.611091	43.713742
3	-79.611544	43.711122
4	-79.6143	43.711422
5	-79.614904	43.71396

Longitude

☐ East ☒ West

Latitude

☒ North ☐ South

Units: Degrees

OK Cancel Help

The default coordinate system for georeferenced projects is the WGS 84 geographic system. Alternate geographic or projected coordinate systems can be selected; however, the coordinates stored in the database will be in the default system.

Coordinate System

Geographic System: Select this to specify the boundary in geographic coordinates.

Projected System: Select this to specify the boundary in projected coordinates.

Coordinate System: This is used to select the geographic or projected coordinate system.

Degrees Minutes Seconds: If the selected coordinate system is geographic, select this to specify the coordinates as degrees, minutes, and seconds.

Decimal Degrees: If the selected coordinate system is geographic, select this to specify the coordinates in decimal degrees.

Boundary Points

Longitude: If it is a geographic coordinate system, this is the longitude of the boundary point in either decimal degrees or degrees, minutes, and seconds.

Latitude: If it is a geographic coordinate system, this is the latitude of the boundary point in either decimal degrees or degrees, minutes, and seconds.

X Coordinates: If it is a projected coordinate system, this is the x coordinate of the boundary point.

Y Coordinates: If it is a projected coordinate system, this is the y coordinate of the boundary point.

Add Point: Press this button to add a point to the boundary.

Delete Point: Press this button to delete the selected boundary point.

2.1.3 Local Coordinates Tab

The information on the local coordinates tab will depend on whether it is a local or georeferenced project.

2.1.3.1 Georeferenced

If the project is a georeferenced project the map coordinates will be in decimal degrees. For display in 3D local coordinates in either feet or meters will need to be assigned. Changing the local coordinates for a project after it has been created is not advisable using this tab, since only project coordinates will be changed and not the model coordinates. If it is necessary to change the coordinates after models have been created the [Assign Local Coordinates](#) ⁹⁴ function should be used.

New Project

Project Info | Boundary | **Local Coordinates** | Category

Create Local Coordinates:

Local Units:
☒ Feet
☐ Meters

Reference Corner:
☐ Upper Left ☐ Upper Right
☒ Lower Left ☐ Lower Right

Reference Coordinate:
 X Coordinate for Corner: 0.00
 Y Coordinate for Corner: 0.00

OK Cancel Help

The following information can be specified on this tab:

Local Units: Select either feet or meters.

Reference Corner: Select the corner of the project to use as a reference. The x and y coordinates below will be assigned to this corner.

X Coordinate to Corner: This is the x coordinate of the reference corner.

Y Coordinate to Corner: This is the y coordinate of the reference corner.

2.1.3.2 Local

If the project is a local project the coordinates will be either feet or meters. Changing the local coordinates for a project after it has been created is not advisable using this tab, since only project coordinates will be changed and not the borehole or well coordinates. If it is necessary to change the

coordinates after boreholes or wells have been created the [Assign Local Coordinates](#)⁹⁴ function should be used.

New Project

Project Info **Local Coordinates** Category

Local Coordinates

Point	X-Coordinate	Y-Coordinate
1	0	0
2	1000	0
3	1000	1000
4	0	1000

Local Units: Feet

OK Cancel Help

The following information can be specified on this tab:


X-Coordinate: This is the x-coordinate of the boundary point.

Y-Coordinate: This is the y-coordinate of the boundary point.

Local Units: Select either feet or meters. These can only be changed when the project is created.

On the right side of the tab there are buttons to add and delete points.

2.1.4 Category Tab



Highlight the category or subcategory to assign the project to on the project tree.

2.2 Locating a Project

Georeferenced projects can be located on the basemap by clicking on the project in the sidebar and then selecting [Popup > Locate](#). The basemap will then be zoomed in so that the project can easily be identified.

2.3 Opening a Project


Projects can either be opened by selecting them from a list or selecting them on the sidebar.

Selecting from the Sidebar

To select the project from the sidebar either click on it once and then select *Popup > Open* or double-click on the project on the sidebar.

Selecting from a List

To select the project from a list either select *File > Open > Project* or click on the Open button on the main toolbar and select Project. The Open Project form below will then be displayed.



Open Project

Project Number: Find

Most Recent Projects	
Project ID /	Name
1	Examples
g1	g1

All Projects	
Project ID /	Name
1	Examples
g1	g1

Project ID

Name:

Details

Status:

Client ID:

Client:

Date Created:

Date Modified:

Open Cancel Help

On the left of this form are lists of the most recently opened projects and of all the projects. On the right side of the form the details of the highlighted project are shown, some of these details are not shown for

the most recent projects. At the top of the form is a toolbar that can be used to find a project by specifying the project number. To select a project to open, highlight it and then click on the Open button.

2.4 Editing a Project

If the project is georeferenced the GIS will show the selected web map service and project boundary; otherwise, for local projects only the project boundary is shown. The project is also used to create and open models.

The project information, local coordinates, category, and address can be edited by selecting [Edit > Project Information](#). The Project Information form will be displayed and can be edited as described in [Creating a Project](#).⁸⁰

2.5 Deleting a Project

An existing project can be deleting by selecting *File > Delete > Project*. The Delete Project form below will be displayed.

Delete Project

Project Number: Find

Most Recent Projects

Project ID ↕	Name
1	Examples
g1	g1

All Projects

Project ID ↕	Name
1	Examples
g1	g1

Project ID

Name:

Details

Status:

Client ID:

Client:

Date Created:

Date Modified:

✓ Delete


✗ Cancel

? Help

2.6 Georeferencing a Project

When projects are imported or created their spatial reference may not be known at the time of import. Georeferencing specifies a spatial location on the basemap for the project. Georeferencing can either be done manually or the location of the project can be located on the basemap.

To georeference a project make sure no project is open then select either [Tools > Projects > Georeference on Map](#) or [Tools > Projects > Georeference Manually](#). The Georeference Project form below will be displayed where you can select the project to be georeferenced.



Most Recent Projects	
Project ID	Name
1	Examples
g1	g1

All Projects	
Project ID	Name
1	Examples
g1	g1

Details	
Project ID	
Name	
Status	
Client ID	
Client	
Date Created	
Date Modified	

Buttons:

On the left of this form are lists of the most recent projects and all the projects. On the right side of the form the details of the highlighted project are shown, some of these details are not shown for the most recent projects. At the top of the form is a toolbar that can be used to find a project by specifying the project number. To select a project to georeference, highlight it and then click on the Select button.

The sections below describe the different methods for georeferencing a project.

2.6.1 Georeferencing to a Point

If the project is to be georeferenced to a point on the map you will then need to click on the basemap at one of the boundary pointss of the project. After this the Georeference Project form below will be displayed.

Georeference Project

Project Number: g1

Project Name: g1

Location in decimal degrees

Map X: -79.53664644

Map Y: 43.71865350

Existing Boundary Points

Point	Longitude	Latitude
1	-80.458891	43.418421
2	-80.444373	43.415064
3	-80.451302	43.404518
4	-80.46714	43.406915
5	-80.458891	43.418421

New Boundary Points

Point	Longitude	Latitude
1	-79.53664644	43.7186535
2	-79.52212844	43.7152965
3	-79.52905744	43.7047505
4	-79.54489544	43.7071475
5	-79.53664644	43.7186535

OK

Cancel

Help

The following information can be specified on this form:

Map X: This is the X location, normally longitude, for the point on the project boundary.

Map Y: This is the Y location, normally latitude, for the point on the project boundary.

Existing Boundary Points: These are the current project boundary points. Select the line containing the point that will be assigned the new map location and the new boundary points will be adjusted.


New Boundary Points: These are the new project boundary points.

2.6.2 Georeferencing Manually

Georeferencing a project manually is very similar to [georeferencing a project to a point](#)⁹³, except that the longitude (Map X) and latitude (Map Y) of the point must be specified.

2.7 Assigning Local Coordinates

Sometimes, it may be necessary to assign the local coordinates to a project after the project has been created or imported. To do this select [Tools > Projects > Assign Local Coordinates](#). The select project form below will be displayed.



Assign Local Coordinates to Project

Project Number: Find

Project ID /	Name
g1	g1
Local 1	Local 1
1	Examples

Most Recent Projects

Project ID /	Name
1	Examples
Local 1	Local 1
g1	g1

All Projects


Project ID: g1
Name: g1

Details

Status: Active
Client ID:
Client:
Date Created: 2021-04-09 12:13:31 PM
Date Modified:

Select Cancel Help

Use this form to select the project and then press the Select button. The Assign Local Coordinates form below will be displayed.



The dialog box titled "Assign Local Coordinates" contains two main sections. The "Local Units" section has two radio buttons: "Feet" and "Meters", with "Meters" selected. The "Reference Corner" section has four radio buttons: "Upper Left", "Upper Right", "Lower Left", and "Lower Right", with "Lower Left" selected. Below these sections are two text input fields: "X Coordinate for Corner:" with the value "0.00" and "Y Coordinate for Corner:" with the value "0.00". At the bottom are three buttons: "Ok" (with a green checkmark icon), "Cancel" (with a red X icon), and "Help" (with a blue question mark icon).

The following information can be specified on this form:

Local Units: Select either feet or meters.

Reference Corner: Select the corner of the project to use as a reference. The x and y coordinates below will be assigned to this corner.

X Coordinate to Corner: This is the x coordinate of the reference corner.

Y Coordinate to Corner: This is the y coordinate of the reference corner.

After the Ok button is pressed the local coordinates will be assigned to the project.

2.8 Exporting a Project

Projects can be exported to an XML Exchange file or Access database file. The sections below describes how to export data from a project.

2.8.1 Exporting a Project to Access Database

Before the project can be exported it must first be [opened](#). After a project has been opened it can be exported to a project database file by selecting [File > Export > Project > To MDB](#). The select directory form below will be displayed, where you can specify the directory to store the exported project database. The exported file name consists of the project ID the letters "_PN_" and the project name with the extension ".mdb". This file name should not be changed, if it is the file will not be able to be imported. If it is necessary to change the name it is recommended that the file be zipped and the zip file name changed.

2.8.2 Exporting a Project to XML

Before the project can be exported it must first be [opened](#). After a project has been opened it can be exported to an XML Exchange file by selecting [File > Export > Project > To XML](#). The Export form will be displayed, where you can specify the file name of the exported project.

2.9 Importing a Project

Projects can be imported from XML Exchange files and Access database files. The importation of project files is described in the section below. When importing a project, no project can be open at the time.

2.9.1 Importing Access Project Databases

When importing a project, no project can be open at the time. To import a project database select [File > Import > Project > From MDB](#), the Import Project Database form will be displayed. Use this form select the project database file to be imported. The file name consists of the project ID the text "_PN_" and the project name with the extension ".mdb".

2.9.2 Importing XML Projects


When importing a project, no project can be open at the time. To import a project from an XML Exchange file select [File > Import > Project > From XML](#), the Import Project form will be displayed. Use this form select the file to be imported. If the project number of the imported project is already in the application, a new unique project number will need to be specified. After this the project will be imported and added to the project list.

2.10 Importing POLLUTEv7 Data


Project data from POLLUTEv7 can be imported either one project at a time or a list of projects can be imported as explained in the sections below.

2.10.1 Importing an individual POLLUTEv7 project

When importing a POLLUTEv7 project, no project can be open at the time. To import a POLLUTEv7 project select **File > Import > POLLUTEv7 Data > Project**, then select the project database file. The default location for the POLLUTEv7 project database files is "c:\Program Files (x86) \GAEA\Pollute\Projects".



After the POLLUTEv7 project database file has been selected, the Import POLLUTEv7 Database form will be displayed.




Import	Model #	Title
☒	1	Case 1: Subtitle D Landfill with constant source concentration
☒	2	Case 2: Pure diffusion
☒	3	Case 3: Advective diffusive transport
☒	4	Case 4: Finite mass source
☒	5	Case 5: Hydraulic trap - Finite mass source
☒	6	Case 6: Fractured layer and sorption
☒	7	Case 7: Fractured rock and radioactive decay
☒	8	Case 8: Diffusion with initial concentration profile
☒	9	Case 9: Freundlich Non-linear sorption
☒	10	Case 10: Time-varying advective-dispersive transport
☒	11	Case 11: Time varying source concentration with background
☒	12	Case 12: POLLUTE vs Analytical solution
☒	13	Case 13: Comparison with analytical method
☒	14	Case 14: Primary and Secondary Leachate Collection
☒	15	Case 15: Leachate Collection with Failure.
☒	16	Case 16: Monte Carlo Simulation
☒	17	Case 17. Landfill with composite primary liners.


This form lists the models in the POLLUTEv7 project. Either all of the models can be selected or individual models selected using the All Models and Import check boxes. The model ID for the imported POLLUTEv7 models can be specified using either the Model Number or Model Title.

2.10.2 Importing a list of POLLUTEv7 projects

When importing a list of POLLUTEv7 projects, no project can be open at the time. To import multiple POLLUTEv7 projects select [File > Import > POLLUTEv7 Data > Project List](#) then select the POLLUTEv7 main database file. The file name is "PMProjects.mdb" and is normally stored in "c:\Program Files (x86) \GAEA\database".



After the POLLUTEv7 main database file has been selected, the Import POLLUTEv7 Project List form will be displayed.



Import	ID	Name	Directory	OldID
☒	1	Examples	c:\Users\mfras\AppData\Local\VirtualStore\Program Files	1
☒	2	estr 1	c:\Users\mfras\AppData\Local\VirtualStore\Program Files	2


This form lists the projects in the POLLUTEv7 main database. Either all of the projects can be selected or individual projects selected using the All Projects and Import check boxes. The model ID for the imported POLLUTEv7 models can be specified using either the Model Number or Model Title.

2.11 Importing POLLUTEv8 Data

Project data from POLLUTEv8 can be imported either one project at a time or a list of projects can be imported as explained in the sections below.


2.11.1 Importing an individual POLLUTEv8 project

When importing a POLLUTEv8 project, no project can be open at the time. To import a POLLUTEv8 project select *File > Import > POLLUTEv8 Data > Project*, then select the project database file. The default location for the POLLUTEv8 project database files is "c:\Program Data\GAEA\PolluteMigrate8\Databases\Projects".




2.11.2 Importing a list of POLLUTEv8 projects

When importing a list of POLLUTEv8 projects, no project can be open at the time. To import multiple POLLUTEv8 projects select *File > Import > POLLUTEv8 Data > Project List* then select the POLLUTEv8 main database file. The file name is "pollutemigrate.mdb" and is normally stored in "c:\Program Data\GAEA\PolluteMigrate8\Databases".



After the POLLUTEv8 main database file has been selected, the Import POLLUTEv8 Project List form will be displayed.


Select Projects



Select	Project Name	Project ID
☒	Examples	1
☒	gfdgfdxfgd	10


This form lists the projects in the POLLUTEv8 main database. Either all of the projects can be selected or individual projects selected using the All Projects and Import check boxes. After the projects have been selected click Next.

Resolve Conflicts



If any of the projects to be imported already exist, the conflict will be shown and you can choose to skip the import of the project or overwrite the existing project. After all of the conflicts have been resolved click Next.

Import Projects



After the projects have been imported click on Done.

2.12 Querying Projects

Project queries can be used to select projects based on their location, project ID, client and other selection parameters. To query projects, select **Tools > Projects > Query Projects**. The Query Projects form will be displayed.

This form is used to specify the selection queries to be used to select the projects. More than one query can be used for the query, the queries to be used are shown on the left side of the form. For a project to be selected it must meet all of the queries.

To select additional queries use the Select Query combo box on the form. These queries can be based on areal extent, client ID, client, project name, project ID, date created, or status. When an additional query is selected, the parameters for the query can be specified beneath the combo box. After the parameters of the query have been specified the query can be added to the list by pressing the Add Query button. After a query has been added to the list it can be removed by selecting it on the list and pressing the Remove Query button. The added query can be modified by selecting it in the list, changing its parameters, then clicking on the Update button.

The following wildcards can be used within the parameters:

Symbol	Description	Example
%	Represents zero or more characters	bl% finds bl, black, blue, and blob
_	Represents a single character	h_t finds hot, hat, and hit

[]	Represents any single character within the brackets	h[oa]t finds hot and hat, but not hit
^	Represents any character not in the brackets	h[^oa]t finds hit, but not hot and hat
-	Represents a range of characters	c[a-b]t finds cat and cbt

To conduct the query, press the Perform Query button at the top of the form. The results of the query will be display on the Results tab. This tab will list the projects that meet the query.

Query Projects

Selection Parameters Results

Open Export


Project ID	Project Name	Status	Client ID	Client	Date Created
Local 1	Local 1	Active - Unkn			2021-04-12
g1	g1	Active			2021-04-09

Done Help

A project from the list can be opened by selecting and then pressing the Open button. In addition, the list can be exported to an Excel file by pressing the Export button.

2.13 Editing Project Categories

The project categories and subcategories on the project tree in the sidebar can be edited by selecting [Tools > Projects > Edit Project Tree](#). The Edit Project Tree Categories form will be displayed. This form displays the project categories and subcategories in tree consisting of nodes and sub-nodes.



The buttons at the top of the form can be used for the following:


Add: To add a project category, highlight the Projects node and click on the Add button then enter the name below. To add a project subcategory, highlight the category and click on the Add button then enter the name below.

Edit: To edit a project category or subcategory, highlight it and click on the Edit button. Then edit the name below.

Remove: To remove a project category or subcategory, highlight it and click on the Remove button.

2.14 Changing a Project Number

The project number is used to uniquely identify all objects associated with the project and should not normally be changed. However, if it is required to be changed the menu item [Edit > Change Project Number](#) can be used. This menu item is only available when no project is open. When selected the Select Project form below will be displayed.



Project ID /	Name
g1	g1
Local 1	Local 1
1	Examples

Project ID /	Name
1	Examples
Local 1	Local 1
g1	g1


Project ID	g1
Name	g1
Details	
Status	Active
Client ID	
Client	
Date Created	2021-04-09 12:13:31 PM
Date Modified	

Map showing geographical area with roads and green spaces.

Buttons:

On the left of this form are lists of the most recently opened projects and of all the projects. On the right side of the form the details of the highlighted project are shown, some of these details are not shown for the most recent projects. At the top of the form is a toolbar that can be used to find a project by specifying the project number. To select a project, highlight it and then click on the Select button.

Using this form select the project number to change and press select. The Enter New Project ID and Name form will be displayed.



Enter New Project ID and Name

Existing Projects

1
g1
Local 1

Project ID:

Project Name:

This form is used to enter the unique new project number and name. After this is entered press the Ok button to finalize the change. The existing project will then be exported to a temporary XML file, then the XML file will be imported with the new project number and name, and finally the old project will be deleted.

Pollute & Migrate


User Guide

Chapter 3 Pollute Models


Chapter 3 Pollute Models

Models are used to represent the subsurface lithology, containment systems, and contaminant source to be studied. These models can be used to study the effects of landfills, buried waste, spills, lagoons, barrier systems, etc. Each study area should be grouped into one or more projects. A project is used to store one or more models in a study area. After a model has been created it can be run to calculate the concentrations of a contaminant at specified depths and times.

3.1 Creating a New Model



After a project has been created or opened, a model can be created either by clicking on the New button and selecting Pollute Model or selecting [File > New > Pollute Model](#). The New Pollute Model form below will be displayed.



Select the template to use for the model and enter a unique model name. When a template is selected it will be shown in the Preview. The Existing tab lists the existing models in the project. After the unique name is entered press the Ok button to create the model and open it for editing.

The program comes with the templates described below. In addition, you can create your own templates as described in the section [Creating a Template](#)²⁹¹.

Blank

This is an empty model that requires the majority of the data to be entered when it is created. If no template is selected, the blank template is used to create the model.

Primary Landfill

The Primary Liner (Subtitle D) Landfill option is used to quickly enter a landfill that may contain a leachate collection system, primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the leakage through the geomembrane can be calculated using either equations by Rowe et. al., 2004; equations by Giroud et. al., 1992; or by specifying and equivalent hydraulic conductivity for the geomembrane.

Primary and Secondary Landfill

The Primary and Secondary Liner Landfill option is used to quickly enter a landfill that may contain a primary leachate collection system, primary composite liner, secondary leachate collection system, secondary composite liner, aquitard, and aquifer. In this option the composite liners can be composed of a geomembrane and/or compacted clay or GCL. The leakage through the geomembrane can be calculated using either equations by Rowe et. al., 2004; equations by Giroud et. al., 1992; or by specifying and equivalent hydraulic conductivity for the geomembrane.


Vertical Migration

The Vertical Migration option is used to quickly enter a model for the vertical migration of a contaminant from a waste mass into an aquifer. The model may contain a primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a clay liner. If the geomembrane is present the leakage through the geomembrane is calculated using equations by Rowe et. al., 2004.


Horizontal Migration

The Horizontal Migration option is used to quickly enter a model for the horizontal migration of a contaminant from a waste mass to the site boundary. The model may contain a primary composite liner and an aquitard. In this option the primary composite liner can be composed of a geomembrane and a clay liner. If the geomembrane is present the leakage through the geomembrane is calculated using equations by Rowe et. al., 2004.

3.2 Opening a Model



To open an existing model either select **File > Open > Pollute Model**, press the Open button on the toolbar and select Pollute Model, or double-click on it in the list of models. If the first two methods are used the Open Pollute Model form will be displayed.




This form lists the most recently opened models at the top and all of the models on the bottom. When a model is selected a preview for it will be shown on the right. Select the model to open and then click on the Open button.

3.3 Editing a Model

After a model has been created or opened, depending on the template it can be edited using the methods below.

3.3.1 Editing a Normal Model

If the model was created using the Blank template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the four tabs for General data, Layers, Boundaries, and Special Features. In addition, there is a tab for the subsurface model.



The data entry for the General data, Layers, and Boundaries is described in the sections below. The data entry for the Special Features is the same for all the templates and is described in the [Editing Special Features](#) ^[158] section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#) ^[174]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#) ^[178].

3.3.1.1 General Data

To edit the general data for a model click on the General tab on the left side of the model form.

General Information

Model Title: Case 2: Pure diffusion

Maximum Depth: 4 m

Darcy Velocity: 0 m/year

Laplace Transform Parameters

TAU: 7 N: 20 SIG: 0 RNU: 2

Run Parameters

Output Units: Time Units: year Depth Units: m Concentration Units: mg/L

☐ All Depths ☒ Specified Depths

☒ Concentrations at Specified Times ☐ Maximum Concentrations

Depth	Units
0	m

Time	Units
10	year
50	year
100	year
150	year
200	year

The following can be specified on this tab:

General Information

Model Title: This is the title of the model is used to describe the model, and may be up to 255 characters long.

Maximum Depth: This is the maximum depth of the model including the bottom boundary condition. It is used only for drawing purposes and will not affect the calculations within the model.

Darcy Velocity: The Darcy Velocity is defined as: $v_a = n v$ where, n = the effective porosity, v = the seepage (groundwater) velocity. If zero is entered for the Darcy velocity the transport mechanism will be purely diffusive. When the Variable Properties or Passive Sink options have been selected the Darcy Velocity parameter is omitted, since it is entered in these options.

Laplace Transform Parameters

The solution of the contaminant migration equations involves the inversion of a Laplace Transform. In this inversion the accuracy depends upon four parameters: TAU, N, SIG, and RNU. The user may adopt the default values (TAU=7, SIG=0, N=20, and RNU=2) or specify other values. It has been found that a value of TAU between 7 and 10, and a value of SIG = 0 is satisfactory in most cases. The more critical parameters, RNU and N, typically yield accurate results when:

$$RNU = (0.1 * \text{Layer Thickness} * \text{Darcy Velocity}) / (\text{Minimum Diffusion/Dispersion Coefficient})$$

and

$$N = 10 * RNU \text{ if } RNU \text{ is greater than } 1.0.$$

These values of RNU and N will work extremely well but will often require more integration than is necessary. If the computation times seem excessive smaller values of RNU and N should be tried, and the accuracy of the results compared. The program will detect grossly unreasonable results and automatically repeat the calculation with the values suggested above, in this circumstance the value of RNU is limited to 40.

Run Parameters

The run parameters specify the depths and times to calculate the concentrations for the model.

Time Units: The output units for the times can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

Depth Units: The output units for the depths can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

Concentration Units: The output units for the concentrations can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

All Depths or Specified Depths: This allows you to select whether to calculate the concentrations at all depths or at selected depths. If All Depths is selected, the concentrations will be calculated at the boundary between all sublayers. If you wish to calculate at selected depths then the depths can be added and removed using the Add and Delete buttons.

Type of Output: There are two types of output that can be generated, either concentrations at specified times or maximum concentrations. If Concentrations at Specified Times is selected the Times can be added and removed using the Add and Delete buttons.

The screenshot shows a dialog box titled 'Run Parameters'. At the top, there are two radio buttons: 'Concentrations at Specified Times' (unselected) and 'Maximum Concentrations' (selected). Below the radio buttons, there are five input fields with labels and units:

- Search Depth:** A text box containing '0' followed by a dropdown menu showing 'm'.
- Accuracy (%):** A text box containing '0.25'.
- Number of Iterations:** A text box containing '25'.
- Lower Time Limit:** A text box containing '0' followed by a dropdown menu showing 'year'.
- Upper Time Limit:** A text box containing '0' followed by a dropdown menu showing 'year'.

If the top boundary condition is Finite Mass or Constant Concentration, then the contaminant concentration at any depth will reach a maximum value at a determinable time. After reaching this maximum value the concentration will decrease if the contaminant source is finite (i.e., the Reference Height of Leachate is finite), or the concentration will remain at the maximum value if the contaminant

source is infinite (i.e., Constant Concentration top boundary condition). When the output type is maximum concentrations then the following can be specified:

Search Depth: This is the depth for which to search for the maximum concentration, any depth between 0 and the maximum thickness of the deposit above the base boundary. The default depth is the depth of the base boundary. In searching for the maximum concentration the depth used will be the depth closest to the nearest sublayer interface. It is recommended that the user be sure to have a sublayer interface at the depth requested, or specify a large number of sublayers for the layer.

Accuracy: This is the accuracy to which the maximum base concentration is to be calculated, typically a value of 0.1% is used.

Number of Iterations: This is the maximum number of iterations to try to obtain the maximum base concentration to the required accuracy, typically a value of 25 is used. If the lower and upper time limits are well selected, convergence to an accuracy of 0.1% can usually be obtained within 10 iterations.

Upper and Lower Time Limits: The user needs to specify lower and upper time limits in which the maximum is expected to occur. If the lower and upper time limits do not bracket the time of the maximum, the program will usually adjust the time limits to include the time of the maximum. However, if both the specified limits are at times when there is negligible concentrations at the depth being considered, then the program may not be able to find a meaningful maximum. If the top boundary condition is Constant Concentration and the lower time limit is close to or above the time of the maximum, the program will adjust the lower time limit until it is lower than the time of the maximum. When the top boundary condition is Constant concentration, the user is advised to check the results by using different values for the lower and upper time limits.

3.3.1.2 Layers

To edit the layer data for a model click on the Layers tab on the left side of the model form.

Name	Sublayers	Thickness	Thickness Units	Dry Density	Density Units	Porosity	Hydrodynamic Dispersion Coefficient	Dispersion Units	Distribution Coefficient	Distribution Units	Fractures	Symbol
Primary Liner	4	0.6	m	1.9	g/cm ³	0.4	0.02	m ² /a	1.5	cm ³ /g	None	
Unsaturated Collection	4	0.2	m	1.9	g/cm ³	0.45	300	m ² /a	0	cm ³ /g	None	
Saturated Collection	4	0.1	m	1.9	g/cm ³	0.45	100	m ² /a	0	cm ³ /g	None	
Secondary Liner	4	0.75	m	1.9	g/cm ³	0.4	0.02	m ² /a	1.5	cm ³ /g	None	

At the top of the tab there are buttons for:

Add: Add a layer below the currently selected layer.

Delete: Delete the currently selected layer.

Copy: Copy the currently selected layer to the clipboard.

Paste: Paste the layer in the clipboard below the currently selected layer.

Move Down: Move the currently selected layer down.

Move Up: Move the currently selected layer up.

The following can be specified for each layer:

Name: This is the name of the layer. It is used only for drawing and output.

Number of Sublayers: The number of sublayers in each layer is primarily used in the output of the calculated concentrations with depth; a concentration will be calculated at each sublayer interface. If the Freundlich Non-Linear Sorption, Langmuir Non-Linear Sorption, or Variable Properties Special Feature is selected, the accuracy of the results will depend on the number of sublayers.

Thickness: This is the thickness of the layer, this is the total thickness of all the sublayers in the layer.. The maximum thickness of each sublayer is 5 units. This maximum can be adjusted using the Maximum Sublayer Thickness option of the Special Features menu. If the maximum sublayer thickness is not changed then the number of sublayers is automatically increased if required to keep their thickness to less than 5.

Dry Density: The dry density of the layer.

Porosity: This is the porosity of the layer, which must be greater than 0 and less than or equal to 1. If the layer is being used to represent a geomembrane the porosity should be set to 1.

Coefficient of Hydrodynamic Dispersion: This is the coefficient of hydrodynamic dispersion for the layer:

$$D = D_e + D_{md}$$

where,

D_e = the diffusion coefficient for the species,

D_{md} = the coefficient of mechanical dispersion.

For intact clayey layers, diffusion will usually be the controlling factor and dispersion will often be negligible [Gillham and Cherry, 1982, Rowe, 1987; Rowe et al, 2004]. In sandy layers, dispersion will tend to be the controlling factor. If the Variable Properties option of the Special Features submenu is selected the dispersivity can be specified separately.

Distribution Coefficient: This is the distribution coefficient for the layer. In the basic mode (ie. where Langmuir Non-linear sorption and Freundlich Non-linear sorption have not been selected) the sorption-desorption of a conservative species of contaminant is assumed to be linear such that:

$$S = K_d c$$

where,

S = solute sorbed per unit weight of soil,

K_d = distribution (sorption) coefficient,
 c = concentration of contaminant.

This is a reasonable approximation for low concentrations of contaminant, however at high concentrations sorption is generally not linear and more complex relationships should be used. If there is no sorption (i.e., a conservative species) the distribution coefficient is zero. Two types of non-linear sorption can be used if desired, these are Langmuir Non-Linear Sorption and Freundlich Non-Linear Sorption. Both options can be selected in the Special Features submenu.

Fractures: Any or all of the layers may be fractured. These fractures may be 1, 2, or 3 dimensional. Where the first dimension is for one set of vertical fractures, the second is for a second set of (orthogonal) vertical fractures, and the third is for horizontal fractures (ie. for a 3D block, dimension 1 is length, dimension 2 is width, and dimension 3 is depth). If 1, 2, or 3 dimensional fractures are specified for the layer, the fracture data can be entered at the bottom of the tab.

Symbol: This is used to select the symbol that will be used for the layer when drawing the subsurface model. When the symbol is clicked on the symbol can be selected as described in the [Select Symbol](#) ^[124] section.

Fractures

Continuity of concentration and flux is assumed at the boundary between layers. If a fractured layer is in contact with an unfractured layer, it is assumed that all fluid flow is transported along the fractures that intersect the unfractured layers (i.e., it is equivalent to having a very thin sand layer between unfractured and fractured layers). In a fractured model the program can consider advective-dispersive transport along the fractures coupled with diffusion into the matrix on either side of the fracture. However, if the Darcy velocity is zero, or small, then the transport mechanism will be essentially diffusive through the matrix, the fractures will have no effect and should not be considered in modeling the migration of contaminants. Users planning to model migration in fractured media are warned that they should first see Rowe and Booker, 1990, 1991a, 1991b, and Rowe et al, 2004 for a discussion of modeling of fractured systems.

The following information about the fractures in each dimension can be specified:

Fracture Spacing: The spacing of fractures is the distance between fractures in each dimension.


Fracture Opening Size: The fracture opening size is the width of the gap between the fracture walls.

Number to sum: This is the number of terms to sum in the evaluation of the advective-dispersive equation for contaminant migration [Rowe and Booker, 1990, 1991a, 1991b]. For blocks where the fracture spacing is of the same order in all directions, 8 to 10 terms is usually adequate. As the aspect ratio (horizontal spacing/vertical spacing or vertical spacing/vertical spacing) increases more terms are required in the summation. When the aspect ratio is large, the problem can usually be reduced to a lower order (eg. from 3D to 2D or 2D to 1D). For example, if the spacing between fractures in one vertical direction is 50 units, and in the other vertical and horizontal directions is 2 units. The widely spaced fractures can be ignored and the problem reduced to a 2D problem [Rowe and Booker, 1990].

Dispersion coefficient: This is the dispersion coefficient along the fracture.

Distribution coefficient: This is the distribution coefficient along the fracture as defined by Freeze and Cherry (1979). This is often assumed to be zero.

Select Symbol



The following information can be specified using this form:

Library: This combo box is used to select the symbol library to use to draw the layer. When the arrow at the right is pressed a list will display the available symbol libraries. After a library has been selected, the symbols displayed in the tab will be updated.


Symbol: The symbol from the library can be selected by clicking on one of the 18 symbols displayed for the current library. The selected symbol is highlighted with a blue border.

Foreground Color: This is the color to use for the shaded parts of the symbol. The foreground color can be changed by pressing the Foreground Color button. When this button is pressed a Color form is displayed. Using this form, a basic color can be selected or a custom color can be specified.

Background Color: This is the color to use for the unshaded parts of the symbol. The background color can be changed by pressing the Background Color button. When this button is pressed a Color form is displayed. Using this form, a basic color can be selected or a custom color can be specified.

Fill Size: The fill size is used to expand or condense the symbol. The size of the symbol is multiplied by the fill size and then the symbol is drawn. For example, a fill size of 2 will result in the symbol being doubled in size. The fill size must be greater than 0.

This form is used to select a symbol to represent a subsurface layer.



The following can be specified on this form:

Library: This is used to select the symbol library. Symbols are grouped into libraries consisting of 18 symbols. When the library is selected the symbols will be displayed in the grid below the library.

Symbol: The symbol can be selected by clicking on it in the grid. The selected symbol will be highlighted with a blue box and the description for the symbol will be displayed beneath the symbol grid.

Foreground: This is used to select the foreground color for the symbol.

Background: This is used to select the background color for the symbol.

Fill Size: This is used to specify the fill size for the symbol. Generally a value of 1 or 2 should be used.

3.3.1.3 Boundaries

For every model there are two boundary conditions, one at the top and one at the bottom. The top boundary condition is usually the point of contact between the contaminant source (eg. a landfill) and the subsurface layers (deposit), and can be either:

- Zero Flux,
- Constant Concentration, or
- Finite Mass

The bottom boundary condition is usually the point of contact between the deposit and either a much more or much less permeable strata (eg. an aquifer or bedrock) and can be either:

- Zero Flux,
- Constant Concentration,
- Fixed Outflow, or
- Infinite Thickness

To edit the boundary data for a model click on the Boundaries tab on the left side of the model form.

The screenshot shows a software window with a menu bar (Run, Auto, On, Off, Save, Save As) and a tabbed interface. The 'Boundaries' tab is active. It contains two panels: 'Top Boundary' and 'Bottom Boundary'. In the 'Top Boundary' panel, three radio buttons are present: 'Zero Flux', 'Constant Concentration' (which is selected), and 'Finite Mass'. Below these, a text input field shows '1000' and a dropdown menu shows 'mg/L'. In the 'Bottom Boundary' panel, the same three radio buttons are present, with 'Constant Concentration' selected. Below, a text input field shows '0' and a dropdown menu is visible.

Zero Flux Top Boundary Condition

The zero flux top boundary condition represents the case where there is no transmission of contaminant across the top boundary. This option is for highly specialized applications and is rarely used. If the top boundary is specified as zero flux no additional information is required.

Constant Concentration Top Boundary Condition

The constant concentration top boundary condition represents the case where the concentration of contaminant in the landfill remains constant throughout time, and is equivalent to the assumption of an infinite mass of contaminant in the landfill. If this top boundary condition is specified the following can be specified:

Concentration: This is the constant concentration for the top boundary.

Finite Mass Top Boundary Condition

The finite mass top boundary condition is most representative of a landfill, where the concentration of contaminant starts at an initial value, increases with time, and then declines as contaminant is transported into the subsurface and is removed by leachate collection systems.

Top Boundary

☐ Zero Flux
☐ Constant Concentration
☒ Finite Mass

Initial Source Concentration:

Rate of Concentration Increase:

Volume of Leachate Collected:

Specify

☐ Reference Height of Leachate ☒ Waste Properties

Waste Thickness:

Waste Density:

Proportion of Mass:

Volumetric Water Content:

Conversion Rate Half Life:

When the top boundary is finite mass the user must specify:

- Initial Source Concentration,
- Rate of Increase in concentration,
- Volume of Leachate Collected

and either:

- Thickness of Waste,
- Waste Density,
- Proportion of Mass,
- Volumetric Water Content of the waste,
- Conversion Rate Half-Life of the contaminant

or:

- Reference Height of Leachate

If the Variable Properties option has been selected from the Special Features menu, the values for the finite mass parameters will be specified in the Variable Properties entry instead.

Initial Source Concentration: This is the initial concentration of the source of contaminants, usually at time zero.

Rate of Concentration Increase: This is the rate of increase in concentration with time due to increasing mass entering the landfill. If the peak concentration is reached early in the landfill's life and the analysis starts at this time, the rate of increase would be zero.

Volume of Leachate Collected: This is the volume of leachate collected per unit area of landfill per unit time, usually by the leachate collection system. Thus, the average volume of leachate collected is equal to the average infiltration through the landfill cover less the average exfiltration through the base of the landfill (assuming the waste is at field capacity). For example, if the average infiltration is 0.3 m/a and the average exfiltration is 0.03 m/a, then the average volume of leachate collected is $0.3 - 0.03 = 0.27$ m/a.

Waste Thickness: This is the vertical thickness of the waste, and is used to calculate the mass of contaminant per unit area of waste. Either the thickness of waste or reference height of leachate must be specified.

Waste Density: This is the apparent density of the waste (i.e. mass of waste per unit volume of the landfill). Either the waste density or reference height of leachate must be specified.

Proportion of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste). Either the proportion of mass or reference height of leachate must be specified. Rowe et al (2004) report some published values for leachable mass.

Volumetric Water Content: This is the volumetric water content of the waste. Either the volumetric water content or reference height of leachate must be specified.

Conversion Rate Half-Life: The generation coefficient is calculated based on the conversion rate half-life K , such that $\lambda = \ln 2 / K$. A value of $\lambda = 0$ implies no generation of concentration with time. In the program $\lambda = 0$ is obtained by specifying $K = 0$ (this is the default case).

Reference Height of Leachate: The reference height of leachate represents the volume of leachate that would contain the total leachable mass of a contaminant of interest at the initial source concentration. Thus, the reference height (H_r) is equal to the mass of contaminant (M) per unit area divided by the initial source concentration (c_0) (i.e. $H_r = M/c_0$).

Either the reference height of leachate or the waste thickness, waste density, proportion of mass, volumetric water content, and conversion rate half-life must be specified. If the reference height of leachate is zero then the mass of contaminant is calculated using the above parameters. If the reference height of leachate is not zero then the mass of contaminant is calculated using this value, and the above parameters are ignored. For example, if there is an average of 12.5 m of waste at a density of 600 kg/m^3 and the contaminant represents 0.2% of the total waste mass, is then:

$$M = (0.2/100) (600) (12.5) = 15 \text{ kg/m}^2$$

And, if the initial source concentration is 1000 mg/L (i.e., 1 kg/m^3) then the reference height is $H_r = 15/1 = 15 \text{ m}$.

Zero Flux Bottom Boundary Condition

The zero flux bottom boundary condition represents the case where no mass is transported into or out of the bottom of the deposit. This condition can be used to represent the case of a deposit underlain by an impermeable base stratum (e.g., intact bedrock that is impermeable relative to the overlying layer or deposit). If the bottom boundary is specified as zero flux no additional information is required.

Constant Concentration Bottom Boundary Condition

The constant concentration bottom boundary condition represents the case where the concentration of contaminant remains constant in the base strata. The user will be prompted to specify the constant concentration in the base strata. If the bottom boundary condition is specified as constant concentration the following can be specified:

Concentration: This is the constant concentration for the bottom boundary.

Fixed Outflow Bottom Boundary Condition

The fixed outflow bottom boundary condition is most representative of the case where the model is underlain by an aquifer (permeable base strata). The concentration in the base strata (aquifer) varies with time as mass is transported into the aquifer from the deposit, and then transported away by the horizontal velocity in the base strata. The base aquifer is modelled as a boundary condition (not a separate layer) and the concentration at the bottom of the model is the concentration at the top of the base aquifer. This boundary condition assumes that there is sufficient dispersion/mixing such that the concentration is uniform across the thickness of the aquifer being considered. Thus the concentration at the bottom of the aquifer thickness modelled is the same as reported at the top of the aquifer. If the actual aquifer is very thick, normally only the upper portion (3 - 6 m depending on conditions) should be considered in modeling.

Bottom Boundary

☐ Zero Flux
☐ Constant Concentration
☒ Fixed Outflow Velocity
☐ Infinite Thickness

Landfill Length:
 Landfill Width:
 Base Thickness:
 Base Porosity:
 Base Outflow Velocity:
 Base Symbol 

When the bottom boundary is specified as fixed outflow the following can be specified:

Landfill Length: This is the length of the landfill in the direction of groundwater flow.

Landfill Width: This is the width of the landfill in a direction perpendicular to groundwater flow. The width is usually set to 1, since it has no influence on the results.

Base Thickness: This is the vertical thickness of the base strata that is being modelled as a boundary condition.

Base Porosity: This is the porosity of the base strata, between 0 and 1.

Base Outflow Velocity: This is the horizontal Darcy outflow velocity within the base strata at the down-gradient edge of the landfill. If the outflow velocity is set very high the results will be equivalent to setting a constant base concentration of zero. If the Variable Properties option has been selected from the Special Features submenu, the value of the Outflow Velocity will be specified in the Variable Properties option.

Base Symbol: This is used to select the symbol that will be used for the aquifer when drawing the subsurface model. When the symbol is clicked on the symbol can be selected as described in the [Select Symbol](#) ¹²⁴ section.

Infinite Thickness Bottom Boundary Condition


The infinite thickness bottom boundary condition represents the case where the deposit extends infinitely in depth. This condition can be used to model lateral migration within the deposit. If the bottom boundary is specified as infinite thickness only the base symbol is required.

Base Symbol: This is used to select the symbol that will be used for the aquifer when drawing the subsurface model. When the symbol is clicked on the symbol can be selected as described in the [Select Symbol](#) ^[124] section.

3.3.2 Editing a Primary Landfill Model

The Primary Liner (Subtitle D) Landfill option is used to quickly enter a landfill that may contain a leachate collection system, primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the leakage through the geomembrane can be calculated using either equations by Rowe et. al., 2004; equations by Giroud et.al., 1992; or by specifying and equivalent hydraulic conductivity for the geomembrane.

If the model was created using the Primary Landfill template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, Aquifer, and Special Features. In addition, there is a tab for the subsurface model.



The data entry for the General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, and Aquifer is described in the sections below. The data entry for the Special Features is the same for all the templates and is described in the [Editing Special Features](#) ^[158] section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#) ^[174]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#) ^[178].

3.3.2.1 General Data

To select the layers in the model and edit the general data click on the General tab on the left side of the model form.

The screenshot displays the 'General Information' tab of the POLLUTE and MIGRATE software. The interface includes a top toolbar with 'Run', 'Auto', 'On', 'Off', 'Save', and 'SaveAs' buttons. Below the toolbar is a tabbed menu with 'General', 'Source & Hydraulic Heads', 'Geomembranes', 'Clay Liners', 'Aquitard', 'Aquifer', 'Special Features', and 'Subsurface Model'. The 'General Information' section contains a 'Model Title' field with the text 'Case 1: Subtitle D Landfill with constant source concentration', a 'Units' section with 'Metric' selected, and a list of layers with checkboxes: 'Waste' (checked), 'Collection System' (checked), 'Geomembrane' (checked), 'Clay Liner' (checked), 'Aquitard' (checked), and 'Aquifer' (checked). Below this is the 'Laplace Transform Parameters' section with input fields for TAU (7), N (20), SIG (0), and RNU (2). The 'Run Parameters' section includes 'Output Units' (Time: a, Depth: m, Concentration: µg/L) and radio buttons for 'All Depths', 'Specified Depths', 'Concentrations at Specified Times', and 'Maximum Concentrations'. The 'Specified Depths' and 'Concentrations at Specified Times' sections contain tables for adding and deleting parameters.

Depth	Units
0	m

Time	Units
10	yr
20	yr
30	yr

The following can be specified on this tab:

General Information

Model Title: This is the title of the model is used to describe the model, and may be up to 255 characters long.

Units: This is used to select the units to use when creating the model.

Geomembrane: Check this box to include a primary geomembrane in the model. If this box is not checked the Geomembranes tab will not be present.

Clay Liner: Check this box to include a primary clay liner in the model. If this box is not checked the Clay Liners tab will not be present.

Aquitard: Check this box to include an aquitard in the model. If this box is not checked the Aquitard tab will not be present.

Aquifer: Check this box to include an aquifer in the model. If this box is not checked the Aquifer tab will not be present.

Laplace Transform Parameters and Run Parameters

The information specified for the Laplace Transform Parameters and Run Parameters is the same as described in the [General Data](#) ¹¹⁸ section for a Normal Model.

3.3.2.2 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

The screenshot shows a software interface with a top toolbar containing 'Run', 'Auto', 'On', 'Off', 'Save', and 'SaveAs' buttons. Below the toolbar is a tabbed interface with the following tabs: 'General', 'Source & Hydraulic Heads' (which is selected), 'Geomembranes', 'Clay Liners', 'Aquitard', 'Aquifer', 'Special Features', and 'Subsurface Model'. A yellow tooltip with the text 'Press to run the model' points to the 'Run' button. The 'Source & Hydraulic Heads' tab is divided into two sections: 'Source' and 'Hydraulic Heads'. The 'Source' section contains three input fields: 'Concentration' (set to 1500) with a unit dropdown set to 'µg/L', 'Landfill Length' (set to 500) with a unit dropdown set to 'm', and 'Landfill Width' (set to 300) with a unit dropdown set to 'm'. To the right of these fields is a 'Source Type' section with two radio buttons: 'Constant Concentration' (which is selected) and 'Finite Mass'. The 'Hydraulic Heads' section contains two input fields: 'Leachate Head on Primary Liner' (set to 0.3) with a unit dropdown set to 'm', and 'Groundwater level relative to top of Aquifer' (set to 0) with a unit dropdown set to 'm'.

The following can be specified on this tab:

Source

Concentration: This is the concentration for the source. It can either be a constant concentration or the initial concentration depending on the source type.

Landfill Length: This the length of the landfill in the direction of groundwater flow.

Landfill Width: This is the width of the landfill perpendicular to groundwater flow.

Source Type: This option is used to specify the top boundary condition, it can be either Constant Concentration or Finite Mass

If the source type is Finite Mass the following data can also be edited:

Waste Thickness: This is the vertical thickness of the waste, and is used to calculate the mass of contaminant per unit area of waste.

Infiltration: The average infiltration through the landfill cover.

Waste Density: This is the apparent density of the waste (i.e. mass of waste per unit volume of the landfill).

Percentage of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste).

Hydraulic Heads

Leachate Head on Primary Liner: The leachate head above the primary liner.

Groundwater level relative to top of aquifer: The groundwater level relative to the top of the aquifer, or if no aquifer is present the hydraulic gradient in the liner.

3.3.2.3 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

The screenshot shows the 'Geomembrane' tab in the software. The 'Name' field is 'Geomembrane'. The 'Leakage Method' section has 'LEAK, Rowe et al 2004' selected. The 'Calculation Method' section has 'LEAK' selected. The 'Transmissivity (THETA)' is 1E-10 m²/s and 'Conductivity (KOM)' is 0.0001 m/s. The 'Hole Frequency' is 2.5 hectare, 'Hole Radius' is 0.00564 m, 'Wrinkle Radius' is 0.00564 m, and 'CFLAG' is 0. The 'Darcy Velocity' is 2.664E-6 m/a. A 'Calculate Leakage' button is visible.

The following data can be edited on this tab:

Name: This is the name of the geomembrane layer.

Symbol: This is the symbol used to draw the geomembrane. To change the symbol click on the Change Symbol button. The [Select Symbol](#)^[124] form will be displayed where you can change the bitmap library, bitmap, foreground color, background color, and fill size for the symbol.

Number of Sublayers: This is the number of sublayers for the geomembrane and is typically 1.

Thickness: This is the thickness of the geomembrane.

Diffusion Coefficient: This is the diffusion coefficient of the geomembrane. See Rowe et al (2004) for a discussion of this parameter and a table of typical values.

Phase Parameter: This is a dimensionless phase parameter, ' K_H ' or ' S_{gf} ', as discussed in the [Introduction](#)^[21]. The default is one; this represents no phase change. See Rowe et al (2004) for a discussion of this parameter and a table of typical values for common contaminants and HDPE geomembranes.

Leakage Method: This is used to select the method for calculating the leakage through the geomembrane. It can be calculated using the equations by Rowe et. al., 2004 for either a circular hole in a geomembrane in direct contact with the foundation (similar assumptions to Giroud but allowing one to consider more variables) or for a wrinkle (or series of wrinkles) with holes (the most realistic situation for many applications); Giroud & Bonaparte, 1992; or specifying an equivalent hydraulic conductivity.

LEAK, Rowe et al 2004

If the Leakage Type specified is Rowe et. al., 2004 the following can be specified:

Transmissivity (THETA): A detailed discussion of this is given by Rowe (1998) and the effect of this parameter is examined by Rowe et al (2004). Values used in examples include: 1.6×10^{-8} m²/s for “good contact” between a geomembrane (GM) and compacted clay liner (CCL), 1×10^{-7} m²/s for “poor contact” between a GM and CCL, and 1×10^{-10} m²/s for “typical” contact between a GM and geosynthetic clay liner (GCL).

Conductivity (KOM): This is the hydraulic conductivity of the collection system or other material directly above the hole in the geomembrane. The default is 1×10^{-4} m/s.

Calculation Method: The method used to calculate the leakage can be either: LEAK - a circular hole in a geomembrane in direct contact with the foundation (similar assumptions to Giroud but allowing one to consider more variables) or Wrinkles - for a wrinkle (or series of wrinkles) with holes (the most realistic situation for many applications).

Calculate Leakage: After all of the parameters have been specified, this button can be used to calculate and display the leakage (Darcy velocity) through the geomembrane.

LEAK

LEAK

Hole Frequency: 2.5 hectare

Hole Radius: 0.00564 m

Wrinkle Radius: 0.00564 m

CFLAG: 0

If the Calculation Method is selected as LEAK the following parameters can be specified:


Hole Frequency: This is the number of holes in the geomembrane per hectare or acre. The default is 2.5 holes per hectare. See Rowe et al (2004, Chapter 13) for a discussion of the number of holes per hectare.

Hole Radius: This is the average radius of the holes in the geomembrane. The default is 0.00564 m.

Wrinkle Radius: This is the optional average radius of the wrinkles in the geomembrane. The default is 0.00564 m. A "circular hole" can be either a wrinkle or a hole (both involve fluid in direct contact with the underlying clay liner. The only differences are (a) the wrinkle is bigger and (b) if it is a wrinkle then you also need a hole in the wrinkle and leakage through that hole can be controlled by Benoulli's equation).

CFLAG: This is either 1 or 0 depending upon the boundary. CFLAG is 1 when head in the underlying aquifer is greater than zero, and is 0 when the head is greater than the thickness of the soil layer above the first aquifer.

Wrinkles



Parameter	Value	Unit
Wrinkle Frequency	10	hectare
Wrinkle Width	0.3	m
Wrinkle Spacing	10	m
Wrinkle Length	100	m
Hole Radius	0.00564	m

If the Calculation Method is selected as Wrinkles the parameters below can be specified. It is suggested that you sketch up the proposed idealized wrinkle configuration to make sure that it makes physical sense. It is easier to work in term of hectares and remember that a hectare is 100m by 100m square. When modeling Wrinkles one is modeling those wrinkles that have holes. The frequency gives the number of wrinkles with holes per hectare (or acre) while the spacing and length give the typical wrinkle dimensions. For the default 10 (100m long) wrinkles/ha the spacing must be 10m (100m/no of wrinkles=10). For 5 (100m) long wrinkles the spacing would be 20m (100m/no of wrinkles=5). But if the wrinkles were only 20m long one could have 12 of them (three row of 4) with a spacing of 25m (100m/4 wrinkles per row).

Wrinkle Frequency: This is the number of wrinkles per hectare or acre. The default is 10 per hectare.

Wrinkle Width: This is the average width of the wrinkles. The default is 0.3 m.

Wrinkle Spacing: This is the average spacing between the wrinkles. The default is 10 m.

Wrinkle Length: This is the average length of the wrinkles. The default is 100 m.

Hole Radius: This the average radius of the holes in the wrinkles. The default is 0.00564 m. This will limit the leakage that can occur through a given wrinkle.

Giroud & Bonaparte 1992

Giroud & Bonaparte, 1992

☒ Good
☐ Poor

☐ Circle
☒ Long

☐ Yes
☒ No

Hole Frequency: 1 acre

Hole Area: 0.1 cm²

Hole Length: 0 cm

Hole Width: 0 cm

Calculate Leakage Darcy Velocity

If the Leakage Type specified is Giroud & Bonaparte 1992 the following can be specified:

Contact: This is the type of contact between the geomembrane and the underlying material (either the clay liner or aquitard).

Hole Type: This is the type of holes in the geomembrane, either circles or long (rectangles).

Permeation: This is whether or not to consider permeation through the geomembrane.

Hole Frequency: This is the number of holes per hectare or acre. The default is 2.5 per hectare.

Hole Area: If the Hole Type is Circle then this parameter will be displayed. It is the average area of the holes in the geomembrane.

Hole Length: If the Hole Type is Long then this parameter will be displayed. It is the average length of the holes in the geomembrane.

Hole Width: If the Hole Type is Long then this parameter will be displayed. It is the average width of the holes in the geomembrane.

Equivalent K

Equivalent K: If the method used to calculate the leakage through the geomembrane is Equivalent K, then this parameter will be displayed. This is the equivalent hydraulic conductivity of the geomembrane. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill. Note: that the use of an equivalent K is a device for convenience of calculation and in no way represents the true leakage mechanisms. We recommend that you use the leakage equations. See Rowe et al (2004) for a discussion of leakage equations.

3.3.2.4 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

The screenshot shows the 'Clay Liner' tab in the software interface. The tab is selected, and the following parameters are visible:

- Name:** Clay Liner
- Change Symbol** button
- Number of Sublayers:** 10
- Thickness:** 0.9 m
- Density:** 1.9 g/cm³
- Conductivity K:** 1E-7 cm/s
- Diffusion Coef:** 0.02 m²/a
- Distribution Coef:** 0.5 mL/g
- Porosity:** 0.35

The following parameters can be edited on this tab:

Name: This is the name of the clay liner.

Symbol: This is the symbol used to draw the clay liner. To change the symbol click on the [Change Symbol](#) button.

Number of Sublayers: This is the number of sublayers to use for the liner. Typically, a value of 10 is used.

Thickness: This is the thickness of the clay liner.

Density: This is the density of the clay liner.

Conductivity K: This is the equivalent hydraulic conductivity of the clay liner. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill.

Diffusion Coefficient: This is the coefficient of hydrodynamic dispersion for the clay liner.

Distribution Coefficient: This is the distribution coefficient for the clay liner.

Porosity: This is the porosity of the clay liner.

3.3.2.5 Aquitard

To edit the aquitard data for a model click on the Aquitard tab on the left side of the model form. Note that this layer is an attenuation layer beneath the Clay liner. It is typically a layer with a hydraulic conductivity higher than that required for a clay liner (1×10^{-9} m/s) but less than an aquifer.

The screenshot shows the 'Aquitard' tab in a software application. The interface includes a menu bar with options like Run, Auto, On, Off, Save, and SaveAs. Below the menu is a tabbed interface with tabs for General, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, Aquifer, Special Features, and Subsurface Model. The 'Aquitard' tab is active, displaying a form with the following fields:

- Name: Aquitard
- Change Symbol button
- Number of Sublayers: 10
- Thickness: 1 m
- Density: 1.9 g/cm³
- Conductivity K: 1E-5 m/s
- Diffusion Coef: 0.02 m²/a
- Distribution Coef: 0 mL/g
- Porosity: 0.3

The following parameters can be edited on this tab:

Name: This is the name of the aquitard.

Symbol: This is the symbol used to draw the aquitard. To change the symbol click on the [Change Symbol](#) button.

Number of Sublayers: This is the number of sublayers to use for the aquitard. Typically, a value of 10 is used.

Thickness: This is the thickness of the aquitard.

Density: This is the dry density of the aquitard.

Conductivity K: This is the equivalent hydraulic conductivity of the aquitard. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill.

Diffusion Coefficient: This is the coefficient of hydrodynamic dispersion for the aquitard.

Distribution Coefficient: This is the distribution coefficient for the aquitard.

Porosity: This is the porosity of the aquitard.

3.3.2.6 Aquifer

To edit the aquifer and outflow data for a model click on the Aquifer tab on the left side of the model form.

Aquifer

Name:

 [Change Symbol](#)

Thickness: m

Porosity:

Outflow

Outflow in Aquifer

The minimum outflow velocity in the Aquifer that will fulfill the conditions of continuity of flow is: 0.004553 m/a

Outflow Velocity: m/a

Calculated Results

Darcy Velocity:

Leachate Head on Primary Liner:

Aquifer

Name: This is the name of the aquifer.

Symbol: This is the symbol used to draw the aquifer. To change the symbol click on the [Change Symbol](#) button.

Thickness: This is the thickness of the aquifer.

Porosity: The porosity of the aquifer.


Outflow

After this all of the information on the previous tabs has been entered the minimum horizontal outflow velocity in the aquifer will be calculated. You will then have the option of using this velocity or a higher velocity. In addition the calculated Darcy velocity and leachate head on the primary liner will be displayed.

3.3.3 Editing a Primary and Secondary Landfill Model

The Primary and Secondary Liner Landfill model is used to quickly enter a landfill that may contain a primary leachate collection system, primary composite liner, secondary leachate collection system, secondary composite liner, aquitard, and aquifer. In this option the composite liners can be composed of a geomembrane and/or compacted clay or GCL.

If the model was created using the Primary and Secondary Landfill template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, Aquitard, Aquifer, and Special Features. In addition, there is a tab for the subsurface model.



The data entry for the General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, Aquitard, and Aquifer is described in the sections below. The data entry for the Special Features is the same for all the templates and is described in the [Editing Special Features](#)^[158] section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[174]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[178].

3.3.3.1 General Data

To select the layers in the model and edit the general data click on the General tab on the left side of the model form.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard Aquifer Special Features Subsurface Model

General Information

Model Title: Case 17. Landfill with composite primary liners.

Units: ☒ Metric ☐ Imperial

Waste	
Primary Collection System	☒ Primary Geomembrane
Primary Geomembrane	☒ Primary Clay Liner
Primary Clay Liner	☐ Secondary Geomembrane
Secondary Collection System	☒ Secondary Clay Liner
Secondary Clay Liner	☒ Aquitard
Aquitard	☒ Aquifer
Aquifer	

Laplace Transform Parameters

TAU: 7 N: 20 SIG: 0 RNU: 2

Run Parameters

Output Units: Time Units: yr Depth Units: m Concentration Units: µg/L

☐ All Depths ☒ Specified Depths

+ Add - Delete

Depth	Units
0	m

☒ Concentrations at Specified Times ☐ Maximum Concentrations

Concentrations at Specified Times

+ Add - Delete

Time	Units
10	year
20	year
30	year
50	year
100	year

The majority of the data on this tab is the same as that for a Primary Landfill Model and is described in that [section](#)^[132]. The following layers can be included in this model.

Primary Geomembrane: Check this box to include a primary geomembrane in the model. If this box and the secondary geomembrane box are not checked the Geomembranes tab will not be present.

Primary Clay Liner: Check this box to include a primary clay liner in the model. If this box and the Secondary Clay Liner box are not checked the Clay Liners tab will not be present.

Secondary Geomembrane: Check this box to include a secondary geomembrane in the model. If this box and the primary geomembrane box are not checked the Geomembranes tab will not be present.

Secondary Clay Liner: Check this box to include a secondary clay liner in the model. If this box and the Primary Clay Liner box are not checked the Clay Liners tab will not be present.

Aquitard: Check this box to include an aquitard in the model. If this box is not checked the Aquitard tab will not be present.

Aquifer: Check this box to include an aquifer in the model. If this box is not checked the Aquifer tab will not be present.

3.3.3.2 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

The screenshot shows a software interface with a tabbed menu at the top: Run, Auto, On, Off, Save, SaveAs, General, Source & Hydraulic Heads (selected), Collection System, Geomembranes, Clay Liners, Aquitard, Aquifer, Special Features, and Subsurface Model. The 'Source' section contains the following fields:

- Concentration: 1500 $\mu\text{g/L}$
- Landfill Length: 500 m
- Landfill Width: 100 m
- Source Type: ☐ Constant Concentration, ☒ Finite Mass
- Finite Mass section:
 - Waste Thickness: 10 m
 - Infiltration: 0.15 m/a
 - Waste Density: 600 g/cm^3
 - Percent of Mass: 0.1

The 'Hydraulic Heads' section contains the following fields:

- Leachate Head on Primary Liner: 0.3 m
- Leachate Head on Secondary Liner: 0.3 m
- Groundwater level relative to top of Aquifer: 3 m

The source parameters are the same as those for a Primary Landfill Model and are described in that [section](#)¹³³.

Hydraulic Heads


Leachate Head on Primary Liner: The leachate head above the primary liner.

Leachate Head on Secondary Liner: The leachate head above the secondary liner.

Groundwater level relative to top of aquifer: The groundwater level relative to the top of the aquifer, or if no aquifer is present the hydraulic gradient in the liner.

3.3.3.3 Collection System

To edit the collection system data for a model click on the Collection System tab on the left side of the model form.



Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Collection System | Geomembranes | Clay Liners | Aquitard | Aquifer | Special Features | Subsurface Model

Secondary Collection System

Name:



Number of Sublayers:

Thickness:

Density:

Diffusion Coef:

Distribution Coef:

Porosity:

Phase Parameter:

The following parameters can be edited on this tab:

Name: This is the name of the collection system.

Symbol: This is the symbol used to draw the collection system. To change the symbol click on the [Change Symbol](#) button.

Number of Sublayers: This is the number of sublayers to use for the collection system. Typically, a value of 1 is used.

Thickness: This is the thickness of the collection system.

Density: This is the density of the collection system.

Diffusion Coefficient: This is the coefficient of hydrodynamic dispersion for the collection system.

Distribution Coefficient: This is the distribution coefficient for the collection system.

Porosity: This is the porosity of the collection system.

Phase Parameter: This is a dimensionless phase parameter, ' K_H ' or ' S_{gf} ', as discussed in the [Introduction](#). The default is one; this represents no phase change.

3.3.3.4 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard Aquifer Special Features Subsurface Model

Primary Geomembrane

Name: Geomembrane

 Change Symbol

Leakage Method

- ☒ LEAK, Rowe et al 2004
- ☐ Giroud & Bonaparte 1992
- ☐ Equivalent K

Number of Sublayers: 1

Thickness: 60 mil

Diffusion Coef: 3E-5 m²/a

Phase Parameter: 1

LEAK, Rowe et al 2004

Calculation Method

- ☐ LEAK
- ☒ Wrinkles

Transmissivity (THETA): 1E-10 m²/s

Conductivity (KOM): 0.0001 m/s

Wrinkles

Wrinkle Frequency: 10 hectare

Wrinkle Width: 0.3 m

Wrinkle Spacing: 10 m

Wrinkle Length: 100 m

Hole Radius: 0.00564 m

Calculate Leakage Darcy Velocity 0.0015768 m/a

Secondary Geomembrane

Name: Geomembrane

 Change Symbol

Leakage Method

- ☒ LEAK, Rowe et al 2004
- ☐ Giroud & Bonaparte 1992
- ☐ Equivalent K

Number of Sublayers: 10

Thickness: 60 mil

Diffusion Coef: 3E-5 m²/a

Phase Parameter: 0

Equivalent K:

LEAK, Rowe et al 2004

Calculation Method

- ☐ LEAK
- ☒ Wrinkles

Transmissivity (THETA): 1E-10 m²/s

Conductivity (KOM): 0.0001 m/s

Wrinkles

Wrinkle Frequency: 10 hectare

Wrinkle Width: 0.3 m

Wrinkle Spacing: 10 m

Wrinkle Length: 100 m

Hole Radius: 0.00564 m

Calculate Leakage Darcy Velocity 0.0018909 m/a

The top of the form is used to specify the data for the primary geomembrane and the bottom of the form is used to specify the data for the secondary geomembrane. The data entered for each geomembrane is the same as that for a Primary Landfill model and is described in that [section](#)^[134].

3.3.3.5 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

The screenshot shows the 'POLLUTE and MIGRATE' software interface. At the top, there is a toolbar with buttons for 'Run', 'Auto', 'On', 'Off', 'Save', and 'SaveAs'. Below the toolbar is a tabbed menu with the following tabs: 'General', 'Source & Hydraulic Heads', 'Collection System', 'Geomembranes', 'Clay Liners', 'Aquitard', 'Aquifer', 'Special Features', and 'Subsurface Model'. The 'Clay Liners' tab is selected.

The main form is titled 'Primary Clay Liner'. It contains the following fields:

- Name: Clay Liner
- Change Symbol button
- Number of Sublayers: 10
- Thickness: 0.9 m
- Density: 1.9 g/cm³
- Conductivity K: 1E-7 cm/s
- Diffusion Coef: 0.02 m²/a
- Distribution Coef: 0.5 mL/g
- Porosity: 0.35

Below the Primary Clay Liner section is the 'Secondary Clay Liner' section, which has identical fields:

- Name: Clay Liner
- Change Symbol button
- Number of Sublayers: 10
- Thickness: 0.9 m
- Density: 1.9 kg/m³
- Conductivity K: 1E-9 m/s
- Diffusion Coef: 0.02 m²/a
- Distribution Coef: 0.5 m³/kg
- Porosity: 0.35

The top of the form is used to specify the data for the primary clay liner and the bottom of the form is used to specify the data for the secondary clay liner. The data entered for each clay liner is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.3.6 Aquitard

To edit the aquitard data for a model click on the Aquitard tab on the left side of the model form. Note that this layer is an attenuation layer beneath the Clay liner. It is typically a layer with a hydraulic conductivity higher than that required for a clay liner (1×10^{-9} m/s) but less than an aquifer.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners **Aquitard** Aquifer Special Features Subsurface Model

Aquitard

Name: Aquitard

Change Symbol

Number of Sublayers: 10

Thickness: 3 m

Density: 1.9 kg/m³

Conductivity K: 1E-5 m/s

Diffusion Coef: 0.02 m²/a

Distribution Coef: 0.5 m³/kg

Porosity: 0.3

The data entered for the aquitard is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.3.7 Aquifer

To edit the aquifer and outflow data for a model click on the Aquifer tab on the left side of the model form.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard **Aquifer** Special Features Subsurface Model

Aquifer

Name: Aquifer

Change Symbol

Thickness: 3 m

Porosity: 0.3

Outflow

Outflow in Aquifer

The minimum outflow velocity in the Aquifer that will fulfill the conditions of continuity of flow is: 0.12606 m/a


Outflow Velocity: 10 m/a

The data entered for the aquifer is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁹.

3.3.4 Editing a Vertical Migration Model

The Vertical Migration model is used to quickly enter a model for the vertical migration of a contaminant from a waste mass into an aquifer. The model may contain a primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the leakage through the geomembrane is calculated using equations by Rowe et. al., 2004.

If the model was created using the Vertical Migration template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, Aquitard, Aquifer, and Special Features. In addition, there is a tab for the subsurface model.



The data entry for the General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, Aquitard, and Aquifer is described in the sections below. The data entry for the Special Features is the same for all the templates and is described in the [Editing Special Features](#)^[158] section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[174]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[178].

3.3.4.1 General Data

To select the layers in the model and edit the general data click on the General tab on the left side of the model form.

The screenshot shows a software interface with the following sections:

- General Information:**
 - Model Title: [Text Field]
 - Units: ☒ Metric ☐ Imperial
 - Layers (with checkboxes):
 - Waste** (Red)
 - Collection System** (Yellow)
 - Geomembrane** (Grey)
 - Clay Liner** (Orange)
 - Aquitard** (Brown)
 - Aquifer** (Light Yellow)
 - Checkboxes on the right:
 - ☒ Collection System
 - ☒ Geomembrane
 - ☒ Clay Liner
 - ☒ Aquitard
 - ☒ Aquifer
- Laplace Transform Parameters:**
 - TAU: [7] N: [20] SIG: [0] RNU: [2]
- Run Parameters:**
 - Output Units:
 - Time Units: [year]
 - Depth Units: [m]
 - Concentration Units: [mg/L]
 - Options:
 - ☒ All Depths ☐ Specified Depths
 - ☒ Concentrations at Specified Times ☐ Maximum Concentrations
 - Concentrations at Specified Times:
 - + Add - Delete
 - Table:

Time	Units
50	year
100	year
150	year

The majority of the data on this tab is the same as that for a Primary Landfill Model and is described in that [section](#)¹³². The following layers can be included in this model.

Collection System: Check this box if there is a collection system above the geomembrane.

Geomembrane: Check this box to include a primary geomembrane in the model. If this box is not checked the Geomembranes tab will not be present.

Clay Liner: Check this box to include a primary clay liner in the model. If this box is not checked the Clay Liners tab will not be present.

Aquitard: Check this box to include an aquitard in the model. If this box is not checked the Aquitard tab will not be present.

Aquifer: Check this box to include an aquifer in the model. If this box is not checked the Aquifer tab will not be present.

3.3.4.2 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

The screenshot shows the 'POLLUTE and MIGRATE' software interface. The top menu bar includes 'Run', 'Auto', 'On', 'Off', 'Save', and 'SaveAs'. Below the menu is a tabbed interface with the following tabs: 'General', 'Source & Hydraulic Heads', 'Geomembranes', 'Clay Liners', 'Aquitard', 'Aquifer', 'Special Features', and 'Subsurface Model'. The 'Source & Hydraulic Heads' tab is active, showing two sub-sections: 'Source' and 'Hydraulic Heads'.

Source Section:

- Concentration: 1000 mg/L
- Waste Length: 1000 m
- Waste Width: 300 m
- Source Type: ☐ Constant Concentration ☒ Finite Mass
- Finite Mass parameters:
 - Waste Thickness: 10 m
 - Infiltration: 0.15 m/year
 - Waste Density: 600 g/cm³
 - Percent of Mass: 0.1

Hydraulic Heads Section:

- Leachate Head on Primary Liner: 0.3 m
- Groundwater level relative to top of Aquifer: 0 m

The source parameters are the same as those for a Primary Landfill Model and are described in that [section](#) ¹³³.

Hydraulic Heads

Leachate Head on Primary Liner: If there is a collection system this is the leachate head above the primary liner.

Groundwater level relative to top of aquifer: The groundwater level relative to the top of the aquifer, or if no aquifer is present the hydraulic gradient in the liner.

3.3.4.3 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | Aquitard | Aquifer | Special Features | Subsurface Model

Geomembrane

Name: Geomembrane

Change Symbol

Number of Sublayers: 1

Thickness: 60 mil

Diffusion Coef: 3E-5 m²/a

Phase Parameter: 1

LEAK, Rowe et al 2004

Calculation Method

☐ LEAK ☒ Wrinkles

Transmissivity (THETA): 1E-10 m²/s

Conductivity (KOM): 0.0001 m/s

Wrinkles

Wrinkle Frequency: 10 hectare

Wrinkle Width: 0.3 m

Wrinkle Spacing: 10 m

Wrinkle Length: 100 m

Hole Radius: 0.00564 m

Calculate Leakage Darcy Velocity

The data entered for the geomembrane is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁴.

3.3.4.4 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | Aquitard | Aquifer | Special Features | Subsurface Model

Clay Liner

Name: Clay Liner

Change Symbol

Number of Sublayers: 10

Thickness: 1 m

Density: 1.9 g/cm³

Conductivity K: 1E-9 m/s

Diffusion Coef: 0.02 m²/a


Distribution Coef: 0 mL/g

Porosity: 0.3

The data entered for the clay liner is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.4.5 Aquitard

To edit the aquitard data for a model click on the Aquitard tab on the left side of the model form. Note that this layer is an attenuation layer beneath the Clay liner. It is typically a layer with a hydraulic conductivity higher than that required for a clay liner (1×10^{-9} m/s) but less than an aquifer.



Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | **Aquitard** | Aquifer | Special Features | Subsurface Model

Aquitard

Name: Aquitard

 Change Symbol

Number of Sublayers: 10

Thickness: 1 m

Density: 1.9 g/cm³

Conductivity K: 1E-7 m/s

Diffusion Coef: 0.02 m²/a


Distribution Coef: 0 mL/g

Porosity: 0.3

The data entered for the aquitard is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.4.6 Aquifer

To edit the aquifer and outflow data for a model click on the Aquifer tab on the left side of the model form.



Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | Aquitard | **Aquifer** | Special Features | Subsurface Model

Aquifer

Name: Aquifer

 Change Symbol

Thickness: 1 m

Porosity: 0.3

Outflow

Outflow in Aquifer

The minimum outflow velocity in the Aquifer that will fulfill the conditions of continuity of flow is: 2.7496 m/a

Outflow Velocity: 150 m/a

Calculated Results

Darcy Velocity: 0.0027496 m/a


Leachate Head on Primary Liner: 0.3 m

The data entered for the aquifer is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁹.

3.3.5 Editing a Horizontal Migration Model


The Horizontal Migration model is used to model horizontal migration of a contaminant from a waste mass to the site boundary. The model may contain a primary composite liner and an aquitard. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the leakage through the geomembrane is calculated using equations by Rowe et. al., 2004.

In this model the attenuation layer is modeled as a passive sink, where there is downward flow due to infiltration from precipitation and horizontal flow due to a difference in heads between the waste and the attenuation layer. The infiltration will have the effect of removing contaminant by acting as a passive sink with inflow. To avoid this effect set the infiltration into the attenuation layer to zero. Unless you really understand what you are doing, it is recommended that you set the infiltration to zero.



At the site boundary, the attenuation layer is assumed to continue indefinitely and is modelled as an Infinite Thickness boundary. If a geomembrane is present the horizontal flow is calculated using the leakage through the geomembrane calculated using the equations by Rowe et. al., 2004. And if the geomembrane is not present the horizontal flow is calculated using the average gradient (using the head in the waste and the head in the attenuation layer) and the harmonic mean hydraulic conductivity between the head measurements.

If the model was created using the Horizontal Migration template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, and Special Features. In addition, there is a tab for the subsurface model.



The data entry for the General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, and Aquitard is described in the sections below. The data entry for the Special Features is the same for all the templates and is described in the [Editing Special Features](#)^[158] section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[174]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[178].

3.3.5.1 General Data

To select the layers in the model and edit the general data click on the General tab on the left side of the model form.

General Information

Model Title:

Units: ☒ Metric ☐ Imperial

Waste GM Liner Aquitard

☒ Geomembrane
☒ Clay Liner

Laplace Transform Parameters

TAU: N: SIG: RNU:

Run Parameters

Output Units: Time Units: Depth Units: Concentration Units:

☒ All Depths ☐ Specified Depths

☒ Concentrations at Specified Times ☐ Maximum Concentrations

Concentrations at Specified Times

+ Add X Delete

Time	Units
50	year
100	year
150	year

The majority of the data on this tab is the same as that for a Primary Landfill Model and is described in that [section](#)¹³². The following layers can be included in this model.

Geomembrane: Check this box to include a primary geomembrane in the model. If this box is not checked the Geomembranes tab will not be present.

Clay Liner: Check this box to include a primary clay liner in the model. If this box is not checked the Clay Liners tab will not be present.

An aquitard layer is always present in this model.

3.3.5.2 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

The screenshot shows the 'POLLUTE and MIGRATE' software interface. The 'General' tab is active, with a yellow tooltip that says 'Close the current document (Ctrl+W)'. The 'Source' tab is selected, showing the following parameters:

- Concentration: 1000 mg/L
- Waste Length: 1000 m
- Waste Width: 100 m
- Source Type: ☒ Finite Mass
- Finite Mass parameters:
 - Waste Thickness: 10 m
 - Infiltration: 0.15 m/year
 - Waste Density: 600 g/cm³
 - Percent of Mass: 0.1

The 'Hydraulic Heads' tab is also visible, showing the following parameters:

- Infiltration in to Attenuation Layer: 2.7496 m/a
- Head in the Waste: 0.3 m
- Head in the Aquitard: 0 m
- Distance between Head Measurements: 1 m

The source parameters are the same as those for a Primary Landfill Model and are described in that [section](#) ¹³³.

Hydraulic Heads

Infiltration in to Attenuation Layer: This is the downward infiltration due to precipitation in the attenuation layer (aquitard). The infiltration will have the effect of removing contaminant by acting as a passive sink with inflow. To avoid this effect set the infiltration into the attenuation layer to zero.

Head in the Waste: This is the head in the waste, relative to the same datum (depth) as the head in the attenuation layer (aquitard).

Head in the Aquitard: This is the head in the aquitard (attenuation layer) at a location outside of the barrier (liner system).

Distance between Head Measurements: This is the horizontal distance between the two head measurements above.

3.3.5.3 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Geomembranes Clay Liners Aquitard Special Features Subsurface Model

Geomembrane

Name: Geomembrane

Change Symbol

Number of Sublayers: 1

Thickness: 60 mil

Diffusion Coef: 3E-5 m²/a

Phase Parameter: 1

LEAK, Rowe et al 2004

Calculation Method

☐ LEAK ☒ Wrinkles

Transmissivity (THETA): 1E-10 m²/s

Conductivity (KOM): 0.0001 m/s

Wrinkles

Wrinkle Frequency: 10 hectare

Wrinkle Width: 0.3 m

Wrinkle Spacing: 10 m

Wrinkle Length: 100 m

Hole Radius: 0.00564 m

Calculate Leakage Darcy Velocity

The data entered for the geomembrane is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁴.

3.3.5.4 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

Run Auto On Off Save SaveAs

General Source & Hydraulic Heads Geomembranes Clay Liners Aquitard Special Features Subsurface Model

Clay Liner

Name: Clay Liner

Change Symbol

Number of Sublayers: 10

Width: 1 m

Density: 1.9 g/cm³

Conductivity K: 1E-9 m/s

Diffusion Coef: 0.02 m²/a

Distribution Coef: 0 mL/g


Porosity: 0.3

Press to run the model

The data entered for the clay liner is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.5.5 Aquitard

To edit the aquitard data for a model click on the Aquitard tab on the left side of the model form. Note that this layer is an attenuation layer beneath the Clay liner. It is typically a layer with a hydraulic conductivity higher than that required for a clay liner (1×10^{-9} m/s) but less than an aquifer.



Run Auto On Off Save SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | **Aquitard** | Special Features | Subsurface Model

Aquitard

Name:



Number of Sublayers:

Width:

Density:

Conductivity K:

Diffusion Coef:

Distribution Coef:

Porosity:

The data entered for the aquitard is the same as that for a Primary Landfill model and is described in that [section](#)¹³⁸.

3.3.6 Editing Special Features

There are several special features that can be added to a model; such as:

- Initial Concentration Profile,
- Maximum Thickness,
- Non-linear Sorption,
- Passive Sink,
- Print Mass into Base,
- Radioactive/Biological Decay,
- Variable Properties,
- Monte Carlo Simulation,
- Sensitivity Analysis.

These features are described in the sections below.

3.3.6.1 Initial Concentration Profile

This option allows you to input an initial concentration profile at specified depths and also the initial flux into and out of the deposit. A situation where this may be appropriate, is if there is an initial background concentration in a sample, and one is modeling outward diffusion from the sample in a laboratory experiment (eg. see Barone et. al. 1990).

Note: If any of the layers have fractures, this option cannot be used.

Warning: If using this option it is a good idea to specify a thin layer between zones where there are significant differences between initial concentration (eg. between the soil and a top or bottom reservoir in a diffusion test).

To add this feature check the Initial Concentration Profile box on the Special Features tab. The Initial Concentration form will be shown on the right side of the tab.

Initial Concentration Profile

Start Time: 0 yr

Flux into Soil: 0 m²/a

Flux into Base: 0 m²/a

Mass at Start Time

Mass into Base: 0 kg

Mass out of Base: 0 kg

Interval Type: ☒ Depth Intervals ☐ Sublayers

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Concentration	Concentration Units
0	cm	4.5	cm	10	mg/L

The following can be specified:

Start Time: This is the time for the start of the initial concentration profile, it is usually zero.

Flux into Soil: This is the flux of contaminant into the soil at the top boundary up to the start time (usually zero for a start time of zero).

Flux into Base: This is the flux of contaminant out of the soil into the base up to the start time (usually zero for a start time of zero).

Interval Type: The initial concentration profile can be specified over depth intervals or for every sublayer. For example, if there were only two different zones with different initial concentrations, then it would be best to specify the profile over these depth intervals. However, if the deposit had a continuously changing initial concentration profile with depth, then it would be better to specify the concentration for each sublayer (the number of sublayers is specified in the entry of the layer data).

In addition if the Print Mass into the Base special feature is selected, the user will be asked for:

Mass into the Soil: This is the mass of contaminant into the soil at the top boundary up to the start time (usually zero for a start time of zero).

Mass into the Base: This is the mass of contaminant out of the soil into the base up to the start time (usually zero for a start time of zero).

Depth Intervals

If the interval type is Depth Intervals then the depth interval and concentrations are specified in the table. At the top of the table there are buttons to add and delete a depth interval.


Sublayers

If the interval type is Sublayers then the table will be populated with the depth intervals for the sublayers and only the concentration for each depth interval needs to be entered.

3.3.6.2 Maximum Sublayer Thickness

This option allows the user to override the default maximum sublayer thickness of 5 units. The maximum sublayer thickness is set at 5 to avoid possible exponential overflow in the program, which can occur sometimes if the sublayers are too large. If the maximum sublayer thickness is not changed then the number of sublayers is automatically increased if required to keep their thickness to less than 5. For example, if the layer thickness was 50m with 5 sublayers (giving a sublayer thickness of 10), the program will automatically adjust the number of sublayers to 10.

To select this option check the Maximum Sublayer Thickness box on the Special Features tab.



The following can be specified:

Maximum Sublayer Thickness: This is the maximum sublayer thickness in the same depth units as specified on the General tab.

WARNING: When overriding this maximum sublayer thickness the user takes the risk that the program could crash or give false results.

3.3.6.3 Non-linear Sorption

In addition to linear sorption, there are two types of non-linear sorption can be modeled. These are Freundlich or Langmuir, the theory for these types is described in the [Introduction](#)¹⁹.

To add this feature check the Non-linear Sorption box on the Special Features tab. The Non-linear Sorption form will be shown on the right side of the tab.

Click to run the model

☐ Initial Concentration Profile

☐ Maximum Sublayer Thickness

☒ Non-linear Sorption

☐ Passive Sink

☐ Print Mass in Base

☐ Radioactive/Biological Decay

☐ Time Varying Properties

☐ Monte Carlo Simulation

☐ Sensitivity Analysis

Non-linear Sorption

Type of Sorption

☐ None

☒ Freundlich

☐ Langmuir

Maximum Number of Iterations: 10

Minimum Reference Concentration: 0.1 mg/L

Top Depth	Bottom Depth	Depth Units	Coefficient Kf	Kf Units	Exponent E
0	7	cm	2	cm³/g	0.628

The following can be specified:

Sorption Type: This can be either None, Freundlich, or Langmuir. The layer data will depend on the type of sorption selected.

Maximum Number of Iterations: The iterative procedure used to determine K, repeats until either the maximum change in concentration between iterations is less than 0.1% or the maximum number of iterations is reached.

Minimum Reference Concentration: This is the minimum value that will be used when calculating the secant (linear) distribution coefficient, K. If the average concentration in the sublayer is less than this value, then the Reference value is used.

Freundlich Non-linear Sorption

The following can be entered for each layer specified on the Layers tab.

Coefficient Kf: This is an empirically determined parameter for the layer.

Exponent E: This is an empirically determined parameter for the layer

Langmuir Non-linear Sorption

The following can be entered for each layer specified on the Layers tab.

Parameter Sm: This is an empirically determined parameter for the layer.

Parameter b: This is an empirically determined parameter for the layer.

3.3.6.4 Passive Sink

This special feature allows you to incorporate one or more passive sinks or a phase change with depth into a model. A passive sink is a depth interval in which there is a horizontal velocity which will have the effect of removing contaminant from beneath the landfill. Typically, a passive sink is used to represent intermediate aquifers or secondary leachate collection systems [Rowe and Fraser, 1993].

In the Passive Sink feature the model is divided into a number of depth intervals, and in each interval the user can specify the Darcy velocity, rate of removal, rate of inflow, and phase parameter. The set of depth intervals should cover the entire thickness of the model, between the top and bottom boundary. If a fixed outflow bottom boundary is used, the depth interval should stop at the top of the base aquifer (i.e., it should not include the base aquifer).

Note: When using both the Time Varying Properties option and the Passive Sink option, the passive sink information is specified in the [Time Varying Properties](#) ⁽¹⁶⁵⁾ special feature.

WARNING: This option should only be used by someone with the hydrogeologic and engineering background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of the physical situation.

THIS OPTION SHOULD NOT BE USED FOR AN IMPORTANT PROJECT WITHOUT THE GUIDANCE OF THE PROGRAM DEVELOPERS.

To add this feature check the Passive Sink box on the Special Features tab. The Passive Sink form will be shown on the right side of the tab.

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Darcy Velocity	Darcy Velocity Units	Rate of Removal	Rate of Removal Units	Phase Parameter
0	m	0.6	m	0.003	m/a	0	m/a	1
0.6	m	0.8	m	0.003	m/a	0	m/a	0.1
0.8	m	0.9	m	0.003	m/a	15	m/a	1
0.9	m	1.65	m	0	m/a	0	m/a	1

The following can be specified:

Inflow Rate: This option is used to specify the inflow rate with depth.

Phase Change: This option is used to incorporate a phase change with depth.

Landfill Length: If the is a normal model type and the bottom boundary is not fixed outflow, the landfill length needs to be specified when using a passive sink. This is the landfill length in the direction of groundwater flow.

Landfill Width: If the is a normal model type and the bottom boundary is not fixed outflow, the landfill width needs to be specified when using a passive sink.

Interval Type: The depth intervals can either be specified or the layer depth intervals on the Layers Tab can be used. If the depth intervals are being specified there are buttons at the top of the table to add and delete depth intervals.

For each depth interval the following is specified:

Top Depth: This is the top depth of the depth interval. If the Interval Type is Layers, this is filled in by the program. The set of depth intervals should cover the entire thickness of the model.

Bottom Depth: This is the bottom depth of the depth interval. If the Interval Type is Layers, this is filled in by the program.

Darcy Velocity: This is the Darcy Velocity for the depth interval. A negative value indicates an upward flow or flow in towards the source.

Rate of Removal: This is the rate of removal of contaminant by the passive sink. According to the principle of continuity of flow the rate of removal should be equal to:

$$R_r = (v_{a1} - v_{a2}) L / h$$

where,

R_r = Rate of removal or outflow velocity (flow per unit area per unit time),

v_{a1} = Darcy velocity above the interval,

v_{a2} = Darcy velocity below the interval,

L = Landfill length,

h = thickness of the layer from which fluid is being removed.

An example would be a 600 m (L) long landfill with a 0.3 m thick (h) secondary leachate collection system. The Darcy velocity above the secondary leachate collection system is 0.01 m/a (v_{a1}), and below is 0.003 m/a (v_{a2}). The rate of removal is then:

$$R_r = (0.01 - 0.003) * 600 / 0.3 = 14 \text{ m}^3/\text{a}/\text{m}^2 = 14 \text{ m/a}$$

Rate of Inflow: If the Inflow Rate option has been selected on the previous tab, the Rate of Inflow field will be shown. This is the rate of inflow into the passive sink.

Phase Parameter: If the Phase Change option has been selected on the previous tab, the Phase Parameter field will be shown. This is a dimensionless phase parameter as discussed in the [Introduction](#) ²¹.

3.3.6.5 Print Mass in Base

This option will print the total mass into the soil and the base, it is not normally used. To use this option check the Print Mass into Base box on the Special Features tab.

3.3.6.6 Radioactive/Biological Decay

To add this feature check the Radioactive/Biological Decay box on the Special Features tab. The Radioactive/Biological Decay form will be shown on the right side of the tab.

The screenshot shows the 'Radioactive/Biological Decay' tab in the software. On the left, a list of options includes 'Initial Concentration Profile', 'Maximum Sublayer Thickness' (checked), 'Non-linear Sorption', 'Passive Sink', 'Print Mass in Base', 'Radioactive/Biological Decay' (checked), 'Time Varying Properties', 'Monte Carlo Simulation', and 'Sensitivity Analysis'. The main area of the tab contains settings for 'Source Decay' and 'Base Decay', both set to 'Yes' with a half-life of 100 years. Below these is the 'Interval Type' section, set to 'Depth Intervals'. A table of 'Depth Intervals' is shown with one entry: Top Depth 0, Top Depth Units m, Bottom Depth 50, Bottom Depth Units m, Half-Life 100, Half-Life Units yr.

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Half-Life	Half-Life Units
0	m	50	m	100	yr

The following can be specified:

Source Decay: This allows the user to select whether first order decay of contaminant will be modelled in the source. If selected the user will be asked to specify the half-life in the source. If not selected the half-life in the source is assumed to be infinite (i.e., no first order decay).

Base Decay: This allows the user to select whether first order decay will be modelled in the base of the deposit (eg. an underlying aquifer). If selected the user will be asked to specify the half-life in the base. If not selected the half-life in the base is assumed to be infinite (i.e., no first order decay).

Interval Type: The depth intervals can either be specified or the layer depth intervals on the Layers Tab can be used.

For each depth interval the following is specified:

Top Depth: This is the top depth of the depth interval. If the Interval Type is Layers, this is filled in by the program. The set of depth intervals should cover the entire thickness of the model.

Bottom Depth: This is the bottom depth of the depth interval. If the Interval Type is Layers, this is filled in by the program.

Half-Life: This is the half-life for the depth interval.

3.3.6.7 Time Varying Properties

The program is normally capable of determining the concentrations any time without determining them at previous times. However, if there is a complex source concentration history or a change in velocities or layer properties with time then it is necessary to sequentially follow this history. For example, the program can model a working landfill which experiences progressive failure of the leachate collection system and resulting buildup in the leachate mound (i.e., an increase in Darcy velocity) over a period of years [Rowe and Fraser, 1993a, 1993b].

This option allows the user to vary the source concentration, reference height of leachate, volume of leachate collected, rate of concentration increase, Darcy velocity, outflow velocity, dispersivity, layer properties, and decay rate with time. The Variable Properties option implements a “time-marching” scheme, where the program stops and restarts the solution every time parameters are changed. In the basic mode of operation the accuracy of the solution is independent of the number of sublayers. However, if the Variable Properties option is used then the accuracy of this procedure depends on the number of sublayers used in the model, and the user should experiment with the number of sublayers to ensure that the results obtained are sufficiently accurate (see Examples 10, 11, and 15).

WARNING: This option should only be used by someone with the hydrogeologic and engineering background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of the physical situation.

THIS OPTION SHOULD NOT BE USED FOR A PROJECT OF IMPORTANCE WITHOUT THE GUIDANCE OF THE PROGRAM DEVELOPERS.

To add this feature check the Time Varying Properties box on the Special Features tab. Time Varying Properties form will be shown on the right side of the tab.

General | Layers | Boundaries | Special Features | Subsurface Model

☐ Initial Concentration Profile
☐ Maximum Sublayer Thickness
☐ Non-linear Sorption
☒ Passive Sink
☐ Print Mass in Base
☐ Radioactive/Biological Decay
☒ Time Varying Properties
☐ Monte Carlo Simulation
☐ Sensitivity Analysis

Time Varying Properties

☒ Properties Increment within Periods ☒ Passive Sink
☒ Variable Layer Properties ☒ Phase Change
☒ Variable Decay ☒ Inflow

Warning: In the Variable Properties option the accuracy of the calculations will depend on the number of sublayers.

+ Add X Delete | First Prev Next Last

Property	Value	Units	Increment
Number of	1		
Start Time:	0	year	
End Time:	10	year	
Source	1	mg/L	0
Darcy Velocity:	.05	m/a	0
Dispersivity:	0	m	
Base Velocity:	2	m/a	0
Rate for Conc.:	0	mg/L/yr	
Volume Collected:	.3	m/a	0
Finite Mass			

Property	Value	Units
Waste Thickness:	12	m
Waste Density:	0	g/cm ³
Proportion of Mass:	0	
Water Content:	0	
Conv. Rate Half-Life:	0	year

Increment: 1 | First Prev Next Last

☒ Source Decay Half-Life: 1000 year ☒ Base Decay Half-Life: 1000 year

Interval Type ☒ Depth Intervals ☐ Layers

+ Add X Delete

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Darcy Velocity	Darcy Velocity Units	Rate of Removal	Rate of Removal Units	Rate of Inflow	Rate of Inflow Units	Phase Parameter	Diffusion Coefficient	Diffusion Coefficient Units	Porosity	Density	Density Units	Distribution Coefficient	Distribution Coefficient Units	Half Life	Half Life Units
0	m	1	m	0.01	m/a	0	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year
1	m	1.3	m	0.01	m/a	6.67	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year
1.3	m	3.3	m	0	m/a	0	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year

The following options can be selected at the top of this form:

Properties Increment within Periods: This allows the user to choose whether the properties increment within time periods or are constant within time groups. If the properties increment within time periods, the user can specify the number of increments and the increment size for each time period. For example, if the Darcy velocity increased linearly from .01 m/a to .11 m/a between 10 and 20 years, the user could specify 10 increments and a Darcy velocity increment of .01. If however, the properties remain constant between time periods the user need only specify the values of the properties. For example, if the Darcy velocity was .01 m/a between 0 and 10 years and then .02 m/a between 11 and 30 years, the user could specify two groups the first from 0 to 10 years with a Darcy velocity of .01 m/a and the second from 11 to 30 years with a Darcy velocity of .02 m/a.

Variable Layer Properties: This option can be used to vary both source and layer properties with time. The model is divided into a number of depth intervals and in each interval the user can specify the Diffusion Coefficient (or Coefficient of Hydrodynamic Dispersion), Porosity, Density, and Distribution Coefficient. If this option is selected the Layer Data table will be displayed as described below.

Variable Decay: This option is used to vary the radioactive or biological decay with time. The source, base, and depth interval decay rates can be varied. If this option is selected the Layer Data table will be displayed as described below.

Passive Sink: Check this box if the model contains a passive sink as well as time varying properties. The Darcy Velocity and Rate of Removal can be specified for each depth interval in the Layer Data table as described below.

Note: When using both the Variable Properties option and the Passive Sink option, the Darcy velocity used is the product of the Darcy velocity specified in both of the options. For clarity, it is generally recommended the user specify the Darcy velocity on the Time Period Data table as 1, and vary the Passive Sink Darcy velocity with time.

Phase Change: This option is used to incorporate a phase change parameter for each depth interval in the Layer Data table as described below.

Inflow Rate: This option is used to specify the Rate of Inflow for each depth interval in the Layer Data table as described below.

Time Period Data

This table is used to specify the data for each time period. At the top of the table there are buttons to add and delete a time group; as well as to navigate between time periods.

The following can be specified for each time period:

Number of Increments: If the Properties Increment within Periods this is the number of increments to use in sub-dividing the time period. The concentrations will be calculated for the times at the end of each increment, if there is only one increment specified for the time period will be calculated at the end time. For example, if the time period started at 0 years and ended at 20 years and the number of increments was 4, concentrations would be calculated at 5, 10, 15, and 20 years.

Start Time: This is the start time of the first time period, and is the time at which calculations begin (usually zero). The start time is only specified for the first time period.

End Time: This is the end time of the time period, and will be the start time of the next time period.

Source Concentration: This is the source concentration at the beginning of the time period. The calculated concentration from the end of the last period will be used if the user specifies a negative value for the source concentration. For the first time period the source concentration does not decrease until the end of the time period. To model a landfill with a depleting source, the concentration should be set for the first time period and then -1 should be used for the following time periods.

Note: The actual source concentration will vary with time due to the migration of contaminant into the soil and the collection of leachate. This is automatically handled by the program.

Source Concentration Increment: This is the increment size by which to increase the source concentration for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected. If no additional mass is being added to the source then this should be zero.

Darcy Velocity: This is the Darcy velocity at the beginning of this time period. If an increment in Darcy velocity is specified, it will be added to this velocity to get the velocity at the start of the next increment.

Note: When using both the Variable Properties option and the Passive Sink option together, the Darcy velocity used is the product of the Darcy velocity specified in both of the options. For clarity, it is recommended the user specify the Darcy velocity on the Variable Properties option as 1, and vary the Passive Sink Darcy velocity.

Darcy Velocity Increment: This is the increment size by which to increase the Darcy velocity for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected.

Dispersivity: This is the dispersivity for the model. When the Variable Properties option is used the dispersivity (α) and diffusion coefficient (D_{md}) can be specified independently.

Base Velocity: If the bottom boundary condition is fixed outflow, the user can specify the base horizontal Darcy velocity at the down-gradient edge of the landfill for the beginning of the time period.

Base Velocity Increment: This is the increment size by which to increase the base velocity for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected.

Rate for Conc. If the top boundary condition is finite mass, the user can specify the rate at which the source concentration changes per year. For the case where there is no additional mass added or removed from the landfill this value should be set at zero.

Volume Collected: When the top boundary condition is finite mass, the user needs to specify the Volume of Leachate Collected for the beginning of the time period.

Volume Collected Increment: This is the increment by which to increase the volume of leachate collected during each time increment. If the infiltration through the cover of the landfill is constant, the increment in the volume of leachate collected should be equal and of opposite sign to the increment in the Darcy velocity. This field will only be shown if the Properties Increment within Periods option has been selected.

Finite Mass Specification: If the top boundary condition is finite mass, the user can specify either the Waste Properties or the Reference Height of Leachate.

Thickness of Waste: This is the vertical thickness of the waste for the time period, and is used to calculate the mass of contaminant per unit area of waste.

Waste Density: This is the apparent density of the waste for the time period (i.e. mass of waste per unit volume of the landfill).

Proportion of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste for the time period (eg. mass of chloride in waste/total mass of waste).

Water Content: This is the volumetric water content of the waste for the time period.

Conversion Rate Half-Life: The generation coefficient is calculated based on the conversion rate half-life K , such that $\lambda = \ln 2 / K$. A value of $\lambda = 0$ implies no generation of concentration with time. In the program $\lambda = 0$ is obtained by specifying $K = 0$ (this is the default case).

Reference Height of Leachate: The reference height of leachate represents the volume of leachate that would contain the total leachable mass of the contaminant of interest at the initial source concentration. Thus, the reference height (H_r) is equal to the mass of contaminant (M) per unit area divided by the initial source concentration (c_o) (i.e. $H_r = M/c_o$).

Layer Data

If the Variable Layer Properties, Variable Decay, or Passive Sink options are selected the layer data for each time period and increment should be specified in the Layer Data table. This table shows the layer data for the currently selected time period and increment. If the Properties Increment within Periods option is selected, the Increment within the time period can be changed using the buttons at the top of the table.

If the Variable Decay option is selected the following can be specified for each time period and increment.

Source Decay: This allows the user to select whether first order decay of contaminant will be modelled in the source for this time period. If selected the user will be asked to specify the half-life in the source. If not selected the half-life in the source is assumed to be infinite (i.e., no first order decay).

Base Decay: This allows the user to select whether first order decay will be modelled in the base of the deposit for this time period (eg. an underlying aquifer). If selected the user will be asked to specify the half-life in the base. If not selected the half-life in the base is assumed to be infinite (i.e., no first order decay).

Interval Type: The layer data for each time period and increment should cover the full depth of the model. The depth intervals can either be specified or the layer depth intervals on the Layers Tab can be used. If the depth intervals are being specified there are buttons at the top of the table to add and delete depth intervals.

Depending on the options selected the following can be specified:

Top Depth: This is the top depth of the depth interval for this time period and increment. The set of depth intervals should cover the entire thickness of the model.

Bottom Depth: This is the bottom depth of the depth interval.

Darcy Velocity: If the Passive Sink option is selected, this is the Darcy Velocity for the depth interval. A negative value indicates an upward flow or flow in towards the source. Note: When using both the Variable Properties option and the Passive Sink option, the Darcy velocity used is the product of the Darcy velocity specified in both of the options. For clarity, it is recommended the user specify the Darcy velocity on the Time Period as 1, and vary it here.

Rate of Removal: If the Passive Sink option is selected, this is the rate of removal of contaminant by the passive sink. According to the principle of continuity of flow the rate of removal should be equal to:

$$R_r = (v_{a1} - v_{a2}) L / h$$

where,

R_r = Rate of removal or outflow velocity (flow per unit area per unit time),

v_{a1} = Darcy velocity above the interval,

v_{a2} = Darcy velocity below the interval,

L = Landfill length,

h = thickness of the layer from which fluid is being removed.

An example would be a 600 m (L) long landfill with a 0.3 m thick (h) secondary leachate collection system. The Darcy velocity above the secondary leachate collection system is 0.01 m/a (v_{a1}), and below is 0.003 m/a (v_{a2}). The rate of removal is then:

$$R_r = (0.01 - 0.003) * 600 / 0.3 = 14 \text{ m}^3/\text{a}/\text{m}^2 = 14 \text{ m/a}$$

Rate of Inflow: If the Inflow Rate option has been selected on the previous tab, the Rate of Inflow field will be shown. This is the rate of inflow into the passive sink.

Phase Parameter: If the Phase Change option has been selected on the previous tab, the Phase Parameter field will be shown. This is a dimensionless phase parameter as discussed in the [Introduction](#)^[21].

Diffusion Coefficient: If the Variable Layer Properties is selected, this is the diffusion coefficient for the depth interval.

Porosity: If the Variable Layer Properties is selected, this is the porosity for the depth interval. It must be greater than 0 and less than or equal to 1. If the interval is being used to represent a geomembrane the porosity should be set to 1.

Density: If the Variable Layer Properties is selected, this dry density of the depth interval and time period.

Distribution Coefficient: If the Variable Layer Properties is selected, this is the distribution coefficient for the depth interval and time period. In the basic mode (ie. where Langmuir Non-linear sorption and Freundlich Non-linear sorption have not been selected) the sorption-desorption of a conservative species of contaminant is assumed to be linear.

Half-Life: If the Variable Decay option is selected, this is the half-life for the depth interval.


3.3.6.8 Monte Carlo Simulation

In the description of a soil deposit and a contaminant source (eg. a landfill) the values of all the input data are not always known with certainty. For example, the length of time that the primary leachate collection system will function before becoming clogged [Rowe and Fraser, 1993a, 1993b]. However, if the probability distribution can be estimated for the variable then Monte Carlo simulation can be used to predict the expected contaminant concentrations.

This feature supports the use of Monte Carlo simulation, to evaluate the effects of uncertainty in the values of some of the input data. The input data are described using probability distributions, from which data values are randomly chosen for each simulation pass. Numerous simulations are performed, and the results describe the probability distribution of the function being simulated, in this program the probability distribution is that of the peak concentration at various depths. Once the distributions of peak concentrations are determined, the user can make statistical predictions of the peak concentration; such as, the probability of the peak concentration exceeding a specific value.

Monte Carlo simulation can not be used at the same time as a Sensitivity Analysis. This is a computationally intensive feature, and the user should be aware that it may take anywhere from a few minutes to hours to complete with computation time depending on the speed of the computer, the number of simulations to be performed, the number of layers, and the Talbot integration parameter 'N'. For this reason the [Auto Run](#)^[177] option can not be used with this feature.

To add this feature check the Monte Carlo Simulation box on the Special Features tab. The Monte Carlo Simulation form will be shown on the right side of the tab.



The following can be specified:

Number of Simulations: This is the number of simulation analyses (realizations) to make, during each simulation the probability distributions of each variable are randomly sampled and the concentrations calculated. To obtain sufficiently reliable results at least 500 simulations are recommended, and for some cases between 1000 to 10000 simulations (realizations) may be required. The user should experiment with this parameter to determine the sensitivity of the results to the number of simulations.

Number of Data Ranges: This is the number of data ranges to divide the probability distributions into in the output of the results of the simulation. A maximum of 20 ranges may be specified. This parameter does not affect the accuracy of the results and is for display purposes only.

List All Results: By selecting this option, the user can obtain a list of all the simulation results. Listing all the results will include the results of every simulation pass in the output, the output file that is obtained may be extremely large. This option can be used to list all the results for a limited number of simulations (e.g. 10), to obtain a better idea of how the program is functioning, prior to running it for all the simulations.

Variables

Each variable represents one data item in the input data to be modified in the Monte Carlo simulation and is specified in the variable table. At the top of the table there are buttons to add and delete a variable. For each variable the following is specified:

Distribution Type: A distribution must be entered for each variable, the distribution types can be different for different variables. There are five types of probability distributions that can be entered:

Uniform Distribution: This is used to specify a uniform probability distribution, in which there is the equal probability that a data point has any value between a specified minimum and maximum. The probability distribution curve would be a horizontal straight line. The user will need to specify the Minimum and Maximum data values in the Parameters to the right of the table.

Triangular Distribution: This is used to specify a triangular probability distribution function, where the probability is a maximum for a given value (mode) then linearly drops off on each side of this value. The probability distribution curve would be a triangle. The user will need to specify the Minimum, Mode, and Maximum data values in the Parameters to the right of the table.

General Distribution: This is used to specify a set of data and probability pairs that will be linearly interpolated. The probability distribution curve would be a continuous function, which is approximated by a set of straight line segments. The set of values must cover the entire data range, and the probability values do not have to sum to 1. The data and probability pairs can be entered in the Parameters to the right of the table.

Normal Distribution: This is used to specify a normal distribution for the variable. The distribution is symmetrical in shape similar to a bell, and is sometimes called a Gaussian distribution. To define the distribution the user needs to specify the Mean and Standard Deviation in the Parameters to the right of the table.

Lognormal Distribution: A lognormal distribution can be specified for the variable with this option. This distribution is similar to the normal distribution except that it is based on the logarithm of the random variable (eg. Darcy velocity or layer thickness). The user will need to specify the Mean of the log of the variable and the Standard Deviation of the log of the variable in the Parameters to the right of the table.

Variable Type: This is the type of data for which the user wishes to enter a probability distribution. There are 6 types of data that can be used:

Initial Source Concentration: This is the Initial Source Concentration of the top boundary, and can only be used if the top boundary condition is NOT zero flux.

Darcy Velocity: This is the Darcy Velocity of the model.

Layer Thickness: This allows the user to specify a distribution for the thickness of a layer. The user will be asked to specify the layer for which to vary the thickness.

Diffusion Coefficient: This is the Diffusion Coefficient of a layer, the user will be asked to specify the layer for which to vary the Diffusion Coefficient.

Distribution Coefficient: This is the Distribution Coefficient of a layer, the user will be asked to specify the layer for which to vary the Distribution Coefficient. If the layer selected is fractured the distribution coefficient along the fracture will be varied.

Variable Properties End Time: This is the End Time of a Variable Properties Time Group, the user will be asked to specify the Time Group for which to vary End Time. When varying the end time of a time group the program will shift the end times of subsequent time groups to maintain their relative position, and will try to keep the end times of any previous time groups the same. This variable type will not show up if the Variable Properties feature has not been previously selected.

Variable Value: If the variable type is Layer Thickness, Diffusion Coefficient, or Distribution Coefficient this is the layer to use for the variable. If the variable type is Variable Properties End Time this is the end time of the time period to vary.

3.3.6.9 Sensitivity Analysis

In the description of a soil deposit and a contaminant source (eg. a landfill) the values of all the input data are not always known with certainty. For example, the length of time that the primary leachate collection system will function before becoming clogged [Rowe and Fraser, 1993a, 1993b]. However, if the minimum and maximum values (Uniform Distribution) of the parameter can be estimated then Sensitivity Analysis can be used to predict the expected range of contaminant concentrations.

This feature is very similar to Monte Carlo simulation; except, that when performing a Sensitivity Analysis only one variable may be evaluated at a time. Monte Carlo simulation can not be used at the same time as a Sensitivity Analysis. This is a computationally intensive feature, and the user should be aware that it may take anywhere from a few minutes to hours to complete with computation time depending on the speed of the computer, the number of simulations to be performed, the number of layers, and the Talbot integration parameter 'N'. For this reason the [Auto Run](#)^[177] option can not be used with this feature.

To add this feature check the Sensitivity Analysis box on the Special Features tab. The Sensitivity Analysis form will be shown on the right side of the tab.

The following can be specified:

Number of Simulations: This is the number of simulation analyses (realizations) to make, during each simulation the probability distributions of each variable are randomly sampled and the concentrations calculated. To obtain sufficiently reliable results at least 500 simulations are recommended, and for some cases between 1000 to 10000 simulations (realizations) may be required. The user should experiment with this parameter to determine the sensitivity of the results to the number of simulations.

Number of Data Ranges: This is the number of data ranges to divide the probability distributions into in the output of the results of the simulation. A maximum of 20 ranges may be specified. This parameter does not affect the accuracy of the results and is for display purposes only.

List All Results: By selecting this option, the user can obtain a list of all the simulation results. Listing all the results will include the results of every simulation pass in the output, the output file that is

obtained may be extremely large. This option can be used to list all the results for a limited number of simulations (e.g. 10), to obtain a better idea of how the program is functioning, prior to running it for all the simulations.

Variable Type: This is the type of data for which the user wishes to enter a uniform distribution. There are 6 types of data that can be used:

Initial Source Concentration: This is the Initial Source Concentration of the top boundary, and can only be used if the top boundary condition is NOT zero flux.

Darcy Velocity: This is the Darcy Velocity of the model.

Layer Thickness: This allows the user to specify a distribution for the thickness of a layer. The user will be asked to specify the layer for which to vary the thickness.

Diffusion Coefficient: This is the Diffusion Coefficient of a layer, the user will be asked to specify the layer for which to vary the Diffusion Coefficient.

Distribution Coefficient: This is the Distribution Coefficient of a layer, the user will be asked to specify the layer for which to vary the Distribution Coefficient. If the layer selected is fractured the distribution coefficient along the fracture will be varied.

Variable Properties End Time: This is the End Time of a Variable Properties Time Group, the user will be asked to specify the Time Group for which to vary End Time. When varying the end time of a time group the program will shift the end times of subsequent time groups to maintain their relative position, and will try to keep the end times of any previous time groups the same. This variable type will not show up if the Variable Properties feature has not been previously selected.

Minimum: This is the minimum value of the uniform distribution for the variable.


Maximum: This is the maximum value of the uniform distribution for the variable.

Layer Number: If the variable type is Layer Thickness, Diffusion Coefficient, or Distribution Coefficient this is the layer to vary.

Time Group: If the variable type is Variable Properties End Time this is the end time of the time period to vary.

3.3.7 Displaying the Subsurface Model


When a model has been created a representation of the model will be displayed on the Subsurface Model tab.



At the top of the tab there are buttons to adjust the options for the display and to print it to the default printer.

3.3.7.1 Subsurface Model Options

When the Options button is pressed, the Subsurface Model Options form is displayed.



The dialog box titled "Subsurface Model Options" contains the following elements:

- A checked checkbox labeled "Draw text leaders".
- Two input fields: "Width (pixels):" with the value "800" and "Height (pixels):" with the value "800".
- Two buttons with pencil icons: "Leader Line Style" and "Layer Line Style", each followed by a small empty text box.
- Two large buttons: "Model Title Font" and "Model Text Font".
- A footer bar with three buttons: "OK" (with a green checkmark icon), "Cancel" (with a red X icon), and "Help" (with a question mark icon).

The following can be edited on this form:

Width: This is the width of the model image in pixels.

Height: This is the height of the model image in pixels.

Draw text leaders: Check this box to draw leader lines from the model to the text (layer names).


Leader Line Style: Press this button to adjust the line style for the text leaders.

Layer Line Style: Press this button to adjust the line style for the layers.

Model Title Font: Press this button to adjust the font for the model title.

Model Text Font: Press this button to adjust the font for the text.

3.4 Running a Model



After the data for the model has been entered, the model can be run to calculate the concentrations with time and depth. To run a model click on the Run button at the top of the form or the F9 key. Alternatively, after the model data has been entered the Auto option at the top of the form can be turned on. This option will automatically run the model after any change has been made, and can be used to quickly view the results of changes in the model. The Monte Carlo Simulation and Sensitivity Analysis special features are computationally intensive and the Auto option is not available when these features are selected.

The results of the model will be displayed on the two tabs on the right side of the form as described in the section [Displaying Model Output](#)^[178].

3.5 Displaying Model Output

After a model has been run, the results can be displayed in a variety of [graphs \(charts\)](#)^[179] or a [text listing](#)^[178] on the two tabs on the right side of the form.

3.5.1 Displaying Model Listing

A text listing of the model data and output is displayed on the List tab.

POLLUTEv10

Version 10.00
Copyright (c) 2025
GAEA Technologies Ltd., R.K. Rowe and J.R. Booker

Case 4: Finite mass source

THE DARCY VELOCITY (Flux) THROUGH THE LAYERS $V_a = 0.03$ m/a

Layer Properties

Layer	Thickness	Number of Sublayers	Coefficient of Hydrodynamic Dispersion	Matrix Porosity	Distribution Coefficient	Dry Density
Aquitard	4 m	4	0.01 m ² /a	0.4	0 cm ³ /g	1.5 g/cm ³

Boundary Conditions

Finite Mass Top Boundary

Initial Concentration	1000 mg/L
Rate of Increase	0 mg/L/yr
Volume of Leachate Collected	0.27 m/a
Reference height of Leachate	7.5 m

Fixed Outflow Bottom Boundary

Landfill Length	200 m
Landfill Width	300 m
Base Thickness	3 m
Base Porosity	0.3
Base Outflow Velocity	6 m/a

Laplace Transform Parameters

TAU	7
N	20
SIG	0
RNU	2

Maximum Base Concentration Parameters

Depth of Search	4 m
-----------------	-----


At the top of this tab, the Options button can be used to adjust the format of the listing. The initial format settings are specified in the template used for the model. The use of this form is described in the [Editing](#)

[Listing Format and Options](#)^[294] for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

Also at the top of the form is a toolbar for editing the selected text, saving the listing, and printing the listing.

3.5.2 Displaying Charts

The [chart type](#)^[180] to be displayed can be selected from the combo box at the top of the Graph tab. Also at the top of the Graph tab are buttons to Edit the chart format, adjust the chart Options, Print the chart, and export the chart data. These buttons are described in the sections below.



3.5.2.1 Chart Types


If the model did not use the Monte Carlo Simulation or Sensitivity Analysis special features these charts can be displayed:

- [Depth vs Concentration](#)¹⁸⁰
- [Concentration vs Time](#)¹⁸¹
- [Concentration vs Depth vs Time](#)¹⁸²
- [Depth vs Time](#)¹⁸⁴
- [Flux vs Time](#)¹⁸⁴


or if the model used the Monte Carlo Simulation or Sensitivity Analysis feature these charts can be displayed:

- [Probability vs Concentration](#)¹⁸⁶
- [Probability vs Time](#)¹⁸⁶
- [Probability vs Variable Value](#)¹⁸⁷


This chart will display the depth versus concentration for each of the times specified in the model. The curve for each time can be turned on and off using the check boxes in the legend.




This chart will display the concentration versus time for each of the depths specified in the model. The curve for each depth can be turned on and off using the check boxes in the legend.




This chart will display the concentration versus depth versus time in 3D as nodal network with the concentration determining the color of each 3D grid cell.




This chart will display the depth versus time as colored grid, with the concentration determining the color.




This chart will display the top and bottom flux versus time. The curve for the top and bottom flux can be turned on and off using the check boxes in the legend.



This chart will display the probability versus concentration.




This chart will display the probability versus time.




This chart will display the probability versus variable value.



3.5.2.2 Editing Chart Format




The format of the chart can be edited by clicking on the Edit button on the Graph tab. The Editing Chart form will be displayed.




This form shows a tree view on the left containing the various sections of the chart that can be formatted. On the right are the options for the selected section. The initial format settings are specified in the template used for the model.

The use of this form is described in the [Editing Chart Formatting](#)^[295] for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

3.5.2.3 Editing Chart Line Options



If the chart type is not Concentration vs Depth vs Time or Depth vs Time, the chart is displayed as series of lines. The line options can be edited by pressing the Options button on the Graph tab. The Chart Options form will be displayed.




The 'Chart Options' dialog box has a blue title bar. On the left, there is a 'Line Width' spinner set to '2' and a checkbox labeled 'Show Data Values' which is currently unchecked. On the right, there is a 'Line Colors' section containing a table with 12 rows. Each row has a 'Line #' column and a 'Color' column. The colors for lines 1 through 10 are: blue, dark red, green, red, blue, magenta, yellow, teal, bright green, and black. Lines 11 and 12 are grey. At the bottom of the dialog are three buttons: 'OK' with a green checkmark, 'Cancel' with a red X, and 'Help' with a blue question mark.


Line #	Color
1	Blue
2	Dark Red
3	Green
4	Red
5	Blue
6	Magenta
7	Yellow
8	Teal
9	Bright Green
10	Black
11	Grey
12	Grey

The initial options are specified in the template used for the model. The use of this form is described in the [Editing Chart Line Options](#)^[304] for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

3.5.2.4 Editing Chart Grid Options



If the chart type is Concentration vs Depth vs Time or Depth vs Time, the chart is displayed as a grid and the grid options can be edited by pressing the Options button on the Graph tab. The Chart Options form will be displayed.


The image shows a 'Chart Options' dialog box with a blue title bar. It contains several settings: a checked checkbox for 'Interpolate Data' with a 'Number of Interpolations' spinner set to 2; 'Start Color' and 'End Color' buttons with corresponding color swatches (white and red); a 'Number of Steps' spinner set to 20; a checked checkbox for 'Grid Visible' with a 'Grid Color' button and a small color swatch; and three buttons at the bottom: 'OK' with a checkmark, 'Cancel' with an 'X', and 'Help' with a question mark.

The initial options are specified in the template used for the model. The use of this form is described in the [Editing Chart Grid Options](#)^[305] for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

3.5.2.5 Printing the Chart




To preview and print a chart click on the Print button at the top of the tab. The Chart Preview form will be displayed.




Using this form the print settings can be adjusted and the chart printed.

3.5.2.6 Exporting Chart Data



The chart can be exported by clicking on the Export button at the top of the tab. The Export Dialog form will be displayed.



Using this form the chart can be exported to a bitmap or metafile. It is not recommended to use this form to export the data, the [Export Output Data to Excel](#)¹⁹⁴ function should be used instead.

3.6 Exporting to Excel

The output data from a model can be exported to an Excel file by selecting the Excel tab. The output data can be listed all on one sheet or have one sheet for each time. The times can be displayed just for the first depth or all depths.

To export the data to an Excel file click on the Export to Excel button. You will then be prompted to specify the file name of the Excel file. After the data has been exported you will have the option to open it in Excel. The file is stored in "xlsx" format.

[illegible]

3.7 Exporting to a Migrate Model


The Pollute model can be converted and saved as a Migrate model by going to [File > Export > to Migrate Model](#). After the model has been converted you will need to specify a unique name for the Migrate model.

3.8 Importing Output Data


In addition to the calculated results of the model, imported output data can also be displayed on the concentration vs depth and concentration vs time charts. This imported data can be from other models, experimental results, or theoretical results. The imported data can be extracted from an Excel file, other models in the project, or created and entered directly. After the imported data has been entered in can be edited or deleted.

3.8.1 Importing Other Model Output Data

Output data from a different model in the project can be imported to compare the results of two different models. To import this data select **File > Import > Other Model Output Data**. The Select Pollute Model form on the will be displayed.



After the model has been selected, you will be asked to provide a name for the imported dataset.



Dataset Name


Enter the name of the dataset:

OK Cancel

The data will then be imported and the name will appear in the chart legend. The imported data will only show up in charts and will not be displayed in the listing.

3.8.2 Importing Output Data from Excel

To import the data from an Excel file select File > Import > Output Data from Excel File. You will then be asked to select the file to import.



Import Excel Data

Name:

Time Units:

Depth Units:

Concentration Units:

+ Add - Delete

Time	Depth	Concentration
+20 yr!A3	+20 yr!B3:B35	+20 yr!C3:C35
+50 yr!A3	+50 yr!B3:B35	+50 yr!C3:C35

	A	B	C	D	E	F	G	H
1	Time	Depth	Conc					
2	(yr)	(m)	(µg/L)					
3	50	0	1500					
4	50	0.001524	1006.9811					
5	50	0.091524	885.04316					
6	50	0.181524	769.81267					
7	50	0.271524	662.33081					
8	50	0.361524	563.36677					
9	50	0.451524	473.40521					
10	50	0.541524	392.64992					
11	50	0.631524	321.04261					
12	50	0.721524	258.2942					
13	50	0.811524	203.92544					
14	50	0.901524	157.31318					
15	50	1.201524	157.28187					
16	50	1.291524	123.1356					
17	50	1.381524	95.223854					
18	50	1.471524	72.730908					
19	50	1.561524	54.8631					
20	50	1.651524	40.874233					
21	50	1.741524	30.083706					
22	50	1.831524	21.887742					
23	50	1.921524	15.764545					
24	50	2.011524	11.274461					
25	50	2.101524	8.0563486					
26	50	2.401524	2.0279932					
27	50	2.701524	0.43086027					
28	50	3.001524	0.07705844					
29	50	3.301524	0.01157726					
30	50	3.601524	0.001458643					

10 yr 20 yr 30 yr 50 yr 100 yr

Import Cancel Help

After the file has been selected, the Import Excel Data form will be displayed. On the right of this form is the Excel sheets from the file and on the left of the form the following can be specified:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.

Import Table

The data to be imported from the Excel sheets on the right must be specified in the Import Table. For each time to be imported the range of cells for the depth and concentration must be selected. At the top of the Import Table there are buttons to Add and Delete a time.

The time can be selected by first selecting the time cell in the Import Table and then clicking on the time in sheets on the right side of the form. After a time has been selected the range of cells for the depth and concentration can be specified by first clicking on the cell in the Import Table, then selecting the first cell in the sheets on the right side of the form and while holding down the left mouse button selecting the last cell in the range.

After all of the data to be imported has been specified in the Import Table, press the Import button to import the data.

3.8.3 Creating an Imported Dataset

Data can also be imported into the model by creating a dataset and entering the data. To create a new data select [File > New > Imported Dataset](#). The Create New Dataset form will be displayed.

Create New Dataset

Name:

Time Units: Concentration Units:

Depth Units:

+ Add X Delete

Time	Depth	Concentration

OK Cancel ? Help

The following can be specified on this form:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.

Import Table

The time, depth, and concentration data to import can be entered in the Import Table. At the top of the table there are buttons to add and delete a data point.

When all of the data points have been entered press the Ok button to create the dataset.

3.8.4 Editing an Imported Dataset

After the data has been created or imported it can be edited by selecting Edit > Imported Dataset. The Select Imported Dataset form will be displayed.



Select the dataset to edit and then click on the Ok button. The Edit Dataset form will be displayed.

Name: Case 18: Phase Change

Time Units: yr Concentration Units: mol/m3

Depth Units: m

+ Add X Delete

Time	Depth	Concentration
95	0	5.52674840438603E-5
95	0.15	0.000254692081837588
95	0.3	0.000408322543147919
95	0.45	0.000498531347488346
95	0.6	0.00052392842755612
95	0.65	0.000523922355508225
95	0.7	0.000523916159137902
95	0.75	0.000523909838450055
95	0.8	0.000523903393449613
95	0.825	0.000523903265765265
95	0.85	0.000523903263148956
95	0.875	0.0005239033856013
95	0.9	0.000523903633122938
95	1.0875	0.000465918039072118

OK Cancel Help

The following can be edited on this form:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.


Import Table

The time, depth, and concentration data can be edited in the Import Table. At the top of the table there are buttons to add and delete a data point.

After all of the edits are complete, click on the Ok button to save the changes.


3.8.5 Deleting an Imported Dataset

Imported datasets can be deleted from the model by selecting File > Delete > Imported Dataset. The Delete Imported Dataset form will be displayed.




Select the dataset to delete then click on the Ok button. Only the imported dataset will be deleted. This will not delete the original Excel file or other Model data.


3.9 Saving a Model



To save any changes to a model click on the Save button at the top of the form. If the save button is not enabled, then no changes have been made yet.



To save the model under a new name click on the SaveAs button at the top of the form. The Save As form will be displayed.



The dialog box titled "Save Pollute Model As" contains a "Name:" text field at the top. Below it is a checkbox labeled "Save As Template". Underneath the checkbox is a section titled "Existing" which contains a table listing various model cases. At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".


Name	Template
Case 10: Time-varying advective-dispersive	Blank
Case 11: Time varying source concentration with	Blank
Case 12: POLLUTE vs Analytical solution	Blank
Case 13: Comparison with analytical method	Blank
Case 14: Primary and Secondary Leachate	Blank
Case 15: Leachate Collection with Failure.	Blank
Case 16: Monte Carlo Simulation	Blank
Case 17: Landfill with composite primary liners.	Primary & Secondary Landfill
Case 18: Phase Change	Blank
Case 19: Multiphase Diffusion Test	Blank
Case 1: Subtitle D Landfill with constant source	Primary Landfill
Case 20: Sensitivity Analysis	Blank
Case 2: Pure diffusion	Blank
Case 4: Finite mass source	Blank
Case 5: Hydraulic trap - Finite mass source	Blank

At the top of this form a new unique name can be specified. There is a list of existing models in the bottom of the form to make it easier to specify a unique name.

In addition, the model can be saved as a template by checking the Save As Template box. After being saved as a template it can be used to create other models.

3.10 Deleting a Model


To delete a model select **File > Delete > Pollute Model** when the project is open but no model is open. The Delete Pollute Model form will be displayed.



Select the model then press the Delete button to delete the model.

3.11 Converting a Model


Models that have been created with templates other than the Blank (Regular) can be converted to a regular model by selecting *Edit > Convert to Regular Pollute Model*. The Convert Pollute Model will be displayed.



This form will list the models that were not created using the regular (Blank) template. Select the model to convert then press the Convert button.

3.12 Exporting a Model

Models can be imported and exported from one computer to another as XML exchange files. To export a model select **File > Export > Pollute Model** when the project is open but no model is open. The Export Pollute Model form will be displayed.



Select the model to export then click on the Export button. After this you will be prompted to specify the name of the XML file to store the exported model.

3.13 Importing a Model

Models can be imported and exported from one computer to another as XML exchange files. To import a model select *File > Import > Pollute Model* when the project is open but no model is open. You will then be prompted to specify the name of the file to import.

Pollute & Migrate


User Guide

Chapter 4 Migrate Models

Chapter 4 Migrate Models

Models are used to represent the subsurface lithology, containment systems, and contaminant source to be studied. These models can be used to study the effects of landfills, buried waste, spills, lagoons, barrier systems, etc. Each study area should be grouped into one or more projects. A project is used to store one or more models in a study area. After a model has been created it can be run to calculate the concentrations of a contaminant at specified depths and times.

4.1 Creating a New Model



After a project has been created or opened, a model can be created either by clicking on the New button and selecting Migrate Model or selecting *File > New > Migrate Model*. The New Migrate Model form below will be displayed.

The dialog box is titled 'New Migrate Model'. It has two tabs: 'New' and 'Existing'. The 'New' tab is active, showing a list of model templates: 'Blank', 'Primary & Secondary Landfill', 'Primary Landfill', and 'Primary Leakage Rate Landfill'. The 'Preview' section on the right shows a vertical cross-section of a model. The top layer, from 0.00 m to 1.00 m, is shaded orange with diagonal lines and labeled 'Layer One'. The bottom layer, from 1.00 m to 5.00 m, is white. Both layers are labeled 'Constant Concentration' at their respective boundaries. At the bottom of the dialog, there is a 'Name:' label followed by a text input field. Below the input field are three buttons: 'OK' (with a green checkmark), 'Cancel' (with a red X), and 'Help' (with a blue question mark).

Select the template to use for the model and enter a unique model name. When a template is selected it will be shown in the Preview. The Existing tab lists the existing models in the project. After the unique name is entered press the Ok button to create the model and open it for editing.

The program comes with the templates described below. In addition, you can create your own templates as described in the section [Creating a Template](#)²⁹¹.

Blank

This is an empty model that requires the majority of the data to be entered when it is created. If no template is selected, the blank template is used to create the model.

Primary Landfill

The Primary Liner (Subtitle D) Landfill option is used to quickly enter a landfill that may contain a leachate collection system, primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the an equivalent hydraulic conductivity must be specified or the geomembrane.


Primary and Secondary Landfill

The Primary and Secondary Liner Landfill option is used to quickly enter a landfill that may contain a primary leachate collection system, primary composite liner, secondary leachate collection system, secondary composite liner, aquitard, and aquifer. In this option the composite liners can be composed of a geomembrane and/or compacted clay or GCL. If the geomembrane is present the an equivalent hydraulic conductivity must be specified or the geomembrane.

Primary Leakage Rate Landfill

The Leakage Rate (Subtitle D) Landfill is used for a landfill that contains a leachate collection system, primary composite liner, and aquifer. It uses a leakage rate calculated according to the method proposed by Giroud et. al. (1992), to determine the Darcy velocity through the composite liner. In this method the leakage rate through a composite liner will depend on the type and number of defects in the geomembrane, the leachate head on the liner, and the thickness and hydraulic conductivity of the compacted clay or geosynthetic clay liners. In addition the leakage rate due to permeation can also be considered, and is calculated according to the method proposed by Giroud and Bonaparte (1989).

4.2 Opening a Model



To open an existing model either select *File > Open > Migrate Model*, press the Open button on the toolbar and select Pollute Model, or double-click on it in the list of models. If the first two methods are used the Open Migrate Model form will be displayed.

Most Recent Models	
Name	Template
test var diff	Blank
Case 4: Finite Mass and Leachate Collection System	Blank
Case 3: Pure Diffusion - constant source and base	Blank
#VAR Case 12: Two Landfills - Different Source His	Blank
#VAR Case 13: Failure of Leachate Collection Syste	Primary Leakage Rate Landfill
test 2 var	Blank
Test 1	Blank
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill

All Models	
Name	Template
Case 2: Landfill with composite primary and con	Primary & Secondary Landfill
#DLIM #FRAC Case 10: 1m Compacted Clay Lin	Blank
#VAR Case 12: Two Landfills - Different Source	Blank
#VAR Case 13: Failure of Leachate Collection S	Primary Leakage Rate Landfill
Case 11: Two Landfills	Blank
Case 1: Subtitle D Landfill with constant source	Primary Leakage Rate Landfill
Case 3: Pure Diffusion - constant source and ba	Blank
Case 4: Finite Mass and Leachate Collection Sys	Blank
Case 5: Demonstrate Effects of Integration	Blank
Case 6: Repeat Case 5 using N=20 and RNU=2	Blank
Case 7: Repeat Case 5 using N=20, RNU=2, an	Blank
Case 8: Concentration Profile for a Buried Landf	Blank
Case 9: Comparison with an analytical solution -	Blank
Test 1	Blank
VAR DIFF	Blank
test 2 var	Blank

Preview not available

Open Cancel Help

This form lists the most recently opened models at the top and all of the models on the bottom. When a model is selected a preview for it will be shown on the right. Select the model to open and then click on the Open button.

4.3 Editing a Model

After a model has been created or opened, depending on the template it can be edited using the methods below.

4.3.1 Editing a Normal Model

If the model was created using the Blank template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the three tabs for General data, Boundaries, and Layers. In addition, there is a tab for the subsurface model.

The screenshot displays the 'General Information' tab of the POLLUTE and MIGRATE software. The interface includes a menu bar (File, Edit, Tools, Window, Help) and a toolbar with icons for Close, Help, Exit, Run, Save, and Save As. The 'General' tab is selected, showing the following fields and options:

- Model Title:** Case 3: Pure Diffusion - constant source and base concentrations.
- Number of Landfills:** 1
- ☐ Maximum Sublayer Thickness
- ☐ Specify OFLOW
- ☐ Time Varying Properties

Below these are two sections:

- Laplace Transform Parameters:**
 - TAU: 7
 - N: 11
 - SIG: 0
 - RNU: 1
- Gauss Integration:**
 - ☐ Fine
 - ☒ Normal
 - ☐ Wide
 - ☐ Select

Further down is the **Run Parameters** section:

- Time Units: year
- Depth Units: m
- Concentration Units: mg/L
- ☐ Zero Negative Concentraions

At the bottom, there are two tables for output data:

- Output Distances:**

Distance	Units
0	m
100	m
- Output Times:**

Time	Units
10	year
50	year
100	year
150	year
200	year

The data entry for the General data, Boundaries, and Layers is described in the sections below. If the Time Varying Properties is checked, there will also be the option to check Variable Layer Properties and a Time-Varying Properties tab will also be present.

Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[253]. The control

of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#) ²⁵⁷.

4.3.1.1 General Data

To edit the general data for a model click on the General tab on the left side of the model form.

The screenshot shows the 'General Information' tab of a model form. The form is divided into several sections:

- General Information:**
 - Model Title: Case 3: Pure Diffusion - constant source and base concentrations.
 - Number of Landfills: 1
 - Maximum Sublayer Thickness: ☐
 - Specify OFLOW: ☐
 - Time Varying Properties: ☐
- Laplace Transform Parameters:**
 - TAU: 7
 - N: 11
 - SIG: 0
 - RNU: 1
- Gauss Integration:**
 - Integration Type: ☒ Select
 - Number of Groups: 1
 - Number of Samples: 20
 - Table:

Group	Step Size	# of Steps
1	0.1	12
- Run Parameters:**
 - Time Units: year
 - Depth Units: m
 - Concentration Units: mg/L
 - Zero Negative Concentrations: ☐
- Output Distances:**
 - Buttons: + Add, X Delete
 - Table:

Distance	Units
0	m
100	m
- Output Times:**
 - Buttons: + Add, X Delete
 - Table:

Time	Units
10	year
50	year
100	year
150	year
200	year

The following can be specified on this tab:

General Information

Model Title: This is the title of the model is used to describe the model, and may be up to 255 characters long.

Number of Landfills: One or more landfills or other contaminant sources may be modelled. The maximum is 10.

Maximum Sublayer Thickness: The maximum thickness of each sublayer is 5 units. The number of sublayers is automatically increased if required to keep their thickness to less than 5. For example, if the layer thickness was 50 m and it had 5 sublayers (giving a sublayer thickness of 10), the program will automatically adjust the number of sublayers to 10. Optionally, the maximum sublayer thickness can be specified by checking this box.

Specify OFLOW: Check this box to specify the OFLOW.

Time Varying Properties: Check this box to specify time-varying properties.

Variable Layer Properties: If there is time varying properties, check this box to specify variable layer properties.

Laplace Transform Parameters

The solution of the contaminant migration equations involves the inversion of a Laplace Transform. In this inversion the accuracy depends upon four parameters: TAU, N, SIG, and RNU. The user may adopt the default values (TAU=7, SIG=0, N=20, and RNU=2) or specify other values. It has been found that a value of TAU between 7 and 10, and a value of SIG = 0 is satisfactory in most cases. The more critical parameters, RNU and N, typically yield accurate results when:

$$RNU = (0.1 * \text{Layer Thickness} * \text{Darcy Velocity}) / (\text{Minimum Diffusion/Dispersion Coefficient})$$

and

$$N = 10 * RNU \text{ if } RNU \text{ is greater than } 1.0.$$

These values of RNU and N will work extremely well but will often require more integration than is necessary. If the computation times seem excessive smaller values of RNU and N should be tried, and the accuracy of the results compared. The program will detect grossly unreasonable results and automatically repeat the calculation with the values suggested above, in this circumstance the value of RNU is limited to 40.

Gauss Integration

The theoretical development involves the use of a Fourier transform and hence the synthesis of the final solution involves some numerical integration. These integrations are performed numerically by decomposing the integration range into a number of subintervals and then using Gauss quadrature within each subinterval. The width and number of integration subintervals which are required to achieve a reasonable accuracy (say 0.1%) depends somewhat on the geometry and properties of the problem under consideration. These parameters can be determined from a few trial calculations for a representative point and time of interest.

The program is capable of performing four levels of Gauss quadrature, FINE, NORMAL, WIDE, and SELECT. When SELECT is specified the user must input the integration parameters. The computation time is directly proportional to the amount of integration. The error involved in the integration depends upon the problem and the depth of the point of interest beneath the source. This error tends to be greatest at the surface outside the landfill, and decreases with depth below the landfill.

Run Parameters

The run parameters specify the depths and times to calculate the concentrations for the model.

Time Units: The output units for the times can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

Depth Units: The output units for the depths can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

Concentration Units: The output units for the concentrations can be selected using the combo box. All of the units selected for the input data will then be converted to units consistent with these units and the output data generated will be in these units.

Zero Negative Concentrations: Check this box to make negative calculated concentrations zero.

Output Distances These are the distances at which to calculate the concentration of contaminant. The distances should be entered in ascending order. Use the Add and Delete buttons to add and delete a distance.

Output Times: These are the times at which to calculate the concentration of contaminant. The times should be entered in ascending order. Use the Add and Delete buttons to add and delete a time.

4.3.1.2 Boundaries

For every model there are two boundary conditions, one at the top and one at the bottom. The top boundary condition is usually the point of contact between the contaminant source (eg. a landfill) and the subsurface layers (deposit), and can be either:

- Constant Concentration at the surface,
- Finite Mass at the surface,
- Zero concentration at the surface with buried mass,
- Impermeable surface with buried mass,

The bottom boundary condition is usually the point of contact between the layered deposit and either a much more or much less permeable strata (eg. an aquifer or intact bedrock) and can be either:

- Impermeable,
- Zero Concentration, or
- An Aquifer,

If more than one landfill has been specified, the data for the top boundary condition must be specified for each landfill (or other contaminant source). Although more than one landfill may be specified as the source for the contaminants, it should be noted that the type of boundary condition must be the same for all the landfills. This means that if the top boundary condition is specified as finite mass, then all the landfills must be finite mass. In addition, it should be noted that since the liner of a landfill is modelled as a layer, all of the landfills must have the same type of liner (i.e., it is not possible to model a landfill with a geomembrane and a landfill without a geomembrane together).

To edit the boundary data for a model click on the Boundaries tab on the left side of the model form.

Top Boundary

☐ Constant Concentration - Surface
☒ Finite Mass - Surface
☐ Impermeable - Buried
☐ Zero Concentration - Buried

	Landfill 1	Landfill 2	Units
Offset Distance	0		m
Landfill Surface Width	200		m
Landfill Base Width	200		m
Initial Concentration	1		mg/L
Source Half-life	0	year	
Waste Thickness	25	m	
Waste Density	600	kg/m ³	
Percentage of Mass	0.2		
Volume Leachate Collected	0	m/a	

Bottom Boundary

☐ Impermeable
☐ Zero Concentration
☒ Aquifer

☐ Print Mass into Base

	Aquifer	Units
Base Thickness	0	m
Base Half-Life	0	yrs
Base Porosity	0.3	
Sink Removal	0	m/a
Outflow Velocity	0	m/a
Dispersion Coefficient	0	m ² /a

Base Symbol

If the Time Varying Properties option is selected only the type of top boundary is specified on this tab. The properties for the top boundary will be specified on the Time Varying tab.

Constant Concentration at Surface

Top Boundary

☒ Constant Concentration - Surface
☐ Finite Mass - Surface
☐ Impermeable - Buried
☐ Zero Concentration - Buried

	Landfill 1	Landfill 2	Units
Offset Distance	0		m
Landfill Surface Width	200		m
Landfill Base Width	200		m
Surface Concentration	1		mg/L

The constant concentration top boundary condition represents the case where the concentration of contaminant in the landfill remains constant throughout time, and is equivalent to the assumption of an infinite mass of contaminant in the landfill. If this top boundary condition is specified the following must be specified for each landfill:

Offset Distance: This is the distance from the co-ordinate origin on the x-axis (horizontal) to the centre of the landfill .

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Surface Concentration: This is the constant concentration at the surface of each landfill..

Finite Mass at the Surface

Top Boundary

- ☐ Constant Concentration - Surface
☒ Finite Mass - Surface
☐ Impermeable - Buried
☐ Zero Concentration - Buried

	Landfill 1	Landfill 2	Units
Offset Distance	150	650	m
Landfill Surface Width	300	600	m
Landfill Base Width	280	580	m
Initial Concentration	1500	0	mg/L
Source Half-life	0	0	year
Waste Thickness	15	0	m
Waste Density	600	600	kg/m ³
Percentage of Mass	0.2	0.2	
Volume Leachate Collected	0.05	0.05	m/a

The finite mass boundary condition is most representative of a landfill, where the concentration of contaminant starts at an initial value, increases with time, and then declines as contaminant is transported into the subsurface and is removed by leachate collection systems. The following must be specified for each landfill.

Offset Distance: This is the distance from the co-ordinate origin on the x-axis (horizontal) to the centre of the landfill .

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Initial Source Concentration: This is the initial concentration of the source of contaminants, usually at time zero.

Source Half-Life: If the contaminant species experiences radioactive or biological decay while in the landfill, the first-order decay half-life may be specified. If there is no decay specify a half-life of zero (which is taken to be infinite).

Waste Thickness: This is the average thickness of waste in the landfill (or other contaminant source). If the effects of the side-slopes of the landfill are being considered by using different base and surface widths, then the waste thickness specified here should not consider these effects.

Waste Density: This is the apparent density of the waste (i.e. mass of waste per unit volume of the landfill). Either the waste density or reference height of leachate must be specified.

Proportion of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste). Either the proportion of mass or reference height of leachate must be specified. Rowe et al (2004) report some published values for leachable mass.

Volume of Leachate Collected: This is the volume of leachate collected per unit area of landfill per unit time, usually by the leachate collection system. Thus, after the landfill reaches field capacity the average volume of leachate collected is equal to the average infiltration through the landfill cover less the average exfiltration through the base of the landfill (assuming the waste is at field capacity). For example, if the average infiltration is 0.3 m/a and the average exfiltration is 0.03 m/a, then the average volume of leachate collected is $0.3 - 0.03 = 0.27$ m/a.

Impermeable Surface and Buried Mass

Top Boundary

- ☐ Constant Concentration - Surface
☐ Finite Mass - Surface
☒ Impermeable - Buried
☐ Zero Concentration - Buried

	Landfill 1	Landfill 2	Units
Offset Distance	150	650	m
Landfill Surface Width	300	600	m
Landfill Base Width	280	580	m

This boundary conditions is similar to the zero surface concentration and buried mass condition, except in this case the surface is assumed to represent an impermeable layer, (i.e. zero-flux). The following must be specified for each landfill.

Offset Distance: This is the distance from the co-ordinate origin on the x-axis (horizontal) to the centre of the landfill .

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Zero Concentration and Buried Mass

Top Boundary

☐ Constant Concentration - Surface
☐ Finite Mass - Surface
☐ Impermeable - Buried
☒ Zero Concentration - Buried

	Landfill 1	Landfill 2	Units
Offset Distance	150	650	m
Landfill Surface Width	300	600	m
Landfill Base Width	280	580	m

This boundary condition can be used to model a buried contaminant source. Using this boundary condition, contaminants can move upwards and downwards from the source. At the surface the concentration is assumed to be zero, which would simulate the removal of contaminants at the surface by runoff, collection systems, or other means. This boundary condition assumes that the dispersion coefficient in the soil adjacent to the buried waste, is the same as within the buried waste. The following must be specified for each landfill.

Offset Distance: This is the distance from the co-ordinate origin on the x-axis (horizontal) to the centre of the landfill .

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Impermeable

The impermeable bottom boundary condition represents the case where no mass is transported into or out of the bottom of the deposit. This condition can be used to represent the case of a deposit underlain by an impermeable base stratum (e.g., intact bedrock that is impermeable relative to the overlying layer or deposit).

Zero Flux

The zero concentration bottom boundary condition represents the case where the concentration of contaminant remains zero in the base strata.

Aquifer

Bottom Boundary

☐ Impermeable
☐ Zero Concentration
☒ Aquifer

☒ Print Mass into Base

	Aquifer	Units
Base Thickness	2	m
Base Half-Life	0	year
Base Porosity	0.3	
Sink Removal	0	m/a
Outflow Velocity	0	m/a
Dispersion Coefficient	10	m ² /a
Base Integration Width	2400	m

Base Symbol


The aquifer boundary condition represents the case where the deposit is underlain by a permeable base strata. The concentration in the base strata (aquifer) varies with time as mass is transported into the aquifer from the deposit, and then transported away by the horizontal velocity and dispersion in the base strata.

The base aquifer is modelled as a boundary condition (not a separate layer) and the concentration at the bottom of the deposit is the concentration at the top of the base aquifer. This boundary condition assumes that there is sufficient dispersion/mixing (i.e. a very high vertical dispersion coefficient) such that the concentration is uniform across the thickness of the aquifer being considered. Thus the concentration at the bottom of the aquifer thickness modelled is the same as reported at the top of the aquifer. If the actual aquifer is very thick, normally only the upper portion (3 - 6 m depending on conditions) should be considered in modelling. Alternatively, the aquifer could be modelled as an additional layer. This approach allows the consideration of vertical dispersion\diffusion, and may give a vertical diffusion profile through the aquifer's thickness. With this boundary condition the user must specify:

Base Thickness: This is the vertical thickness of the base strata that is being modelled as a boundary condition.

Base Half-Life: This is the first-order decay half-life of the contaminant species in the aquifer. If the contaminant species does not experience radioactive or biological decay, a half-life of zero should be specified to imply infinite half-life.

Base Porosity: This is the porosity of the base strata, between 0 and 1.

Sink Removal: This is used to specify the rate of removal of contaminants from the aquifer by a passive sink (ex. a purge well system). For a more detailed discussion see Sink Removal Rate under Layer Properties.

Outflow Velocity: This is the horizontal Darcy outflow velocity within the base strata at the down-gradient edge of the landfill. If the outflow velocity is set very high the results will be equivalent to setting a constant base concentration of zero.

Base Integration Width: The base integration width is used to determine the flux of contaminants into and out of the base. This integration width is measured in the same direction as the landfill width, which should be in the direction of groundwater flow. Ideally the base integration width should be infinite; however, to limit computing time typical values equal to six times the landfill base width may be used.

Base Symbol: This is used to select the symbol that will be used for the aquifer when drawing the subsurface model. When the symbol is clicked on the symbol can be selected as described in the [Select Symbol](#) ²²⁷ section.

If the Time Varying Properties option is selected the base half-life, base porosity, sink removal, and outflow velocity are specified on the Time Varying tab.

4.3.1.3 Layers

To edit the layer data for a model click on the Layers tab on the left side of the model form.

General Boundaries Layers Subsurface Model																								
+ Add > Delete ↓ Move Down ↑ Move Up																								
Name	Sublayers	Thickness	Thickness Units	Dry Density	Density Units	Porosity	Distribution Coefficient	Distribution Units	Vertical Diffusion	Horizontal Diffusion	Diffusion Units	Vertical Velocity	Horizontal Velocity	Velocity Units	Decay Half-Life	Half-Life Units	Sink Removal	Removal Units	Concentration	Conc. Units	Fractures	Symbol		
	2	1	m	0	g/cm ³	0.4	0	ml/g	0.01	0.01	m ² /a	0.01	0	m/a	0	year	0	m/a	0	ml/g	None			
	5	5	m	0	g/cm ³	0.4	0	ml/g	0.02	0.02	m ² /a	0.01	0	m/a	0	year	0	m/a	1500	ml/g	None			
	4	2	m	0	g/cm ³	0.4	0	ml/g	0.01	0.01	m ² /a	0.01	0	m/a	0	year	0	m/a	0	ml/g	None			

The data for each individual layer is entered on this tab. Continuity of concentration and flux is assumed at the boundary between layers. If a fractured layer is in contact with an unfractured layer, it is assumed that all fluid flow is transported along the fractures that intersect the unfractured layers (i.e., it is equivalent to having a very thin sand layer between unfractured and fractured layers).

Layers can be added and deleted using the Add and Delete buttons. Layers can also be moved up and down from the top using the Move Down and Up buttons. The data required for each layer consists of:

Name: This is the name of the layer. It is used only for drawing and output.

Number of Sublayers: The number of sublayers in each layer is primarily used in the output of the calculated concentrations with depth; a concentration will be calculated at each sublayer interface. The maximum thickness of each sublayer is 5 units. The number of sublayers is automatically increased if required to keep their thickness to less than 5. For example, if the layer thickness was 50 m and it had 5 sublayers (giving a sublayer thickness of 10), the program will automatically adjust the number of sublayers to 10.

Thickness: This is the thickness of the layer, this is the total thickness of all the sublayers in the layer..

Dry Density: The dry density of the layer.

Porosity: This is the porosity of the layer, which must be greater than 0 and less than or equal to 1. If the layer is being used to represent a geomembrane the porosity should be set to 1.

Distribution Coefficient: This is the distribution coefficient for the layer. In the basic mode (ie. where Langmuir Non-linear sorption and Freundlich Non-linear sorption have not been selected) the sorption-desorption of a conservative species of contaminant is assumed to be linear such that:

$$S = K_d c$$

where,

S = solute sorbed per unit weight of soil,

K_d = distribution (sorption) coefficient,

c = concentration of contaminant.

This is a reasonable approximation for low concentrations of contaminant, however at high concentrations sorption is generally not linear and more complex relationships should be used. If there is no sorption (i.e., a conservative species) the distribution coefficient is zero.

Vertical and Horizontal Diffusion/Dispersion Coefficients: These are the horizontal and vertical coefficients of hydrodynamic dispersion for the layer:

$$D_{xx} = D_{ex} + D_{mdx}$$

$$D_{zz} = D_{ex} + D_{mdz}$$

where,

Dex and Dez = diffusion coefficients for the species,
Dmdx and Dmdz = coefficients of mechanical dispersion.

For intact clayey layers, diffusion will usually be the controlling factor and dispersion will often be negligible [Gillham and Cherry, 1982, Rowe, 1987]. In sandy layers, dispersion will tend to be the controlling factor.

Vertical and Horizontal Darcy Velocities: The horizontal and vertical velocities are defined as:

$$V_{ax} = nv_x$$

$$V_{az} = nv_z$$

where,

n = effective porosity,
vx and vz = seepage or groundwater velocities.

Decay Half-Life: If the contaminant species experiences radioactive or biological decay in a layer, this option can be used to specify the half-life of the species in the layer. First order (exponential) decay is assumed for both radioactive and biological decay, eg.

$$c(t) = c(0) e^{-\lambda t}$$

where,

c(t) = concentration at time t,
c(0) = initial concentration,
 λ = decay constant = 0.693147/half-life,

If there is no decay of the species in the layer, the half-life should be specified as zero which is the same as an infinite half-life (i.e. $\lambda = 0$).

Sink Removal Rate: This is used to specify the rate of removal of contaminants from a layer by a passive sink, (for example, a secondary leachate collection system or purge wells). According to the principle of continuity of flow the rate of removal should be equal to:

where,

Rr = rate of removal (flow per unit area per unit time)
vaz1 = vertical Darcy velocity in the layer above,
vaz2 = vertical Darcy velocity in the layer below,
vax = horizontal Darcy velocity in the layer with the passive sink,
L = Width of the base of the landfill,
h = thickness of the layer with the passive sink

An example would be a 600 m long landfill with a 0.3 m thick secondary leachate, collection system. Assuming the vertical Darcy velocity above the layer is 0.01 m/a and below the layer is 0.003 m/a, then the rate of removal would be:

$$Rr = (0.01 - 0.003) \times 600/0.3 = 14 \text{ m/a.}$$

Concentration: If the top boundary condition is buried mass the user can also specify an initial concentration for the layer, to represent this mass

Fractures: Any or all of the layers may be fractured. These fractures may be 1, 2, or 3 dimensional. Where the first dimension is for one set of vertical fractures, the second is for a second set of

(orthogonal) vertical fractures, and the third is for horizontal fractures (ie. for a 3D block, dimension 1 is length, dimension 2 is width, and dimension 3 is depth). If 1, 2, or 3 dimensional fractures are specified for the layer, the fracture data can be entered at the bottom of the tab.

Symbol: This is used to select the symbol that will be used for the layer when drawing the subsurface model. When the symbol is clicked on the symbol can be selected as described in the [Select Symbol](#)  section.

If the Time Varying Properties and Variable Layer Properties options are selected the Dry Density, Distribution Coefficient, Vertical and Horizontal Diffusion Coefficients, Vertical and Horizontal Velocities, Decay Half-Life, Sink Removal, and Concentration are specified on the Time Varying tab.

Continuity of concentration and flux is assumed at the boundary between layers. If a fractured layer is in contact with an unfractured layer, it is assumed that all fluid flow is transported along the fractures that intersect the unfractured layers (i.e., it is equivalent to having a very thin sand layer between unfractured and fractured layers). In a fractured model the program can consider advective-dispersive transport along the fractures coupled with diffusion into the matrix on either side of the fracture. However, if the Darcy velocity is zero, or small, then the transport mechanism will be essentially diffusive through the matrix, the fractures will have no effect and should not be considered in modeling the migration of contaminants. Users planning to model migration in fractured media are warned that they should first see Rowe and Booker, 1990, 1991a, 1991b, and Rowe et al, 2004 for a discussion of modeling of fractured systems.

The following information about the fractures in each dimension can be specified:

Fracture Spacing: The spacing of fractures is the distance between fractures in each dimension.


Fracture Opening Size: The fracture opening size is the width of the gap between the fracture walls.

Number to sum: This is the number of terms to sum in the evaluation of the advective-dispersive equation for contaminant migration [Rowe and Booker, 1990, 1991a, 1991b]. For blocks where the fracture spacing is of the same order in all directions, 8 to 10 terms is usually adequate. As the aspect ratio (horizontal spacing/vertical spacing or vertical spacing/vertical spacing) increases more terms are required in the summation. When the aspect ratio is large, the problem can usually be reduced to a lower order (eg. from 3D to 2D or 2D to 1D). For example, if the spacing between fractures in one vertical direction is 50 units, and in the other vertical and horizontal directions is 2 units. The widely spaced fractures can be ignored and the problem reduced to a 2D problem [Rowe and Booker, 1990].

Dispersion coefficient: This is the dispersion coefficient along the fracture.

Distribution coefficient: This is the distribution coefficient along the fracture as defined by Freeze and Cherry (1979). This is often assumed to be zero.

This form is used to select a symbol to represent a subsurface layer.



The following can be specified on this form:

Library: This is used to select the symbol library. Symbols are grouped into libraries consisting of 18 symbols. When the library is selected the symbols will be displayed in the grid below the library.

Symbol: The symbol can be selected by clicking on it in the grid. The selected symbol will be highlighted with a blue box and the description for the symbol will be displayed beneath the symbol grid.

Foreground: This is used to select the foreground color for the symbol.

Background: This is used to select the background color for the symbol.

Fill Size: This is used to specify the fill size for the symbol. Generally a value of 1 or 2 should be used.

4.3.1.4 Time Varing Properties

The program is normally capable of determining the concentrations any time without determining them at previous times. However, if there is a complex source concentration history or a change in velocities or layer properties with time then it is necessary to sequentially follow this history. For example, the program can model a working landfill which experiences progressive failure of the leachate collection system and resulting buildup in the leachate mound (i.e., an increase in Darcy velocity) over a period of years [Rowe and Fraser, 1993a, 1993b].

This option allows the user to vary the layer, source and base properties with time. The Variable Properties option implements a “time-marching” scheme, where the program stops and restarts the solution every time parameters are changed. In the basic mode of operation the accuracy of the solution is independent of the number of sublayers. However, if the Variable Properties option is used then the

accuracy of this procedure depends on the number of sublayers used in the model, and the user should experiment with the number of sublayers to ensure that the results obtained are sufficiently accurate

WARNING: This option should only be used by someone with the hydrogeologic and engineering background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of the physical situation.

THIS OPTION SHOULD NOT BE USED FOR A PROJECT OF IMPORTANCE WITHOUT THE GUIDANCE OF THE PROGRAM DEVELOPERS.

When the Time Varying Properties option on the General tab is checked the Time-Varying Properties tab will be displayed.

The screenshot shows the 'Time Varying Properties' tab. At the top, there are buttons for '+ Add', 'X Delete', and navigation arrows for 'First', 'Prev', 'Next', and 'Last'. Below these is a table with columns: Group, Start Time, End Time, Units, and Increments. The first row shows Group 1, Start Time 0, End Time 0, Units year, and Increments 1.

Below the table are two sections: 'Top Boundary' and 'Bottom Boundary'.

Top Boundary: A table with columns 'Landfill 1' and 'Units'. It lists properties: Offset Distance (0 m), Landfill Surface Width (200 m), Landfill Base Width (200 m), Initial Concentration (1 mg/L), Source Half-life (0 year), Waste Thickness (25 m), Waste Density (600 kg/m³), Percentage of Mass (0.2), and Volume Leachate Collected (0 m/a).

Bottom Boundary: A table with columns 'Aquifer' and 'Units'. It lists properties: Base Half-Life (0 yrs), Base Porosity (0.3), Sink Removal (5 m/a), Outflow Velocity (10 m/a), and Dispersion Coefficient (10 m²/a).

At the bottom is a 'Layer Data' table with 18 columns: Name, Thickness, Thickness Units, Dry Density, Density Units, Porosity, Distribution Coefficient, Distribution Units, Vertical Diffusion, Horizontal Diffusion, Diffusion Units, Vertical Velocity, Horizontal Velocity, Velocity Units, Decay Half-Life, Half-Life Units, Sink Removal, and Removal Units. The first row shows values for a layer named '4'.

Name	Thickness	Thickness Units	Dry Density	Density Units	Porosity	Distribution Coefficient	Distribution Units	Vertical Diffusion	Horizontal Diffusion	Diffusion Units	Vertical Velocity	Horizontal Velocity	Velocity Units	Decay Half-Life	Half-Life Units	Sink Removal	Removal Units
4	4	m	1.5	g/cm³	0.4	0	m²/kg	0.01	0.01	m²/a	0	0	m/a	0	year	0	m/a

Time Period Data

At the top of this tab the current Time Period is displayed and there are buttons to add and delete a time period as well as to navigate between time periods. The following is specified for each time period.

Start Time: This is the start time of the first time period, and is the time at which calculations begin (usually zero). The start time is only specified for the first time period.

End Time: This is the end time of the time period, and will be the start time of the next time period.

Number of Increments: If the Properties Increment within Periods this is the number of increments to use in sub-dividing the time period. The concentrations will be calculated for the times at the end of each increment, if there is only one increment specified for the time period will be calculated at the end time. For example, if the time period started at 0 years and ended at 20 years and the number of increments was 4, concentrations would be calculated at 5, 10, 15, and 20 years.

Top Boundary Data

Based on the type of top boundary specified on the Boundaries tab, the properties for the top boundary are specified for each landfill for the current time period. These properties are described in [Top Boundary section](#) ²¹⁸.

Bottom Boundary Data

Based on the type of bottom boundary specified on the Boundaries tab, the properties for the bottom boundary, except for the base thickness are specified for the current time period. These properties are described in [Bottom Boundary section](#).^[223]

Layer Data

If the Variable Layer Properties option on the General tab is selected, the properties for the layers, except for the name, thickness, number of sublayers and type of fractures are specified for the current time period. These properties are described in the [Layers section](#).^[224]

4.3.2 Editing a Primary Landfill Model

The Primary Liner (Subtitle D) Landfill option is used to quickly enter a landfill that may contain a leachate collection system, primary composite liner, aquitard, and aquifer. In this option the primary composite liner can be composed of a geomembrane and a primary liner. If the geomembrane is present the equivalent hydraulic conductivity for the geomembrane must be specified..Another method of specifying this type of landfill uses a calculated leakage rate through defects in the geomembrane, the user should use Leakage Rate (Subtitle D) Landfill for this option.

If the model was created using the Primary Landfill template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, and Aquifer. In addition, there is a tab for the subsurface model.

RunSaveSaveAs

GeneralSource & Hydraulic HeadsGeomembranesClay LinersAquitardAquiferSubsurface Model

General Information

Model Title: Primary

Waste

Collection System

Geomembrane

Clay Liner

Aquitard

Aquifer

☒ Geomembrane

☒ Clay Liner

☒ Aquitard

☒ Aquifer

Laplace Transform Parameters

TAU: 7N: 11SIG: 0RNU: 1

Run Parameters

Time Units: yearDepth Units: mConcentration Units: mg/L

☐ Zero Negative Concentraions

Gauss Integration

☐ Fine☒ Normal☐ Wide☐ Select

Output Distances

+ AddX Delete

Distance	Units
0	m
500	m

Output Times

+ AddX Delete

Time	Units
10	year
50	year

The data entry for the General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, and Aquifer is described in the sections below. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[253]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[257].

4.3.2.1 General Data

To select the layers in the model and edit the general data click on the General tab on the left side of the model form.

Run | Save | SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | Aquitard | Aquifer | Subsurface Model

General Information

Model Title:

Waste	
Collection System	☒ Geomembrane
Geomembrane	☒ Clay Liner
Clay Liner	☒ Aquitard
Aquitard	☒ Aquifer
Aquifer	

Laplace Transform Parameters

TAU: N: SIG: RNU:

Run Parameters

Time Units: Depth Units: Concentration Units:

☐ Zero Negative Concentraions

Gauss Integration

☐ Fine ☒ Normal ☐ Wide ☐ Select

Output Distances

+ Add - Delete

Distance	Units
0	m
500	m

Output Times

+ Add - Delete

Time	Units
10	year
50	year

The following can be specified on this tab:

General Information

Model Title: This is the title of the model is used to describe the model, and may be up to 255 characters long.

Geomembrane: Check this box to include a primary geomembrane in the model. If this box is not checked the Geomembranes tab will not be present.

Clay Liner: Check this box to include a primary clay liner in the model. If this box is not checked the Clay Liners tab will not be present.

Aquitard: Check this box to include an aquitard in the model. If this box is not checked the Aquitard tab will not be present.

Aquifer: Check this box to include an aquifer in the model. If this box is not checked the Aquifer tab will not be present.

Laplace Transform Parameters, Gauss Integration and Run Parameters

The information specified for the Laplace Transform Parameters, Gauss Integration and Run Parameters is the same as described in the [General Data](#) section for a Normal Model.

4.3.2.2 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

RunSaveSaveAs

GeneralSource & Hydraulic HeadsGeomembranesClay LinersAquitardAquiferSubsurface Model

Source

Constant Concentration - Surface

Finite Mass - Surface

	Landfill	Units
Landfill Surface Width	1000	m
Landfill Base Width	1000	m
Initial Concentration	1000	mg/L
Waste Thickness	25	m
Waste Density	600	kg/m³
Percentage of Mass	0.2	
Infiltration	0	m/a

Hydraulic Heads

	Value	Units
Leachate Head on Primary Liner	0.3	m
Groudwater Level Relative to top of Aquifer	0	m

The following can be specified on this tab:

Source

Source Type: This option is used to specify the top boundary condition, it can be either Constant Concentration or Finite Mass

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Initial Concentration: This is the constant or initial concentration at the surfacel..

If the source type is Finite Mass the following data can also be edited:

Waste Thickness: This is the vertical thickness of the waste, and is used to calculate the mass of contaminant per unit area of waste.

Waste Density: This is the apparent density of the waste (i.e. mass of waste per unit volume of the landfill).

Percentage of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste).

Infiltration: The average infiltration through the landfill cover.

Hydraulic Heads

Leachate Head on Primary Liner: The leachate head above the primary liner.

Groundwater level relative to top of aquifer: The groundwater level relative to the top of the aquifer, or if no aquifer is present the hydraulic gradient in the liner.

4.3.2.3 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

The screenshot shows the 'Geomembrane' tab selected in the software interface. The 'Name' field is set to 'Primary Geomembrane'. Below the name field is a 'Change Symbol' button. A table displays the parameters for the geomembrane layer:

Parameter	Value	Units
Number of Sublayers	1	
Thickness	60	mil
Diffusion Coefficient	3E-5	m ² /a
Conductivity K	1E-12	m/s

The following data can be edited on this tab:

Name: This is the name of the geomembrane layer.

Symbol: This is the symbol used to draw the geomembrane. To change the symbol click on the Change Symbol button. The [Select Symbol](#)^[227] form will be displayed where you can change the bitmap library, bitmap, foreground color, background color, and fill size for the symbol.

Number of Sublayers: This is the number of sublayers for the geomembrane and is typically 1.

Thickness: This is the thickness of the geomembrane.

Diffusion Coefficient: This is the diffusion coefficient of the geomembrane. See Rowe et al (2004) for a discussion of this parameter and a table of typical values.

Equivalent K: This is the equivalent hydraulic conductivity of the geomembrane. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill. Note: that the use of an equivalent K is a device for convenience of calculation and in no way represents the true leakage mechanisms. We recommend that you use the leakage equations. See Rowe et al (2004) for a discussion of leakage equations.

4.3.2.4 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

	Value	Units
Number of Sublayers	10	
Thickness	1	m
Density	1.9	g/cm ³
Conductivity K	1E-9	m/s
Vertical Diffusion Coefficient	0.02	m ² /a
Horizontal Diffusion Coefficient	0.02	m ² /a
Distyribution Coefficient	0	mL/g
Porosity	0.3	

The following parameters can be edited on this tab:

Name: This is the name of the clay liner.

Symbol: This is the symbol used to draw the clay liner. To change the symbol click on the [Change Symbol](#)^[227] button.

Number of Sublayers: This is the number of sublayers to use for the liner. Typically, a value of 10 is used.

Thickness: This is the thickness of the clay liner.

Density: This is the density of the clay liner.

Conductivity K: This is the equivalent hydraulic conductivity of the clay liner. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill.

Vertical Diffusion Coefficient: This is the vertical coefficient of hydrodynamic dispersion for the clay liner.


Horizontal Diffusion Coefficient: This is the horizontal coefficient of hydrodynamic dispersion for the clay liner.

Distribution Coefficient: This is the distribution coefficient for the clay liner.

Porosity: This is the porosity of the clay liner.

4.3.2.5 Aquitard

To edit the aquitard data for a model click on the Aquitard tab on the left side of the model form. Note that this layer is an attenuation layer beneath the Clay liner. It is typically a layer with a hydraulic conductivity higher than that required for a clay liner (1×10^{-9} m/s) but less than an aquifer.



Run Save SaveAs

General Source & Hydraulic Heads Geomembranes Clay Liners **Aquitard** Aquifer Subsurface Model

Aquitard

Name:

 [Change Symbol](#)

	Value	Units
Number of Sublayers	10	
Thickness	1	m
Density	1.9	g/cm³
Conductivity K	1E-5	m/s
Vertical Diffusion Coefficient	0.02	m²/a
Horizontal Diffusion Coefficient	0.02	m²/a
Distribution Coefficient	0	mL/g
Porosity	0.3	

The following parameters can be edited on this tab:

Name: This is the name of the aquitard.

Symbol: This is the symbol used to draw the aquitard. To change the symbol click on the [Change Symbol](#) button.

Number of Sublayers: This is the number of sublayers to use for the aquitard. Typically, a value of 10 is used.

Thickness: This is the thickness of the aquitard.

Density: This is the dry density of the aquitard.

Conductivity K: This is the equivalent hydraulic conductivity of the aquitard. If you are unsure what the value of this is, it is recommended to use a leakage rate landfill.

Vertical Diffusion Coefficient: This is the vertical coefficient of hydrodynamic dispersion for the aquitard.

Horizontal Diffusion Coefficient: This is the horizontal coefficient of hydrodynamic dispersion for the aquitard.

Distribution Coefficient: This is the distribution coefficient for the aquitard.

Porosity: This is the porosity of the aquitard.

4.3.2.6 Aquifer

To edit the aquifer and outflow data for a model click on the Aquifer tab on the left side of the model form.

The screenshot displays the software interface for configuring an Aquifer and its Outflow. The top navigation bar includes tabs for General, Source & Hydraulic Heads, Geomembranes, Clay Liners, Aquitard, **Aquifer**, and Subsurface Model. The **Aquifer** tab is active, showing the following configuration:

- Name:** A text field containing "Aquifer".
- Change Symbol:** A button next to a small icon representing the aquifer.
- Thickness:** A table with a value of 1 and units of m.
- Porosity:** A table with a value of 0.3 and units of m/a.

Below the Aquifer configuration, the **Outflow** section is visible, containing two panels:

- Outflow in Aquifer:** A panel with a text description: "The minimum outflow velocity in the Aquifer that will fulfill the conditions of continuity of flow is: 28.8 m/a". Below this is a table showing the Outflow Velocity as 28.8 m/a.
- Calculated Results:** A panel showing the Darcy Velocity through the Primary Liner as 0.0288 m/a.

Aquifer

Name: This is the name of the aquifer.

Symbol: This is the symbol used to draw the aquifer. To change the symbol click on the [Change Symbol](#)  button.

Thickness: This is the thickness of the aquifer.

Porosity: The porosity of the aquifer.

Outflow

After this all of the information on the previous tabs has been entered the minimum horizontal outflow velocity in the aquifer will be calculated. You will then have the option of using this velocity or a higher velocity. In addition the calculated Darcy velocity and leachate head on the primary liner will be displayed.

4.3.3 Editing a Primary Leakage Rate Model

The Leakage Rate (Subtitle D) Landfill submenu is used to quickly enter data for a landfill that contains a leachate collection system, primary composite liner, and aquifer. This submenu uses a leakage rate calculated according to the method proposed by Giroud et. al. (1992), to determine the Darcy velocity through the composite liner. In this method the leakage rate through a composite liner will depend on the type and number of defects in the geomembrane, the leachate head on the liner, and the thickness and hydraulic conductivity of the compacted clay or geosynthetic clay liners (see Example 1). In addition the leakage rate due to permeation can also be considered, and is calculated according to the method proposed by Giroud and Bonaparte (1989).

If the model was created using the Primary Leakage Rate Landfill template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Geomembranes, Clay Liners, and Aquifer. In addition, there is a tab for the subsurface model.

Run
Save
SaveAs

General
Source & Hydraulic Heads
Geomembranes
Clay Liners
Aquitard
Aquifer
Subsurface Model

General Information

Model Title: Primary

Waste	
Collection System	☒ Geomembrane
Geomembrane	☒ Clay Liner
Clay Liner	☒ Aquitard
Aquitard	☒ Aquifer
Aquifer	

Laplace Transform Parameters

TAU: 7
N: 11
SIG: 0
RNU: 1

Run Parameters

Time Units: year
Depth Units: m
Concentration Units: mg/L

☐ Zero Negative Concentraions

Gauss Integration

☐ Fine
☒ Normal
☐ Wide
☐ Select

Output Distances

+ Add
X Delete

Distance	Units
0	m
500	m

Output Times

+ Add
X Delete

Time	Units
10	year
50	year

The data entry for the General data, Source & Hydraulic Heads, Clay Liners, Aquitard, and Aquifer is the same as for a [Primary Landfill Model](#)^[230] and described in the section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[253]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[257].

The only difference from the Primary Landfill Model is the properties for the geomembrane described in the section below.

4.3.3.1 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

Run | Save | SaveAs

General | Source & Hydraulic Heads | Geomembranes | Clay Liners | Aquifer | Subsurface Model

Geomembrane

Name: Primary Geomembrane

Change Symbol

Parameter	Value	Units
Number of Sublayers	1	
Thickness	60	mil
Diffusion Coefficient	3E-5	m²/a

Leakage Parameters

Contact: ☒ Good ☐ Poor

Hole Type: ☒ Circle ☐ Long

Permeation: ☒ Yes ☐ No

	Value	Units
Frequency	1	/acre
Hole Area	0.1	cm²

The following data can be edited on this tab:

Name: This is the name of the geomembrane layer.

Symbol: This is the symbol used to draw the geomembrane. To change the symbol click on the Change Symbol button. The [Select Symbol](#)^[227] form will be displayed where you can change the bitmap library, bitmap, foreground color, background color, and fill size for the symbol.

Number of Sublayers: This is the number of sublayers for the geomembrane and is typically 1.

Thickness: This is the thickness of the geomembrane.

Diffusion Coefficient: This is the diffusion coefficient of the geomembrane. See Rowe et al (2004) for a discussion of this parameter and a table of typical values.

Leakage Parameters

Contact: This is the contact (Good or Poor) between the Geomembrane and Compacted Clay or GCL,

Hole Type: This is the type of holes in the Geomembrane (circular or long and narrow). If the holes are circular the user will be required to enter the frequency and area of the holes, or if the holes are long and narrow the user will be required to specify the frequency, length, and width of the holes.

Permeation: Permeation through the geomembrane can be considered by selecting Yes. The leakage rate due to permeation will be added to the leakage rate due to defects.

According to Giroud and Bonaparte (1989) the leakage rate due to permeation (Q_g) is equal to the coefficient of migration (M_g) divided by the geomembrane thickness (T_g), i.e. $Q_g = M_g / T_g$. The coefficient of migration (M_g) may be calculated using the following equations:

$$M_g = C_1 \times _P_n \quad \text{if } _P < _P_{\text{plateau}}$$

$$M_g = M_{g\text{max}} \quad \text{if } _P > _P_{\text{plateau}}$$

where, C_1 is a coefficient (in these calculations assumed to be $1 \times 10^{-22} \text{ m}^4 \text{ Kg}^{-2} \text{ S}^3$), ΔP is the pressure difference (with ΔP plateau assumed to be 55 kPa), n is a dimensionless coefficient (in these calculations assumed to be 2), and M_{gmax} is assumed to be $3 \times 10^{-13} \text{ m}^2/\text{s}$. The pressure difference (ΔP) can be obtained using the relationship:

$$\Delta P = \Delta h \times e \times g$$

where Δh is the head difference across the geomembrane (which in these calculations is assumed to be the depth of water or leachate on top of the geomembrane), e is the density of the leachate or water (assumed to be water in these calculations), and g is the acceleration due to gravity.

4.3.4 Editing a Primary and Secondary Landfill Model

The Primary and Secondary Liner Landfill model is used to quickly enter a landfill that may contain a primary leachate collection system, primary composite liner, secondary leachate collection system, secondary composite liner, aquitard, and aquifer. In this option the composite liners can be composed of a geomembrane and/or compacted clay or GCL.

If the model was created using the Primary and Secondary Landfill template, the model form will display the model data on the left and the model output on the right. The model data can be entered in the tabs for General data, Source & Hydraulic Heads, Collection System, Geomembranes, Clay Liners, Aquitard, Aquifer, and Special Features. In addition, there is a tab for the subsurface model.

Run Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard Aquifer Subsurface Model

General Information

Model Title: Case 2: Landfill with composite primary and compacted clay secondary liners.

Waste	
Primary Collection System	☒ Primary Geomembrane
Primary Geomembrane	☒ Primary Clay Liner
Primary Clay Liner	☐ Secondary Geomembrane
Secondary Collection System	☒ Secondary Clay Liner
Secondary Clay Liner	☒ Aquitard
Aquitard	☒ Aquifer
Aquifer	

Laplace Transform Parameters

TAU: 7 N: 11 SIG: 0 RNU: 1

Run Parameters

Time Units: year Depth Units: m Concentration Units: mg/L

☐ Zero Negative Concentraions

Gauss Integration

☒ Fine ☐ Normal ☐ Wide ☐ Select

Output Distances

+ Add X Delete

Distance	Units
0	m
100	m

Output Times

+ Add X Delete

Time	Units
30	year
50	year
100	year
150	year
200	year

The data entry for the General data, Aquitard, and Aquifer is the same as for a [Primary Landfill Model](#)^[230] and described in the section. Based upon the model data a subsurface model is displayed on the Subsurface Model tab, this is the same for all templates and is described in the section [Displaying the Subsurface Model](#)^[253]. The control of the display of the model output is the same for all templates and is described in the section [Displaying Model Output](#)^[257].

The only difference from the Primary Landfill Model is the properties for the Source and Hydraulic Heads, Collection System, Geomembranes and Clay Liners described in the section below.

4.3.4.1 Source and Hydraulic Heads

To edit the source and hydraulic head data for a model click on the Source and Hydraulic Heads tab on the left side of the model form.

Run Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard Aquifer Subsurface Model

Source

☒ Constant Concentration - Surface
☐ Finite Mass - Surface

	Landfill	Units
Landfill Surface Width	200	m
Landfill Base Width	200	m
Initial Concentration	1500	mg/L

Hydraulic Heads

	Value	Units
Leachate Head on Primary Liner	0.3	m
Leachate Head on Secondary Liner	0.3	m
Groundwater Level Relative to top of Aquifer	3	m

The source parameters are the same as those for a Primary Landfill Model and are described in that [section](#) ²³³.

Source

Source Type: This option is used to specify the top boundary condition, it can be either Constant Concentration or Finite Mass

Landfill Surface Width: This is the width of the ground surface or top of the landfill, in the direction of groundwater flow.

Landfill Base Width: The landfill may have a greater width at the surface than at the base, to take into consideration the effect of side-slopes. This is the width of the landfill at the base, in the direction of groundwater flow.

Initial Concentration: This is the constant or initial concentration at the surfacel..

If the source type is Finite Mass the following data can also be edited:

Waste Thickness: This is the vertical thickness of the waste, and is used to calculate the mass of contaminant per unit area of waste.

Waste Density: This is the apparent density of the waste (i.e. mass of waste per unit volume of the landfill).

Percentage of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste (eg. mass of chloride in waste/total mass of waste).

Infiltration: The average infiltration through the landfill cover.

Hydraulic Heads

Leachate Head on Primary Liner: The leachate head above the primary liner.

Leachate Head on Secondary Liner: The leachate head above the secondary liner.

Groundwater level relative to top of aquifer: The groundwater level relative to the top of the aquifer, or if no aquifer is present the hydraulic gradient in the liner.

4.3.4.2 Collection System

To edit the collection system data for a model click on the Collection System tab on the left side of the model form.

	Value	Units
Number of Sublayers	1	
Thickness	0.3	m
Density	1.9	g/cm ³
Vertical Diffusion Coefficient	100	m ² /a
Horizontal Diffusion Coefficient	100	m ² /a
Distribution Coefficient	0	mL/g
Porosity	0.3	

The following parameters can be edited on this tab:

Name: This is the name of the collection system.

Symbol: This is the symbol used to draw the collection system. To change the symbol click on the [Change Symbol](#) button.

Number of Sublayers: This is the number of sublayers to use for the collection system. Typically, a value of 1 is used.

Thickness: This is the thickness of the collection system.

Density: This is the density of the collection system.

Vertical Diffusion Coefficient: This is the vertical coefficient of hydrodynamic dispersion for the collection system.

Horizontal Diffusion Coefficient: This is the horizontal coefficient of hydrodynamic dispersion for the collection system.

Distribution Coefficient: This is the distribution coefficient for the collection system.

Porosity: This is the porosity of the collection system.

4.3.4.3 Geomembranes

To edit the geomembrane data for a model click on the Geomembranes tab on the left side of the model form.

Run
Save
SaveAs

General
Source & Hydraulic Heads
Collection System
Geomembranes
Clay Liners
Aquitard
Aquifer
Subsurface Model

Primary Geomembrane

Name: Primary Geomembrane

Change Symbol

Parameter	Value	Units
Number of Sublayers	1	
Thickness	60	mil
Diffusion Coefficient	3E-5	m ² /a
Conductivity K	2.33E-15	m/s

Secondary Geomembrane

Name:

Change Symbol

	Value	Units
Number of Sublayers	1700912	
Thickness	3.60538982959653	
Diffusion Coefficient	1.64171341608249	
Conductivity K	2.89283313933516	

The top of the form is used to specify the data for the primary geomembrane and the bottom of the form is used to specify the data for the secondary geomembrane. The data entered for each geomembrane is the same as that for a Primary Landfill model and is described in that [section](#)^[234].

4.3.4.4 Clay Liners

To edit the clay liner data for a model click on the Clay Liners tab on the left side of the model form.

Run Save SaveAs

General Source & Hydraulic Heads Collection System Geomembranes Clay Liners Aquitard Aquifer Subsurface Model

Primary Clay Liner

Name:



	Value	Units
Number of Sublayers	10	
Thickness	0.9	m
Density	1.9	g/cm ³
Conductivity K	1E-7	cm/s
Vertical Diffusion Coefficient	0.02	m ² /a
Horizontal Diffusion Coefficient	0.02	m ² /a
Distribution Coefficient	0.5	mL/g
Porosity	0.35	

Secondary Clay Liner

Name:



	Value	Units
Number of Sublayers	10	
Thickness	0.9	m
Density	1.9	g/cm ³
Conductivity K	1E-9	m/s
Vertical Diffusion Coefficient	0.02	m ² /a
Horizontal Diffusion Coefficient	0.02	m ² /a
Distribution Coefficient	0.5	mL/g
Porosity	0.35	

The top of the form is used to specify the data for the primary clay liner and the bottom of the form is used to specify the data for the secondary clay liner. The data entered for each clay liner is the same as that for a Primary Landfill model and is described in that [section](#) ^[235].

4.3.5 Editing Special Features

There are several special features that can be added to a model; such as:

- Initial Concentration Profile,
- Maximum Thickness,
- Non-linear Sorption,
- Passive Sink,
- Print Mass into Base,
- Radioactive/Biological Decay,
- Variable Properties,
- Monte Carlo Simulation,
- Sensitivity Analysis.

These features are described in the sections below.

4.3.5.1 Passive Sink

This special feature allows you to incorporate one or more passive sinks or a phase change with depth into a model. A passive sink is a depth interval in which there is a horizontal velocity which will have the effect of removing contaminant from beneath the landfill. Typically, a passive sink is used to represent intermediate aquifers or secondary leachate collection systems [Rowe and Fraser, 1993].

In the Passive Sink feature the model is divided into a number of depth intervals, and in each interval the user can specify the Darcy velocity, rate of removal, rate of inflow, and phase parameter. The set of depth intervals should cover the entire thickness of the model, between the top and bottom boundary. If a fixed outflow bottom boundary is used, the depth interval should stop at the top of the base aquifer (i.e., it should not include the base aquifer).

Note: When using both the Time Varying Properties option and the Passive Sink option, the passive sink information is specified in the [Time Varying Properties](#) ^[249] special feature.

WARNING: This option should only be used by someone with the hydrogeologic and engineering background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of the physical situation.

THIS OPTION SHOULD NOT BE USED FOR AN IMPORTANT PROJECT WITHOUT THE GUIDANCE OF THE PROGRAM DEVELOPERS.

To add this feature check the Passive Sink box on the Special Features tab. The Passive Sink form will be shown on the right side of the tab.

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Darcy Velocity	Darcy Velocity Units	Rate of Removal	Rate of Removal Units	Phase Parameter
0	m	0.6	m	0.003	m/a	0	m/a	1
0.6	m	0.8	m	0.003	m/a	0	m/a	0.1
0.8	m	0.9	m	0.003	m/a	15	m/a	1
0.9	m	1.65	m	0	m/a	0	m/a	1

The following can be specified:

Inflow Rate: This option is used to specify the inflow rate with depth.

Phase Change: This option is used to incorporate a phase change with depth.

Landfill Length: If the is a normal model type and the bottom boundary is not fixed outflow, the landfill length needs to be specified when using a passive sink. This is the landfill length in the direction of groundwater flow.

Landfill Width: If the is a normal model type and the bottom boundary is not fixed outflow, the landfill width needs to be specified when using a passive sink.

Interval Type: The depth intervals can either be specified or the layer depth intervals on the Layers Tab can be used. If the depth intervals are being specified there are buttons at the top of the table to add and delete depth intervals.

For each depth interval the following is specified:

Top Depth: This is the top depth of the depth interval. If the Interval Type is Layers, this is filled in by the program. The set of depth intervals should cover the entire thickness of the model.

Bottom Depth: This is the bottom depth of the depth interval. If the Interval Type is Layers, this is filled in by the program.

Darcy Velocity: This is the Darcy Velocity for the depth interval. A negative value indicates an upward flow or flow in towards the source.

Rate of Removal: This is the rate of removal of contaminant by the passive sink. According to the principle of continuity of flow the rate of removal should be equal to:

$$R_r = (v_{a1} - v_{a2}) L / h$$

where,

R_r = Rate of removal or outflow velocity (flow per unit area per unit time),

v_{a1} = Darcy velocity above the interval,

v_{a2} = Darcy velocity below the interval,

L = Landfill length,

h = thickness of the layer from which fluid is being removed.

An example would be a 600 m (L) long landfill with a 0.3 m thick (h) secondary leachate collection system. The Darcy velocity above the secondary leachate collection system is 0.01 m/a (v_{a1}), and below is 0.003 m/a (v_{a2}). The rate of removal is then:

$$R_r = (0.01 - 0.003) * 600 / 0.3 = 14 \text{ m}^3/\text{a}/\text{m}^2 = 14 \text{ m/a}$$

Rate of Inflow: If the Inflow Rate option has been selected on the previous tab, the Rate of Inflow field will be shown. This is the rate of inflow into the passive sink.

Phase Parameter: If the Phase Change option has been selected on the previous tab, the Phase Parameter field will be shown. This is a dimensionless phase parameter as discussed in the [Introduction](#)^[21].

4.3.5.2 Time Varying Properties

The program is normally capable of determining the concentrations any time without determining them at previous times. However, if there is a complex source concentration history or a change in velocities or layer properties with time then it is necessary to sequentially follow this history. For example, the program can model a working landfill which experiences progressive failure of the leachate collection system and resulting buildup in the leachate mound (i.e., an increase in Darcy velocity) over a period of years [Rowe and Fraser, 1993a, 1993b].

This option allows the user to vary the source concentration, reference height of leachate, volume of leachate collected, rate of concentration increase, Darcy velocity, outflow velocity, dispersivity, layer properties, and decay rate with time. The Variable Properties option implements a “time-marching” scheme, where the program stops and restarts the solution every time parameters are changed. In the basic mode of operation the accuracy of the solution is independent of the number of sublayers. However, if the Variable Properties option is used then the accuracy of this procedure depends on the number of sublayers used in the model, and the user should experiment with the number of sublayers to ensure that the results obtained are sufficiently accurate (see Examples 10, 11, and 15).

WARNING: This option should only be used by someone with the hydrogeologic and engineering background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of the physical situation.

THIS OPTION SHOULD NOT BE USED FOR A PROJECT OF IMPORTANCE WITHOUT THE GUIDANCE OF THE PROGRAM DEVELOPERS.

To add this feature check the Time Varying Properties box on the Special Features tab. Time Varying Properties form will be shown on the right side of the tab.

General | Layers | Boundaries | Special Features | Subsurface Model

☐ Initial Concentration Profile
☐ Maximum Sublayer Thickness
☐ Non-linear Sorption
☒ Passive Sink
☐ Print Mass in Base
☐ Radioactive/Biological Decay
☒ Time Varying Properties
☐ Monte Carlo Simulation
☐ Sensitivity Analysis

Time Varying Properties

☒ Properties Increment within Periods ☒ Passive Sink
☒ Variable Layer Properties ☒ Phase Change
☒ Variable Decay ☒ Inflow

Warning: In the Variable Properties option the accuracy of the calculations will depend on the number of sublayers.

+ Add X Delete | First Prev Next Last

Property	Value	Units	Increment
Number of	1		
Start Time:	0	year	
End Time:	10	year	
Source	1	mg/L	0
Darcy Velocity:	.05	m/a	0
Dispersivity:	0	m	
Base Velocity:	2	m/a	0
Rate for Conc.:	0	mg/L/yr	
Volume Collected:	.3	m/a	0
Finite Mass			
Waste Props.			

Increment: 1 | First Prev Next Last

☒ Source Decay Half-Life: 1000 year ☒ Base Decay Half-Life: 1000 year

Interval Type ☒ Depth Intervals ☐ Layers

+ Add X Delete

Top Depth	Top Depth Units	Bottom Depth	Bottom Depth Units	Darcy Velocity	Darcy Velocity Units	Rate of Removal	Rate of Removal Units	Rate of Inflow	Rate of Inflow Units	Phase Parameter	Diffusion Coefficient	Diffusion Coefficient Units	Porosity	Density	Density Units	Distribution Coefficient	Distribution Coefficient Units	Half Life	Half Life Units
0	m	1	m	0.01	m/a	0	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year
1	m	1.3	m	0.01	m/a	6.67	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year
1.3	m	3.3	m	0	m/a	0	m/a	0	m/a	0	0	m ² /a	0	0	g/cm ³	0	m ³ /kg	0	year

The following options can be selected at the top of this form:

Properties Increment within Periods: This allows the user to choose whether the properties increment within time periods or are constant within time groups. If the properties increment within time periods, the user can specify the number of increments and the increment size for each time period. For example, if

the Darcy velocity increased linearly from .01 m/a to .11 m/a between 10 and 20 years, the user could specify 10 increments and a Darcy velocity increment of .01. If however, the properties remain constant between time periods the user need only specify the values of the properties. For example, if the Darcy velocity was .01 m/a between 0 and 10 years and then .02 m/a between 11 and 30 years, the user could specify two groups the first from 0 to 10 years with a Darcy velocity of .01 m/a and the second from 11 to 30 years with a Darcy velocity of .02 m/a.

Variable Layer Properties: This option can be used to vary both source and layer properties with time. The model is divided into a number of depth intervals and in each interval the user can specify the Diffusion Coefficient (or Coefficient of Hydrodynamic Dispersion), Porosity, Density, and Distribution Coefficient. If this option is selected the Layer Data table will be displayed as described below.

Variable Decay: This option is used to vary the radioactive or biological decay with time. The source, base, and depth interval decay rates can be varied. If this option is selected the Layer Data table will be displayed as described below.

Passive Sink: Check this box if the model contains a passive sink as well as time varying properties. The Darcy Velocity and Rate of Removal can be specified for each depth interval in the Layer Data table as described below.

Note: When using both the Variable Properties option and the Passive Sink option, the Darcy velocity used is the product of the Darcy velocity specified in both of the options. For clarity, it is generally recommended the user specify the Darcy velocity on the Time Period Data table as 1, and vary the Passive Sink Darcy velocity with time.

Phase Change: This option is used to incorporate a phase change parameter for each depth interval in the Layer Data table as described below.

Inflow Rate: This option is used to specify the Rate of Inflow for each depth interval in the Layer Data table as described below.

Time Period Data

This table is used to specify the data for each time period. At the top of the table there are buttons to add and delete a time group; as well as to navigate between time periods.

The following can be specified for each time period:

Number of Increments: If the Properties Increment within Periods this is the number of increments to use in sub-dividing the time period. The concentrations will be calculated for the times at the end of each increment, if there is only one increment specified for the time period will be calculated at the end time. For example, if the time period started at 0 years and ended at 20 years and the number of increments was 4, concentrations would be calculated at 5, 10, 15, and 20 years.

Start Time: This is the start time of the first time period, and is the time at which calculations begin (usually zero). The start time is only specified for the first time period.

End Time: This is the end time of the time period, and will be the start time of the next time period.

Source Concentration: This is the source concentration at the beginning of the time period. The calculated concentration from the end of the last period will be used if the user specifies a negative value for the source concentration. For the first time period the source concentration does not decrease until

the end of the time period. To model a landfill with a depleting source, the concentration should be set for the first time period and then -1 should be used for the following time periods.

Note: The actual source concentration will vary with time due to the migration of contaminant into the soil and the collection of leachate. This is automatically handled by the program.

Source Concentration Increment: This is the increment size by which to increase the source concentration for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected. If no additional mass is being added to the source then this should be zero.

Darcy Velocity: This is the Darcy velocity at the beginning of this time period. If an increment in Darcy velocity is specified, it will be added to this velocity to get the velocity at the start of the next increment.

Note: When using both the Variable Properties option and the Passive Sink option together, the Darcy velocity used is the product of the Darcy velocity specified in both of the options. For clarity, it is recommended the user specify the Darcy velocity on the Variable Properties option as 1, and vary the Passive Sink Darcy velocity.

Darcy Velocity Increment: This is the increment size by which to increase the Darcy velocity for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected.

Dispersivity: This is the dispersivity for the model. When the Variable Properties option is used the dispersivity (α) and diffusion coefficient (D_{md}) can be specified independently.

Base Velocity: If the bottom boundary condition is fixed outflow, the user can specify the base horizontal Darcy velocity at the down-gradient edge of the landfill for the beginning of the time period.

Base Velocity Increment: This is the increment size by which to increase the base velocity for each increment in the time period. This field will only be shown if the Properties Increment within Periods option has been selected.

Rate for Conc. If the top boundary condition is finite mass, the user can specify the rate at which the source concentration changes per year. For the case where there is no additional mass added or removed from the landfill this value should be set at zero.

Volume Collected: When the top boundary condition is finite mass, the user needs to specify the Volume of Leachate Collected for the beginning of the time period.

Volume Collected Increment: This is the increment by which to increase the volume of leachate collected during each time increment. If the infiltration through the cover of the landfill is constant, the increment in the volume of leachate collected should be equal and of opposite sign to the increment in the Darcy velocity. This field will only be shown if the Properties Increment within Periods option has been selected.

Finite Mass Specification: If the top boundary condition is finite mass, the user can specify either the Waste Properties or the Reference Height of Leachate.

Thickness of Waste: This is the vertical thickness of the waste for the time period, and is used to calculate the mass of contaminant per unit area of waste.

Waste Density: This is the apparent density of the waste for the time period (i.e. mass of waste per unit volume of the landfill).

Proportion of Mass: The available (leachable) mass of contaminant in the waste per unit mass of waste for the time period (eg. mass of chloride in waste/total mass of waste).

Water Content: This is the volumetric water content of the waste for the time period.

Conversion Rate Half-Life: The generation coefficient is calculated based on the conversion rate half-life K , such that $\lambda = \ln 2 / K$. A value of $\lambda = 0$ implies no generation of concentration with time. In the program $\lambda = 0$ is obtained by specifying $K = 0$ (this is the default case).

Reference Height of Leachate: The reference height of leachate represents the volume of leachate that would contain the total leachable mass of the contaminant of interest at the initial source concentration. Thus, the reference height (H_r) is equal to the mass of contaminant (M) per unit area divided by the initial source concentration (c_o) (i.e. $H_r = M/c_o$).

Layer Data

If the Variable Layer Properties, Variable Decay, or Passive Sink options are selected the layer data for each time period and increment should be specified in the Layer Data table. This table shows the layer data for the currently selected time period and increment. If the Properties Increment within Periods option is selected, the Increment within the time period can be changed using the buttons at the top of the table.

If the Variable Decay option is selected the following can be specified for each time period and increment.

Source Decay: This allows the user to select whether first order decay of contaminant will be modelled in the source for this time period. If selected the user will be asked to specify the half-life in the source. If not selected the half-life in the source is assumed to be infinite (i.e., no first order decay).

Base Decay: This allows the user to select whether first order decay will be modelled in the base of the deposit for this time period (eg. an underlying aquifer). If selected the user will be asked to specify the half-life in the base. If not selected the half-life in the base is assumed to be infinite (i.e., no first order decay).

Interval Type: The layer data for each time period and increment should cover the full depth of the model. The depth intervals can either be specified or the layer depth intervals on the Layers Tab can be used. If the depth intervals are being specified there are buttons at the top of the table to add and delete depth intervals.

Depending on the options selected the following can be specified:

Top Depth: This is the top depth of the depth interval for this time period and increment. The set of depth intervals should cover the entire thickness of the model.

Bottom Depth: This is the bottom depth of the depth interval.

Darcy Velocity: If the Passive Sink option is selected, this is the Darcy Velocity for the depth interval. A negative value indicates an upward flow or flow in towards the source. Note: When using both the Variable Properties option and the Passive Sink option, the Darcy velocity used is the product of the

Darcy velocity specified in both of the options. For clarity, it is recommended the user specify the Darcy velocity on the Time Period as 1, and vary it here.

Rate of Removal: If the Passive Sink option is selected, this is the rate of removal of contaminant by the passive sink. According to the principle of continuity of flow the rate of removal should be equal to:

$$R_r = (v_{a1} - v_{a2}) L / h$$

where,

R_r = Rate of removal or outflow velocity (flow per unit area per unit time),

v_{a1} = Darcy velocity above the interval,

v_{a2} = Darcy velocity below the interval,

L = Landfill length,

h = thickness of the layer from which fluid is being removed.

An example would be a 600 m (L) long landfill with a 0.3 m thick (h) secondary leachate collection system. The Darcy velocity above the secondary leachate collection system is 0.01 m/a (v_{a1}), and below is 0.003 m/a (v_{a2}). The rate of removal is then:

$$R_r = (0.01 - 0.003) * 600 / 0.3 = 14 \text{ m}^3/\text{a}/\text{m}^2 = 14 \text{ m/a}$$

Rate of Inflow: If the Inflow Rate option has been selected on the previous tab, the Rate of Inflow field will be shown. This is the rate of inflow into the passive sink.

Phase Parameter: If the Phase Change option has been selected on the previous tab, the Phase Parameter field will be shown. This is a dimensionless phase parameter as discussed in the [Introduction](#)^[21].

Diffusion Coefficient: If the Variable Layer Properties is selected, this is the diffusion coefficient for the depth interval.

Porosity: If the Variable Layer Properties is selected, this is the porosity for the depth interval. It must be greater than 0 and less than or equal to 1. If the interval is being used to represent a geomembrane the porosity should be set to 1.


Density: If the Variable Layer Properties is selected, this dry density of the depth interval and time period.

Distribution Coefficient: If the Variable Layer Properties is selected, this is the distribution coefficient for the depth interval and time period. In the basic mode (ie. where Langmuir Non-linear sorption and Freundlich Non-linear sorption have not been selected) the sorption-desorption of a conservative species of contaminant is assumed to be linear.

Half-Life: If the Variable Decay option is selected, this is the half-life for the depth interval.

4.3.6 Displaying the Subsurface Model


When a model has been created a representation of the model will be displayed on the Subsurface Model tab.



At the top of the tab there are buttons to adjust the options for the display and to print it to the default printer.

4.3.6.1 Subsurface Model Options

When the Options button is pressed, the Subsurface Model Options form is displayed.



The dialog box titled "Subsurface Model Options" contains the following elements:

- A checked checkbox labeled "Draw text leaders".
- Two input fields: "Width (pixels):" with the value "800" and "Height (pixels):" with the value "800".
- Two buttons with pencil icons: "Leader Line Style" and "Layer Line Style", each followed by a small empty text box.
- Two large buttons: "Model Title Font" and "Model Text Font".
- A footer bar with three buttons: "OK" (with a green checkmark icon), "Cancel" (with a red X icon), and "Help" (with a blue question mark icon).

The following can be edited on this form:

Width: This is the width of the model image in pixels.

Height: This is the height of the model image in pixels.

Draw text leaders: Check this box to draw leader lines from the model to the text (layer names).

Leader Line Style: Press this button to adjust the line style for the text leaders.

Layer Line Style: Press this button to adjust the line style for the layers.

Model Title Font: Press this button to adjust the font for the model title.

Model Text Font: Press this button to adjust the font for the text.

4.4 Running a Model



After the data for the model has been entered, the model can be run to calculate the concentrations with time and depth. To run a model click on the Run button at the top of the form or the F9 key..

The results of the model will be displayed on the two tabs on the right side of the form as described in the section [Displaying Model Output](#)^[257].

4.5 Displaying Model Output

After a model has been run, the results can be displayed in a variety of [graphs \(charts\)](#)²⁵⁹ or a [text listing](#)²⁵⁸ on the two tabs on the right side of the form.

4.5.1 Displaying Model Listing

A text listing of the model data and output is displayed on the List tab.

MIGRATEv10

Version 10.00
Copyright (c) 2025
GAEA Technologies Ltd., R.K. Rowe and J.R. Booker

#VAR Case 12: Two Landfills - Different Source Histories

Variable Properties with Time

Group	Start Time	End Time	Increments
1	0 year	20 year	1
2	20 year	22 year	1
3	22 year	24 year	1
4	24 year	26 year	1
5	26 year	28 year	1
6	28 year	30 year	1
7	30 year	40 year	1
8	40 year	100 year	2

Time Group 1

Layer Properties

Layer	Thickness	Sublayers	Dry Density	Porosity	Distribution Coefficient	Half-Life
Layer 1	1	2	1.9 g/cm ³	0.35	0 mL/g	0 year
Layer 2	2	4	1.9 g/cm ³	0.4	0 mL/g	0 year

Layer	Vertical Diffusion	Horizontal Diffusion	Vertical Velocity	Horizontal Velocity	Sink Removal	Concentration
Layer 1	0.019 m ² /a	0.019 m ² /a	0.008 m/a	0 m/a	0 m/a	0 mg/L
Layer 2	0.015 m ² /a	0.015 m ² /a	0.008 m/a	0 m/a	0 m/a	0 mg/L

Boundary Conditions

Finite Mass Top Boundary


	Landfill 1	Landfill 2
Offset	150 m	650 m
Surface Width	300 m	600 m
Base Width	280 m	580 m
Initial Concentration	1500 mg/L	0 mg/L
Source Half-Life	0 year	0 year
Waste Thickness	15 m	0 m
Waste Density	600 kg/m ³	600 kg/m ³

At the top of this tab, the Options button can be used to adjust the format of the listing. The initial format settings are specified in the template used for the model. The use of this form is described in the [Editing Listing Format and Options](#) ²⁹⁴ for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

Also at the top of the form is a toolbar for editing the selected text, saving the listing, and printing the listing.

4.5.2 Displaying Charts

The [chart type](#)²⁶⁰ to be displayed can be selected from the combo box at the top of the Graph tab. Also at the top of the Graph tab are buttons to Edit the chart format, adjust the chart Options, Print the chart, and export the chart data. These buttons are described in the sections below.



4.5.2.1 Chart Types


If the model did not use the Monte Carlo Simulation or Sensitivity Analysis special features these charts can be displayed:

- [Depth vs Concentration](#)²⁶¹
- [Concentration vs Time](#)²⁶²
- [Concentration vs Distance](#)²⁶³
- [Mass vs Time](#)²⁶⁴

- [Depth vs Time](#) ²⁶⁴
- Depth vs Distance


This chart will display the depth versus concentration for each of the times and distances specified in the model.

The curve for each time and distance can be turned on and off using the check boxes in the legend. In addition, at the top of the graph the time and distance can be selected. The arrows beside the time and distance can be used to select the next or previous time or distance.




This chart will display the concentration versus time for each of the distances specified in the model.

The curve for each distance and depth can be turned on and off using the check boxes in the legend. In addition, at the top of the graph the distance can be selected. The arrows beside the distance can be used to select the next or previous distance.




This chart will display the concentration versus distance for each of the times specified in the model.

The curve for each time and depth can be turned on and off using the check boxes in the legend. In addition, at the top of the graph the time can be selected. The arrows beside the time can be used to select the next or previous time..




This chart will display the mass versus time into the soil and into the base..




This chart will display the depth versus time for each distance as colored grid, with the concentration determining the color.

At the top of the graph the distance can be selected. The arrows beside the distance can be used to select the next or previous distance. The integration and colors used to represent the concentration can be specified in the [Grid Options](#) ²⁶⁸.



This chart will display the depth versus distance for each time as colored grid, with the concentration determining the color.


At the top of the graph the time can be selected. The arrows beside the time can be used to select the next or previous time. The integration and colors used to represent the concentration can be specified in the [Grid Options](#) ²⁶⁸.



4.5.2.2 Editing Chart Format




The format of the chart can be edited by clicking on the Edit button on the Graph tab. The Editing Chart form will be displayed.




This form shows a tree view on the left containing the various sections of the chart that can be formatted. On the right are the options for the selected section. The initial format settings are specified in the template used for the model.

The use of this form is described in the [Editing Chart Formatting](#)²⁹⁵ for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

4.5.2.3 Editing Chart Line Options



If the chart type is not Concentration vs Depth vs Time or Depth vs Time, the chart is displayed as series of lines. The line options can be edited by pressing the Options button on the Graph tab. The Chart Options form will be displayed.




The Chart Options dialog box has a blue title bar and contains the following elements:

- Line Width:** A numeric input field set to 2.
- Show Data Values:** An unchecked checkbox.
- Line Colors:** A table with 12 rows, each representing a line number and its corresponding color.
- Buttons:** OK (green checkmark), Cancel (red X), and Help (question mark).


Line #	Color
1	Blue
2	Dark Red
3	Green
4	Red
5	Blue
6	Magenta
7	Yellow
8	Teal
9	Bright Green
10	Black
11	Light Grey
12	Dark Grey

The initial options are specified in the template used for the model. The use of this form is described in the [Editing Chart Line Options](#)^[304] for templates. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

4.5.2.4 Editing Chart Grid Options



If the chart type is Depth vs Time or Depth vs Distance, the chart is displayed as a grid and the grid options can be edited by pressing the Options button on the Graph tab. The Chart Options form will be displayed.



The image shows a 'Chart Options' dialog box with a light blue header. It contains several settings: 'Interpolate Data' is checked; 'Number of Interpolations' is a spinner box set to 2; 'Equalize Colors' is checked; 'Max. Color' is a dropdown menu showing 'Red'; 'Number of Steps' is a spinner box set to 20; and 'Grid Visible' is unchecked. At the bottom, there are three buttons: 'OK' with a green checkmark, 'Cancel' with a red X, and 'Help' with a blue question mark.

The initial options are specified in the template used for the model. Any changes that are done when editing a model will not be saved. To save the changes, the changes need to be made to the template.

The following can be edited on this form:

Interpolate Data: Check to interpolate the data for the grid. This will interpolate between data values to create a finer grid mesh.

Number of Interpolations: This is used to specify the number of interpolations between data values. The higher the number of interpolations the finer the grid mesh. Generally, a value between 2 and 4 is recommended.

Equalize Colors: Check this to equalize the colors so that the maximum color is the same concentration for all the times and distances..

Max. Color: This is used to select the color for the maximum concentration.

Number of Steps: This is the number of steps (intervals) in color between the start and end colors.


Grid Visible: Check to make the grid lines visible.

Grid Color: This is used to select the color of the grid lines.

4.5.2.5 Printing the Chart




To preview and print a chart click on the Print button at the top of the tab. The Chart Preview form will be displayed.




Using this form the print settings can be adjusted and the chart printed.

4.5.2.6 Exporting Chart Data



The chart can be exported by clicking on the Export button at the top of the tab. The Export Dialog form will be displayed.



Using this form the chart can be exported to a bitmap or metafile. It is not recommended to use this form to export the data, the [Export Output Data to Excel](#)^[272] function should be used instead.

4.6 Exporting to Excel

The output data from a model can be exported to an Excel file by selecting the Excel tab. The output data can be listed all on one sheet or have one sheet for each time. The times and distances can be displayed just for the first depth or all depths.

To export the data to an Excel file click on the Export to Excel button. You will then be prompted to specify the file name of the Excel file. After the data has been exported you will have the option to open it in Excel. The file is stored in "xlsx" format.

List Graph Excel							
Sheets/Time		Time Display		Distance Display		 Export to Excel	
☒ All times on one sheet		☒ First time only		☒ First distance only			
☐ One sheet per time		☐ All times		☐ All distances			
	A	B	C	D	E	F	G
1	Time	Distance	Depth	Concentration			
2	(year)	(m)	(m)	(mg/L)			
3	10	0	0	9.957E-01			
4			0.5	2.625E-01			
5			1	2.525E-02			
6			1.5	7.932E-04			
7			2	7.715E-06			
8			2.5	2.260E-08			
9			3	1.905E-11			
10			3.5	4.581E-14			
11			4	0.000E+00			
12		100	0	4.996E-01			
13			0.5	1.317E-01			
14			1	1.266E-02			
15			1.5	3.978E-04			
16			2	3.869E-06			
17			2.5	1.133E-08			
18			3	9.553E-12			
19			3.5	2.300E-14			
20			4	0.000E+00			
21	50	0	0	9.957E-01			
22			0.5	6.149E-01			
23			1	3.163E-01			
24			1.5	1.332E-01			
25			2	4.538E-02			
26			2.5	1.239E-02			
27			3	2.693E-03			
28			3.5	4.574E-04			
29			4	0.000E+00			
30		100	0	4.996E-01			
31			0.5	3.083E-01			
32			1	1.586E-01			
33			1.5	6.677E-02			
34			2	2.274E-02			
35			2.5	6.207E-03			
36			3	1.349E-03			

4.7 Exporting to a Pollute Model

The Migrate model can be converted and saved as a Pollute model by going to [File > Export > to Pollute Model](#). After the model has been converted you will need to specify a unique name for the Pollute model.

4.8 Importing a MIGRATEv9 Model


A MIGRATEv9 model can be imported by selecting File > Import > MIGRATEv9 Model,. After the file has been specified the model will be imported in to the current project. To import a model a project must be open and no model can be opened at the time.

4.9 Importing Output Data


In addition to the calculated results of the model, imported output data can also be displayed on the concentration vs depth and concentration vs time charts. This imported data can be from other models, experimental results, or theoretical results. The imported data can be extracted from an Excel file, other models in the project, or created and entered directly. After the imported data has been entered in can be edited or deleted.

4.9.1 Importing Other Model Output Data


Output data from a different model in the project can be imported to compare the results of two different models. To import this data select *File > Import > Other Model Output Data*. The Select Pollute Model form on the will be displayed.



After the model has been selected, a list of times from the model will be displayed. Select the time to import then click the Ok button.



After the time has been selected, you will be asked to provide a name for the imported dataset.



The data will then be imported and the name will appear in the chart legend. The imported data will only show up in charts and will not be displayed in the listing.

4.9.2 Importing Output Data from Excel

To import the data from an Excel file select File > Import > Output Data from Excel File. You will then be asked to select the file to import.

Name: diff

Time Units: year

Depth Units: in

Concentration Units: mg/L

+ Add X Delete

Time	Distance	Depth	Concentration
+All!A3	+All!B3:B11	+All!C3:C11	+All!D3:D11

A	B	C	D
Time	Distance	Depth	Concentration
(year)	(m)	(m)	(mg/L)
1			
2			
3	10	0	0 9.957E-01
4	10	0	0.5 2.625E-01
5	10	0	1 2.525E-02
6	10	0	1.5 7.932E-04
7	10	0	2 7.715E-06
8	10	0	2.5 2.260E-08
9	10	0	3 1.905E-11
10	10	0	3.5 4.580E-14
11	10	0	4 -2.036E-16
12	10	100	0 4.996E-01
13	10	100	0.5 1.317E-01
14	10	100	1 1.266E-02
15	10	100	1.5 3.978E-04
16	10	100	2 3.869E-06
17	10	100	2.5 1.133E-08
18	10	100	3 9.553E-12
19	10	100	3.5 2.300E-14
20	10	100	4 -1.892E-16
21	50	0	0 9.957E-01
22	50	0	0.5 6.149E-01
23	50	0	1 3.163E-01
24	50	0	1.5 1.332E-01
25	50	0	2 4.538E-02
26	50	0	2.5 1.239E-02
27	50	0	3 2.693E-03
28	50	0	3.5 4.576E-04

Import Cancel Help

After the file has been selected, the Import Excel Data form will be displayed. On the right of this form is the Excel sheets from the file and on the left of the form the following can be specified:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.

Import Table

The data to be imported from the Excel sheets on the right must be specified in the Import Table. For each time to be imported the range of cells for the distance, depth and concentration must be selected. At the top of the Import Table there are buttons to Add and Delete a time.

The time can be selected by first selecting the time cell in the Import Table and then double clicking on the time in sheets on the right side of the form. After a time has been selected the range of cells for the distance, depth and concentration can be specified by first clicking on the cell in the Import Table, then selecting the first cell in the sheets on the right side of the form and while holding down the left mouse button selecting the last cell in the range. There should be the same number of distances, depths, and concentrations for all the times.

After all of the data to be imported has been specified in the Import Table, press the Import button to import the data.

4.9.3 Creating an Imported Dataset

Data can also be imported into the model by creating a dataset and entering the data. To create a new data select *File > New > Imported Dataset*. The Create New Dataset form will be displayed.

Create New Dataset

Name:

Time Units: Concentration Units:

Depth Units:

+ Add X Delete

Time	Distance	Depth	Concentration

OK Cancel Help

The following can be specified on this form:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.


Import Table

The time, distance, depth, and concentration data to import can be entered in the Import Table. At the top of the table there are buttons to add and delete a data point.

When all of the data points have been entered press the Ok button to create the dataset.

4.9.4 Editing an Imported Dataset

After the data has been created or imported it can be edited by selecting Edit > Imported Dataset. The Select Imported Dataset form will be displayed.



Select the dataset to edit and then click on the Ok button. The Edit Dataset form will be displayed.

Name: Case 18: Phase Change

Time Units: yr Concentration Units: mol/m3

Depth Units: m

+ Add X Delete

Time	Depth	Concentration
95	0	5.52674840438603E-5
95	0.15	0.000254692081837588
95	0.3	0.000408322543147919
95	0.45	0.000498531347488346
95	0.6	0.00052392842755612
95	0.65	0.000523922355508225
95	0.7	0.000523916159137902
95	0.75	0.000523909838450055
95	0.8	0.000523903393449613
95	0.825	0.000523903265765265
95	0.85	0.000523903263148956
95	0.875	0.0005239033856013
95	0.9	0.000523903633122938
95	1.0875	0.000465918039072118

OK Cancel Help

The following can be edited on this form:

Name: This is the name to use for the imported data. It will show up in the legend for the charts.

Time Units: This is used to select the time units for the imported data.

Depth Units: This is used to select the depth units for the imported data.

Concentration Units: This is used to select the concentration units for the imported data.


Import Table

The time, depth, and concentration data can be edited in the Import Table. At the top of the table there are buttons to add and delete a data point.

After all of the edits are complete, click on the Ok button to save the changes.


4.9.5 Deleting an Imported Dataset

Imported datasets can be deleted from the model by selecting File > Delete > Imported Dataset. The Delete Imported Dataset form will be displayed.




Select the dataset to delete then click on the Ok button. Only the imported dataset will be deleted. This will not delete the original Excel file or other Model data.


4.10 Saving a Model



To save any changes to a model click on the Save button at the top of the form. If the save button is not enabled, then no changes have been made yet.



To save the model under a new name click on the SaveAs button at the top of the form. The Save As form will be displayed.



The dialog box titled "Save Migrate Model As" contains a "Name:" text field and a "Save As Template" checkbox. Below these is a table of existing models. At the bottom are "OK", "Cancel", and "Help" buttons.


Name	Template
Case 2: Landfill with composite primary and	Primary & Secondary Landfill
#DLIM #FRAC Case 10: 1m Compacted Clay Liner	Blank
#VAR Case 12: Two Landfills - Different Source	Blank
#VAR Case 13: Failure of Leachate Collection	Primary Leakage Rate Landfill
Case 11: Two Landfills	Blank
Case 1: Subtitle D Landfill with constant source	Primary Leakage Rate Landfill
Case 3: Pure Diffusion - constant source and base	Blank
Case 4: Finite Mass and Leachate Collection System,	Blank
Case 5: Demonstrate Effects of Integration	Blank
Case 6: Repeat Case 5 using N=20 and RNU=2.	Blank
Case 7: Repeat Case 5 using N=20, RNU=2, and	Blank
Case 8: Concentration Profile for a Buried Landfill	Blank
Case 9: Comparison with an analytical solution - D =	Blank
Test 1	Blank
test 2 var	Blank

At the top of this form a new unique name can be specified. There is a list of existing models in the bottom of the form to make it easier to specify a unique name.

In addition, the model can be saved as a template by checking the Save As Template box. After being saved as a template it can be used to create other models.

4.12 Converting a Model

Models that have been created with templates other than the Blank (Regular) can be converted to a regular model by selecting *Edit > Convert to Regular Pollute Model*. The Convert Pollute Model will be displayed.



This form will list the models that were not created using the regular (Blank) template. Select the model to convert then press the Convert button.

4.13 Exporting a Model

Models can be imported and exported from one computer to another as XML exchange files. To export a model select **File > Export > Migrate Model** when the project is open but no model is open. The Export Migrate Model form will be displayed.

Export Migrate Model

Most Recent Models

Name	Template
test var diff	Blank
Case 4: Finite Mass and Leachate Collection System	Blank
Case 3: Pure Diffusion - constant source and base	Blank
#VAR Case 12: Two Landfills - Different Source His	Blank
#VAR Case 13: Failure of Leachate Collection Syste	Primary Leakage Rate Landfill
test 2 var	Blank
Test 1	Blank
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill
Case 1: Subtitle D Landfill with constant source con	Primary Leakage Rate Landfill

All Models

Name	Template
Case 2: Landfill with composite primary and con	Primary & Secondary Landfill
#DLIM #FRAC Case 10: 1m Compacted Clay Lin	Blank
#VAR Case 12: Two Landfills - Different Source	Blank
#VAR Case 13: Failure of Leachate Collection S	Primary Leakage Rate Landfill
Case 11: Two Landfills	Blank
Case 1: Subtitle D Landfill with constant source	Primary Leakage Rate Landfill
Case 3: Pure Diffusion - constant source and ba	Blank
Case 4: Finite Mass and Leachate Collection Sys	Blank
Case 5: Demonstrate Effects of Integration	Blank
Case 6: Repeat Case 5 using N=20 and RNU=2	Blank
Case 7: Repeat Case 5 using N=20, RNU=2, an	Blank
Case 8: Concentration Profile for a Buried Landf	Blank
Case 9: Comparison with an analytical solution -	Blank
Test 1	Blank
VAR DIFF	Blank
test 2 var	Blank

Preview

Case 3: Pure Diffusion - constant source and base concentrations.

Distance Model

Landfill 1

Surface Width

Base

Calculated Distances

Depth Model

Constant Concentration

Zero Concentration

Calculated Depths

Select the model to export then click on the Export button. After this you will be prompted to specify the name of the XML file to store the exported model.

4.14 Importing a Model

Models can be imported and exported from one computer to another as XML exchange files. To import a model select *File > Import > Migrate Model* when the project is open but no model is open. You will then be prompted to specify the name of the file to import.

Pollute & Migrate

User Guide

Chapter 5 Templates

Chapter 5 Templates


Templates are a new feature in version 8 and are used to create predefined models and format the output (charts and listings) from the models. The program comes with several predefined templates these include a blank (empty) model, primary landfill, primary and secondary landfill, vertical migration, and horizontal migration. These templates form the underlying base templates of all templates.

By using templates models can be created quickly with a minimum amount of data entry. The models created can have their data edited as required. New templates can be created from existing templates or models.

5.1 Creating a Template

A new template can be created from either an existing template or model.

5.1.1 Creating from an Existing Template




To create a new template from an existing template, open the template then click on the SaveAs button. The Save As form will then be displayed. Enter a unique new name and then click on the Ok button to create the new template.


A screenshot of the 'Save Template As' dialog box. It has a title bar with a green icon and the text 'Save Template As'. Below the title bar is a 'Name:' label followed by a text input field. Underneath is a section labeled 'Existing' containing a table with a header 'Name' and four rows: 'Blank', 'Primary & Secondary Landfill', 'Primary Landfill', and 'Primary Leakage Rate Landfill'. The 'Blank' row is highlighted in blue. At the bottom of the dialog are three buttons: 'OK' with a green checkmark, 'Cancel' with a red X, and 'Help' with a blue question mark.

When the new template is saved the graph and listing options will also be copied. In addition, the underlying base template will also be set the same as the original template.

5.1.2 Creating from an Existing Model



To create a new template from an existing model, open the model then click on the SaveAs button. The Save As form will then be displayed. Enter a unique new name, check the Save As Template box, and then click on the Ok button to create the new template.




The dialog box titled "Save Model As" contains a "Name:" text field and a "Save As Template" checkbox. Below these is a table labeled "Existing" with two columns: "Name" and "Template". The table lists various cases and their corresponding templates. At the bottom are "OK", "Cancel", and "Help" buttons.

Name	Template
Case 2: Landfill with composite primary and	Primary & Secondary Landfill
#DLIM #FRAC Case 10: 1m Compacted Clay Liner	Blank
#VAR Case 12: Two Landfills - Different Source	Blank
#VAR Case 13: Failure of Leachate Collection	Primary Leakage Rate Landfill
Case 11: Two Landfills	Blank
Case 1: Subtitle D Landfill with constant source	Blank
Case 3: Pure Diffusion - constant source and base	Blank
Case 4: Finite Mass and Leachate Collection System,	Blank
Case 5: Demonstrate Effects of Integration	Blank
Case 6: Repeat Case 5 using N=20 and RNU=2.	Blank
Case 7: Repeat Case 5 using N=20, RNU=2, and	Blank
Case 8: Concentration Profile for a Buried Landfill	Blank
Case 9: Comparison with an analytical solution - D =	Blank
Test 1	Blank
test 2 var	Blank

When the new template is saved the graph and listing options from the original template will also be copied. In addition, the underlying base template will also be set the same as the original template.

5.2 Opening a Template

To open an existing template make sure no project is open and then select *File > Open > Pollute Template* or *File > Open > Migrate Template*. The Open Pollute Template or Open Migrate Template form will be displayed.



Select the template to open and then click the Open button.

5.3 Editing a Template


After a template has been opened, the model data and output options can be edited. On the left side of the form is the model data and on the right side is the model output.

The model data in the template will be used as the initial data for any model created with the template. This data can be further edited in the actual model. The editing of the model data is described in detail in the Pollute Models and Migrate Models chapters.


Model output can be displayed in a variety of charts and in a list. The options and formatting of these charts and listing is specified and saved in the template. The editing of the charts and listing formats and options is described in the sections below.

After the editing is complete, click on the Save button to save the changes.

5.3.1 Editing Listing Formatting and Options



The output for a model can also be displayed in a listing. Options for the listing can be edited by pressing the Options button on the List tab. The List Options form will be displayed.



The following can be edited on this form:

Table Header Color: Press this button to change the color for the background of table headers.


Program Font: Press this button to change the font used for the program name in the listing.

Title Font: Press this button to change the font used for the title in the listing.


Section Title Font: Press this button to change the font used for the section titles in the listing.

Normal Font: Press this button to change the font used for the normal text in the listing.

5.3.2 Editing Chart Formatting




The format of the chart can be edited by clicking on the Edit button on the Graph tab. The Editing Chart form will be displayed.



This form shows a tree view on the left containing the various sections of the chart that can be formatted. On the right are the options for the selected section. The editing of each of these sections is described below.

5.3.2.1 Editing the Series Format

The chart series can only be edited when editing a model. This section is ignored when editing a template.



The section will display a list of the data series currently in the chart. In the following charts the series will be line series:


- Depth vs Concentration
- Concentration vs Time
- Flux vs Time
- Probability vs Concentration
- Probability vs Time
- Probability vs Variable Value

In the Concentration vs Depth vs Time chart the series will be a surface. And in the Depth vs Time chart the series will be a color grid.

It is recommended to only edit the [Chart Line Options](#)^[304] and [Chart Grid Options](#)^[305] to control the format for the series.


5.3.2.2 Editing the Chart Format

This section is used to edit the format of the chart.



The sub-sections can be edited by clicking on them in the tree view on the left or the tabs at the top. The editing of the most pertinent sub-sections is described below.

The chart title can be formatted using the Titles sub-section. Several tabs control the format of the title and are described briefly below.



The following are some of the most pertinent items that can be edited:

Position Tab

Vert. Margin: This is used to specify the margin between the title and chart.

Options Tab

Visible: Check this to show the title on the chart.

Alignment: This is used to select the alignment of the title relative to the chart.


Text Tab

Text: This is the title to show for the chart. If the text contains [Model Title], the model title used for the actual model will be substituted. For the Probability vs Concentration chart if the text contains [Max Conc], the maximum concentration for the model result will be substituted. For the Probability vs Time chart if the text contains [Max Time], the time of the maximum concentration for the model result will be substituted. For the Probability vs Variable Value chart if the text contains [Expected Value], the expected value of the variable for the model result will be substituted.

Format Tab

Font: This is used to set the font for the title.

The axes can be formatted using the Axis sub-section. When this sub-section is expanded each axis can be selected for formatting. The Depth Right and Depth Top axes are used for 3D charts. Several tabs control the format of the each axis and are described briefly below.



The following are some of the most pertinent items that can be edited:

Scales Tab

Automatic: Check this to automatically calculate the axis minimum and maximum values based on the data.

Visible: Check this to show the axis on the chart.

Title Tab

Title: This is the title to show for the axis. If the text contains [units], the data units will be substituted.

Angle: This is the angle of title relative to the horizontal.

Position: This is the position of the title along the axis.

Font: This is used to set the font for the axis title.

Labels Tab

Visible: Check this to show the tick labels on the axis.

Angle: This is the angle of tick labels relative to the horizontal.

Min. Separation %: This is used to specify the minimum separation between labels. A value between 20 and 40% is recommended.

Font: This is used to set the font for the tick labels.

Ticks Tab

Outer Visible: Check this to show ticks at the labels.

Outer Length: This is used to specify the length of the ticks used for the labels.

Outer Color: This is used to select the color of the ticks used for the labels,

Minor Visible: Check this to show minor ticks between labels.

Minor Length: This is used to specify the length of the minor ticks.

Minor Color: This is used to select the color of the minor ticks.


Grid Tab

Visible: Check this to show the grid related to the axis.

Color: This is used to select the color of the grid lines,

Style: This is used to select the style of the grid lines.

The chart legend can be formatted using the Legend sub-section. Several tabs control the format of the legend and are described briefly below.



The following are some of the most pertinent items that can be edited:

Style Tab

Visible: Check this to show the legend on the chart.

Check boxes: Select check boxes to display a check box beside each series in the legend to turn on and off the display of the series in the chart.

Position Tab

Position: This is used to select the location of the legend relative to the chart.

Margin: This is used to specify the distance between the chart and the legend.

Title Tab

Visible: Check to show the title in the legend.


Text: This is the title to show in the legend.

Text Alignment: This is used to select the horizontal alignment for the legend title.

Font: This is used to set the font for the legend title.

5.3.2.3 Editing the Chart Data


This section can be used to preview the data in the chart. This section is not shown when editing a template.




The data shown is the result of the model execution and it is not recommended that the data be edited in this section. Any edits will only be shown on the chart and not be saved.

5.3.2.4 Editing the Print Preview

This section can be used to preview and print the chart. This section is not shown when editing a template.



5.3.3 Editing Chart Line Options



If the chart is displayed as series of lines, the line options can be edited by pressing the Options button on the Graph tab. The Chart Options form will be displayed.

Chart Options

Line Width:

☐ Show Data Values

Line Colors

Line #	Color
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	

OK Cancel Help


The following can be edited on this form:

Line Width: This is used to select the width of the lines.


Line Colors: This is used to select the colors of each of the line series. When the color is clicked on, a color dialog is displayed that can be used to select a color.

Show Data Values: Check this to show the data values for the line series.

5.3.4 Editing Chart Grid Options




If the chart is displayed as a grid, the grid options can be edited by pressing the Options button on the Graph tab. The Chart Options form for a Pollute or Migrate model will be displayed.

Pollute

The 'Pollute' dialog box, titled 'Chart Options', contains the following settings:

- ☒ Interpolate Data
 - Number of Interpolations: 2
- Start Color:
- End Color:
- Number of Steps: 20
- ☒ Grid Visible
 - Grid Color:

Buttons at the bottom: (with a green checkmark icon), (with a red X icon), and (with a blue question mark icon).

Migrate

The 'Migrate' dialog box, titled 'Chart Options', contains the following settings:

- ☒ Interpolate Data
 - Number of Interpolations: 2
- ☒ Equalize Colors
 - Max. Color: Red
- Number of Steps: 20
- ☒ Grid Visible
 - Grid Color:

Buttons at the bottom: (with a green checkmark icon), (with a red X icon), and (with a blue question mark icon).

The following can be edited on this form:

Interpolate Data: Check to interpolate the data for the grid. This will interpolate between data values to create a finer grid mesh.

Number of Interpolations: This is used to specify the number of interpolations between data values. The higher the number of interpolations the finer the grid mesh. Generally, a value between 2 and 4 is recommended.

Start Color: If it is a Pollute model this is used to select the start color for the lowest concentration in the grid.

End Color: If it is a Pollute model this is used to select the end color for the highest concentration in the grid.

Equalize Colors: If it is a Migrate model check this to equalize the colors so that the maximum color is the same concentration for all the times and distances..

Max. Color: If it is a Migrate model this is used to select the color for the maximum concentration.


Number of Steps: This is the number of steps (intervals) in color between the start and end colors.

Grid Visible: Check to make the grid lines visible.

Grid Color: This is used to select the color of the grid lines.

5.4 Deleting a Template

To delete an existing template make sure no project is open and then select *File > Delete > Pollute Template* or *File > Delete > Migrate Template*. The Delete Pollute Template or Delete Migrate Template form will be displayed.




The image shows a dialog box titled "Delete Pollute Template". It contains a table with two columns: "Name" and "Type". The table lists five templates: Blank, Horizontal Migration, Primary & Secondary Landfill, Primary Landfill, and Vertical Migration. Below the table is a large empty rectangular area. At the bottom of the dialog box are three buttons: "Delete" (with a checkmark icon), "Cancel" (with an 'X' icon), and "Help" (with a question mark icon).

Name	Type
Blank	Blank
Horizontal Migration	Horizontal Migration
Primary & Secondary Landfill	Primary & Secondary Landfill
Primary Landfill	Primary Landfill
Vertical Migration	Vertical Migration

Select the template to delete and then click the Delete button.

5.5 Exporting a Template

To export an existing template to an XML exchange file, make sure no project is open and then select *File > Export > Pollute Template* or *File > Export Migrate Template*. The Export Pollute Template or Export Migrate Template form will be displayed.




Name	Type
Blank	Blank
Horizontal Migration	Horizontal Migration
Primary & Secondary Landfill	Primary & Secondary Landfill
Primary Landfill	Primary Landfill
Vertical Migration	Vertical Migration

Export Cancel Help

Select the template to export and then click the Export button.

5.6 Importing a Template

To import a template from a previously exported XML exchange file, select *File > Import > Pollute Template* or *File > Import Migrate Template*. The Import Pollute Template or Import Migrate Template form will be displayed,



Select the XML exchange file containing the template, then click the Open button. For the template to be imported, the imported template name must not already exist in the program.

Pollute & Migrate

User Guide

Chapter 6 Data and User Management

Chapter 6 Data and User Management

This application provides functionality for both data and user management. In addition, it also provides for data security. The application can be used either as a standalone program or in a network configuration. When used in a network configuration, the network license manager handles the licensing and user administration.


6.1 Security and User Administration

This application has several features to assist in the administration of users and to provide data security.

6.1.1 User Administration

When the application is started users (both local and network) must login to the application. When users are setup in the application they are assigned a username, password, and user type (privilege). Different privilege levels are used to control access to functions of the program and data. The different user types are administrator, power user, limited user, and guest. The functionality of different privilege levels is described in the [User Privilege Level Functionality](#)^[315] section below.

If it is a network version, the user must login as a network user that is setup in the [Network License Manager program](#)^[333]. If it is a local single user computer version of the application, local users can be setup by the administrator by going to [Tools > Manage Local Users](#). The Manage Users form will be displayed showing the current local users




The screenshot shows a window titled "Manage Users" with a blue header bar. Below the header is a toolbar with three buttons: "Add" (with a plus icon), "Edit" (with a pencil icon), and "Remove" (with a minus icon). Below the toolbar is a table with five columns: "User", "ID", "Privilege Level", "Date Created", and "Time". The table contains two rows: "Admin" (ID 101, Administrator, 2015-11-30, 7:45:28 PM) and "Power" (ID 102, Power User, 2020-10-04, 2:48:44 PM). The "Admin" row is highlighted in blue. Below the table is a large empty rectangular area. At the bottom right of the window are two buttons: "Close" and "Help".

User	ID	Privilege Level	Date Created	Time
Admin	101	Administrator	2015-11-30	7:45:28 PM
Power	102	Power User	2020-10-04	2:48:44 PM

At the top of this form there are buttons to Add, Edit or Remove a user.

6.1.1.1 Adding a Local User

To add a local user click on the Add button at the top of the Manage Users form, the Add User form below will be displayed. This form is used to enter the user name, password, and user type for the account. The user name should be unique for each user.




The 'Add User' form is a dialog box with a blue title bar. It contains four input fields: 'User name:', 'Password:', 'Confirm Password:', and 'User type:'. The 'User type:' field is a dropdown menu currently showing 'Power User'. At the bottom are three buttons: 'OK', 'Cancel', and 'Help'.

User name:	
Password:	
Confirm Password:	
User type:	Power User
OK Cancel Help	

6.1.1.2 Editing a Local User

To edit a local user select the user in the list and click on the Edit button at the top of the Manage Users form, the Edit User form below will be displayed. This form is used to edit the user name, password, and user type for the account. The user name should be unique for each user.



The 'Edit User' form is a dialog box with a blue title bar. It contains four input fields: 'User name:', 'Password:', 'Confirm Password:', and 'User type:'. The 'User name:' field contains the text 'Admin'. The 'User type:' field is a dropdown menu currently showing 'Administrator'. At the bottom are three buttons: 'OK', 'Cancel', and 'Help'.

User name:	Admin
Password:	
Confirm Password:	
User type:	Administrator
OK Cancel Help	

6.1.1.3 Removing a Local User

After a local user has been created it can be removed by selecting it on the Manager Users form and clicking on the Remove button.

6.1.1.4 User Privilege Level Functionality

The features and functionality that can be assessed in the application is controlled by the privilege level of the user. In the sections below an "x" beneath a privilege level indicates that this functionality is granted for that level.

	Admin	Power	Limited	Guest
Main Features				
Manage Users	x			
Manage Licenses	x			
Export Main Database	x			
Restore Main Database	x			
Restore Project Database	x			
Preferences (limited individually)	x	x	x	
Symbol Libraries	x	x		
Unit Conversion	x	x	x	x
Unit Precision	x	x		
Clear Recent	x	x	x	
Project Features				
Edit Project Categories	x	x		
New Project	x	x	x	
Open Project	x	x	x	x
Edit Project Information	x	x	x	
Delete Project	x	x	x	
Georeference to Point on Map	x	x	x	
Georeference Manually	x	x	x	
Assign Local Project Coordinates	x	x	x	
Query Projects	x	x	x	x
Import XML Project	x	x	x	
Import Project Database	x	x	x	
Export XML Project	x	x	x	
Export Project Database	x	x	x	
Model Template Features				
Create a Template	x	x	x	
Open Template	x	x	x	
Delete Template	x	x		
Export Template	x	x	x	
Import Template	x	x	x	

Model Features

New Model	x	x	x	
Open Model	x	x	x	x
Delete Model	x	x	x	
Export Model	x	x	x	
Import Model	x	x	x	

6.1.2 Project Security

To provide data security to some projects a password can be added specifically for that project. This password must then be entered every time the project is opened. To add a password when [creating a new project](#)⁸⁰, check the box for Set Password and enter the Password on the New Project form.

New Project

Project Info | Local Coordinates | Category

Project

Number:

Name:

☒ Set password Password:

Client

ID: Name:

Address

Address:

City:

State/Province:

Country:

Postal/ZIP Code:

OK Cancel Help

To add or change a password for an existing project, [open the project](#)  and select [Edit > Project Information](#) to display the Project Information form. Then check the box for Set Password and enter the Password

6.2 Database Management

The data in this application is stored in a main database and project databases. These databases are backed up at regular intervals and if necessary can be restored from backup copies.

6.2.1 Backing up a database


The main database and current project database are backed up at regular intervals. These intervals are set in the [preferences](#) ⁶⁴ for the program. A project database will only be backed up if the project is currently open.

6.2.2 Restoring a database

If necessary due to data corruption or some other problem, a database can be restored from a backup. The sections below describe how to restore the main database and project databases.

6.2.2.1 Restoring the Main Database

To restore the main database, select [Tools > Databases > Restore > Main Database](#) and the Select Backup Database form below will be displayed.




Date	Time
October 7, 2019	15:54:1
October 7, 2019	16:17:1
October 7, 2019	16:29:1

This form lists the backups by date and time. Select the database to restore from the list and then click on the Ok button. If you choose to proceed with the restoration, the main database will be replaced by the backup and the application will be restarted.

6.2.2.2 Restoring a project database


To restore a project database, select *Tools > Databases > Restore > Project Database* and the Select Project form below will be displayed. To backup a project database, no project can be currently open.




Most Recent Projects	
Project ID	Name
Local 1	Local 1
g1	g1

All Projects	
Project ID	Name
Local 1	Local 1
g1	g1

Details
Project ID: g1
Name: g1
Status: Active
Client ID:
Client:
Date Created: 2021-04-09 12:13:31 PM
Date Modified:



This form lists the projects in the application. Select the project to restore from a backup and then press the Select button. The Select Backup Database form below will be displayed.



Date	Time
April 15, 2021	16:32:0

OK Cancel Help

This form lists the backups by date and time. Select the database to restore from the list and then click on the Ok button.

6.3 Network License Management

The application can be licensed on individual computers, a network, or a combination of both. When licensed on a network the licensing is based on concurrent usage, where the number of concurrent users must be less than or equal to the maximum number of users licensed. This means that the program can be installed on any number of computers in the office but only the licensed number of concurrent users can use it at the same time.

The sections below describe the installation for both the server and client computers and how to manage the network using the License Manager.

6.3.1 Installation

When the application is managed on a network the databases and datastore for the application are also normally stored on the network server. There are two ways to install the databases and datastore on the server. The easiest method is to install the application on the server and select the location of the database and datastore directories when the application is first run on the server. Alternatively, if you prefer not to have the application on the server you can install it on a client computer and set the database and datastore directories to the server when the application is first run on the client.

After the databases and datastore have been installed on the server it is important not to overwrite them each time the application is installed on a client computer. To do this make sure you answer "No" to the last question about installing the databases and datastore when the program is first run on a client computer. Instead database and datastore directories should be set to the server when the application is first run.

It is important to make sure that the directories on the server where the databases and datastore are located are shared and have their file access permissions set to "Full Control" for all users.

6.3.1.1 Server Installation

To get the network up and running, the network license service and network license monitor program first need to be installed on the server. The following steps occur during the installation:

- The Network License Monitor program is installed on your computer
- The Network License Manager service is installed.
- Shortcuts are placed on your Programs menu

After the network service has been installed on the server it needs to be started before it can be used. This is done automatically when the server is restarted or it can be done manually through the Windows Services Manager. To do it manually open the Services list from Administrative tools in the Windows Control Panel. Select the PM License Manager in the Services list and then select Start.


To uninstall the network service automatically, select Uninstall Network License Service from the application shortcuts on the Programs menu. The service will then be uninstalled the next time the server is restarted. To uninstall the service immediately, it needs to be stopped first and then uninstalled.

To stop the service, open the Services list from Administrative tools in the Windows Control Panel. Select the PM License Manager in the Services list and then select Stop. Then uninstall the network service as described above.


6.3.1.2 Client Installation

The installation of the application on a client is the same as the single user installation. The only difference from the single user installation is that the network option should be selected during the first-run setup stage of the program. In addition, after the databases and datastore have been installed on the server it is important not to overwrite them each time the application is installed on a client computer. To do this make sure you use the default database and datastore directories (on the local C drive) during program installation.

After the program has been installed on the client, the database and datastore folders need to be set to the server. To do this run the program and log in as an administrator (this option is not available to non-administrator users). Select [File > Preferences](#) and go to the Datasources tab. On this tab set the folder paths for the database and datastore to the ones on the server.



If the network option was not selected during the installation on the client computer, then it can be set in the preferences for the application. Select [File > Preferences](#), and select the Network License tab on the left.




To get the licenses from the network, set Networked to yes and enter the network name or IP address. The port number should always be 3002 for the network. This information is displayed on the [Network Monitor](#) ³²¹ form on the network. In the box below the network settings select the licenses to request from the network.

6.3.2 License Manager

The licensing of the application on a network is handled through a service called PM License Manager and an application called Pollute and Migrate License Monitor. The service handles the logging in of users and grants license requests and has no user interface. The network monitor provides a user interface for adding/removing users and managing licenses.

When the Pollute and Migrate License Monitor is being run as a process the program icon will be displayed in the system tray. A popup menu can be displayed by right clicking on the program icon in the system tray. This menu can be used to display the network monitor form, manage licenses, manage users, show the network log, and shutdown the network monitor. Shutting down the network license manager will stop the network license manager process but will not stop the network service.

To display the network license monitor form double-click on the icon or select it from the popup menu.



Name	Logged In	IP
admin	2025-10-08	127.0.0.1

On the right side of the Network License Monitor form a list of users that are currently logged into the program is displayed. And on the left side is a box displaying the network server name and port. These network properties are the ones required to be entered into the preferences of the application on client computers, as described in the section on [setting client network options](#)⁶⁵. The port should always be 3002.

Below the Network Properties box are buttons for managing licenses, managing users, showing the network log, and adjusting settings. These buttons are described in the sections below. The close button will hide the monitor and put an icon in the system tray and the shutdown button will shutdown the monitor.

6.3.2.1 Manage Licenses

To use the application modules on client computers they must be licensed on the network. The modules will run in demo mode on the client computers until the network is licensed. To manage the licenses for the application modules click on the Manage Licenses button on the License Monitor form, the License Manager form will be displayed.

Name	Version	Licensed	Max Users
Migrate Module	10.0	☒	5
Pollute Module	10.0	☒	2

Module

Name:

Version:

Industry:

Registration

Expires:

Licensed On:

Current Users:

Invoice #:

Other

Developer:

Copyright:

Description

On the left side of the form is a list showing the licensing of the application modules. If the module is licensed the Licensed box will be checked and the maximum number of users will be displayed. When the module is selected the details for the license will be displayed in the box on the right side of the form.

At the top of the form there are buttons to register (unlock), export serial numbers, import unlock codes and update the maximum users. If the module has not been licensed the Register, Export and Import buttons will be enabled, after the module has been licensed these buttons will be not enabled.


Licenses can be purchased by selecting the module and clicking on the Purchase button the License Manager form. The Purchase License form will then be displayed.

Purchase License

Select the product, quantity, and license type then click on the Purchase button to purchase the license. To purchase a network license, the Network Monitor should be used.

Module Name:	Pollute Module
Module Version:	10.0
Installed On:	December 30, 1899

Serial Number: P10-2484-8672-1010-8365

 Purchase

License Type: ☒ Perpetual ☐ Annual Subscription

 Close

 Help


This form shows the selected module and the serial number for the module. These serial numbers are unique for each server and module. Either perpetual or subscription licenses can be purchased. After the license type and quantity have been selected, click on the Purchase button to proceed with the purchase. A secure web page will then be opened in your browser where you can enter the purchase information.

Purchase License

Select the product, quantity, and license type then click on the Purchase button to purchase the license. To purchase a network license, the Network Monitor should be used.

Module Name:	Pollute Module
Module Version:	10.0
Installed On:	December 30, 1899


Serial Number: P10-2484-8672-1010-8365

 Purchase

License Type: ☒ Perpetual ☐ Annual Subscription

After purchase is complete enter the Order ID below and click on the Register button to register the license.

Order ID:

 Register

 Close

 Help

When the purchase has been completed, you will be provided by email with a unique order/purchase ID. Enter this ID on the form and click on the Register button to register the module. If the purchase or email is delayed, the license can later be registered as described in the [Registering a License](#)^[328] section.

If a subscription is purchased it can be automatically renewed and the renewal information will be sent to the GaeaSynergy License Monitor.

After a license has been purchased and not yet registered, it can be registered by selecting the module on the License Manager form and clicking the Register button. The Register form below will then be displayed.

Unlock

Module Name: Pollute Module

Module Version: 10.0

Automatic Manual

Order ID:

Register

OK Help

This form has two tabs, one for automatic registrations and one for manual registrations.

Automatic Registration

If you purchased the license online and have an order/purchase ID you can enter on the Automatic tab to register the license.

Manual Registration

Unlock

Module Name: Pollute Module
Module Version: 10.0

Automatic Manual

To register the module and obtain an unlock code, enter your invoice number then click the obtain unlock code button. This will display a registration form on GAEA's website. Fill in the information on the form and then submit it.

Invoice Number:

If you are unable to access the internet, please call us at (613) 900-1950.

Serial Number
P10-2484-8672-1010-8365

Codes
 ☐

User Code:

Obtain code Store codes

OK Help

To manually register the license, contact GAEA with your invoice number and the unique serial number shown on the form. GAEA can be contacted either by clicking on the Obtain Unlock Code button or by emailing us at codes@gaeatech.com. When the Obtain Registration button is used an email form will be displayed where you can enter your contact information and email it directly to GAEA.

After you receive the registration code from GAEA you can enter it on the form and then save it by clicking on the Store Unlock Code button.

Another way to license the application is to export the serial number to a file and email the file to GAEA. We will then send you back an unlock code file that can be imported. To export the serial number select the module and click on the Export button at the top of the License Manager form.

Export Serial Numbers

Name	Pollute Module
Serial Number	P10-2484-8672-1010-8365

To register the modules and obtain unlock codes, enter the information below then select either email or export. When exporting to a file you need to email the file to codes@gaeatech.com.

Invoice Number:

Name:

Company Name:

Address:

City: Province/State:

Country:

Email:

File Name: 

 Email  Export  Cancel  Help

The unique serial number for the module is displayed at the top of this form and can not be changed. Enter all of the information on this form, including the invoice number. After entering an email address and file name the Email and Export buttons will be enabled. To email GAEA the serial number file click on the Email button. To export the serial number to a file click on the Export button, this file will then need to be emailed to us at support@gaeatech.com.

After the serial number file has been exported and emailed to GAEA, we will email you an unlock code file that can be imported. To import this file, select the module on the License Manager form and click on the Import button at the top of the form. The Import Registration form will be displayed.

The 'Import Registration' dialog box has a blue title bar with a question mark and a close button. The main text area contains instructions: 'Importing registration data from a file allows you to register multiple StrataExplorer modules at once. If you have received a registration file from GAEA Technologies, please select it then press 'Store Unlock Codes' to register your modules.' Below this is a 'File:' label followed by a text input field and a 'Browse...' button. A 'Module' section contains a table with the following data:

Name	
Invoice	
Serial Number	
Max Users	
Unlock Code	
User Code	

Below the table is a 'Store Codes' button with a floppy disk icon. At the bottom right are 'Close' and 'Help' buttons.


At the top of the Import Registration form the file with the unlock codes can be selected. After the file has been selected the module details will be shown and the unlock codes can be stored by clicking on the Store Codes button.

After the application has been licensed, the maximum number of users can be updated by clicking on the Update button at the top of the License Manager form. To update the maximum number of users enter the user unlock code from GAEA and click on the Store user code button.

The 'Unlock Users' dialog box has a teal title bar. It contains the following fields and buttons:

- Module Name:** Migrate Module
- Module Version:** 10.0
- Serial Number:** M10-2484-8672-1010-4225
- User Unlock Code:** (empty text input field)
- Store user code** button
- Close** button

If you need to transfer the license for a network installation from one server to another, select the module on the License Manager form and click on the Relock button. The Relock form will then be displayed.




The Relock dialog box displays the following information:

Module Name:	Migrate Module
Module Version:	10.0
Licensed On:	2025-10-08
Max Users:	5

In order to transfer the registration to a different network, you must first relock it. Relocking a module reverts it to an unregistered state.

 Relock

 Close  Help

To transfer the registration to a new server click on the Relock button. The module will no longer be registered on this server and the order/purchase ID can be used to register it on a different server as described in the [Automatic Registration](#)^[328] section..

6.3.2.2 Manager Users

Prior to using the application on a client computer a user must have a user account setup in the license monitor program. This user account is used to login to the application on the client computer. When user accounts are setup they are assigned a username, password, and user type (privilege). Different privilege levels are used to control access to functions of the program and data. The different user types are administrator, power user, limited user, and guest. The functionality of different privilege levels is described in the [User Privilege Level Functionality](#)^[315] section below.


To manage the user accounts click on the Manage Users button on the Network Monitor form. The Manage Users form displays the current user accounts and is used to add, edit, remove, export and import user accounts.

Manage Users


 Add  Edit  Remove |  Export  Import

User	ID	Privilege Level	Date Created	Time
admin	101	Administrator	2021-04-28	4:09:19 PM
guest	104	Guest	2020-04-01	1:45:30 PM
limited	103	Limited User	2020-04-01	1:45:18 PM
power	102	Power User	2020-04-01	12:11:15 PM


 Close  Help




To add a user account click on the Add button at the top of the Manage Users form, the Add User form below will be displayed. This form is used to enter the user name, password, and user type for the account. The user name should be unique for each user.




The 'Add User' dialog box has a blue title bar. It contains three input fields: 'User name:' (empty), 'Password:' (empty), and 'Confirm Password:' (empty). Below these is a 'User type:' dropdown menu with 'Power User' selected. At the bottom are three buttons: 'OK' with a green checkmark icon, 'Cancel' with a red X icon, and 'Help' with a blue question mark icon.




To edit a local user select the user in the list and click on the Edit button at the top of the Manage Users form, the Edit User form below will be displayed. This form is used to edit the user name, password, and user type for the account. The user name should be unique for each user.




The 'Edit User' dialog box has a blue title bar. It contains three input fields: 'User name:' (containing 'admin'), 'Password:' (empty), and 'Confirm Password:' (empty). Below these is a 'User type:' dropdown menu with 'Administrator' selected. At the bottom are three buttons: 'OK' with a green checkmark icon, 'Cancel' with a red X icon, and 'Help' with a blue question mark icon.



After a user account has been created it can be removed by selecting it on the Manager Users form and clicking on the Remove button.



When the licensing is being moved between servers the user accounts can be transferred by exporting them to a file on the original server and then importing this file on the new server. To export the user accounts click on the Export button at the top of the Manage Users form. You will then be prompted to specify the name of the user data file.



After the user accounts have been exported to a user data file, this file can be imported on the new server by clicking on the Import button at the top of the Manage Users form.

6.3.2.3 Active Locks

The licenses that are currently being used can be shown by clicking on the Active Locks button on the License Monitor form. The Active Locks form will display the license (lock name), owner (user), location (IP address) and the date and time the license was granted.

Active Locks				
Lock Name	Owner	Location	Date Created	Time Creat...
 Pollute Module	admin	127.0.0.1	2025-10-08	3:35:27 PM
 Migrate Module	admin	127.0.0.1	2025-10-08	3:35:27 PM

 Close  Help


6.3.2.4 Show Log

To show a log of network license events click on the Show Log button the License Monitor form, the Event Viewer form will be displayed.

Event Viewer					
 Save  Clear  Close  Help					
Type	ID	User	Date	Time	Category
 Informa...	Startup				
 Informa...	Startup	System	2021-04-29	11:02:04 ...	General
 Informa...	Startup	System	2021-04-29	11:02:04 ...	General
Comput...	Debug				
 Informa...	Login	PMLicenseManager	2021-04-29	11:03:21 ...	Licensing
 Informa...	Login	admin	2021-04-29	11:08:40 ...	Licensing
 Informa...	License Req...	admin	2021-04-29	11:08:40 ...	Licensing
 Informa...	Logout	PMLicenseManager	2021-04-29	11:22:59 ...	Licensing
 Informa...	Login	PMLicenseManager	2021-04-29	11:23:44 ...	Licensing
 Informa...	Logout	PMLicenseManager	2021-04-29	12:23:00 P...	Licensing
 Informa...	Login	PMLicenseManager	2021-04-29	12:23:53 P...	Licensing

The details for an event can be displayed by double-clicking on the event in the list. A log file in XML format can be created containing the events by clicking on the Save button at the top of the form. The events in the list can be removed by clicking on the Clear button at the top of the form.

When an event on the Event Viewer form is double-clicked, the details of the event will be displayed in the Event Details form.



The 'Event Details' dialog box displays the following information:


Type:	Information
ID:	Login
User:	admin
Location:	127.0.0.1
Date:	2021-04-29
Time:	11:08:40 AM
Category:	Licensing

admin@127.0.0.1 has logged in.

Buttons: Close, Help

6.3.2.5 Settings

The network server name and port can be adjusted by clicking on the Settings button on the License Monitor form. The Network Settings form below will be displayed. The port should be set to 3002, it is not recommended to adjust this setting without first discussing it with GAEA.



The 'Network Settings' dialog box displays the following information:

Server Name	Localhost
Port	3002

Buttons: Close, Help

Pollute & Migrate

User Guide

Appendix A Examples

Appendix A Examples

All the examples in this appendix have been stored in the Examples project.

7.1 Pollute Examples

The sections below describe the 20 Pollute examples provided in the Examples project.

7.1.1 Case 1: Subtitle D Landfill

This example illustrates the use of the program to model a U.S. RCRA Subtitle D landfill. The landfill consists of a composite liner and a primary leachate collection system. The composite liner is composed of a 60 mil (1.5 mm) geomembrane in good contact with a 0.9 m thick compacted clay liner. Small holes with an area of 0.1 cm² and a frequency of 1 per acre (2.5 per hectare) are assumed for the geomembrane. The method proposed by Giroud et al (1992) is used to calculate the flow (leakage) through the composite liner, these calculations are performed automatically by the program.

The landfill has a length (L) of 200 m in the direction parallel to groundwater flow in the underlying aquifer. Consideration is being given to a volatile organic contaminant with an initial source concentration of 1500 µg/L, which is assumed to remain constant with time over the time period being examined in this example. The leachate head on the composite liner is assumed to be constant at 0.3 m.

The flow in the aquifer must be established based on hydrogeologic data and is represented in terms of the horizontal Darcy velocity (the “Base Outflow Velocity”) in the aquifer at the down-gradient edge of the landfill.

7.1.2 Case 2: Pure Diffusion

This example illustrates the use of the program for the simple case of pure diffusion of a conservative species (i.e., no sorption). The hydrogeology is comprised of a 4 m thick layer with a constant contaminant concentration source at the top, and an underlying aquifer at the base. There is a sufficiently high flushing velocity in the aquifer that the concentration at the bottom of the layer can be assumed to be zero and the aquifer is not explicitly modelled.

7.1.3 Case 3: Advective Diffusive Transport

In this example the input data file from Case 2 will be edited to include advective transport and a permeable base stratum (aquifer) with a fixed outflow. The hydrogeology is comprised of a 4 m thick aquitard layer with a constant contaminant concentration in the landfill source at the top, and a 20 m thick underlying aquifer at the base.

Although the aquifer is 20 m thick it is generally unrealistic to model dilution (mixing) of contaminant through the full thickness. The actual thickness that should be modelled depends on the hydrogeologic conditions, the length of monitoring screens, and the local regulations. In this example dilution (mixing) of the contaminant will only be considered in the upper 3m of the aquifer, and hence the aquifer thickness used is $h = 3$ m.

Since the aquifer (i.e., the contaminant receptor) is being modelled as a boundary condition the actual deposit thickness that is explicitly modelled is the 4 m thick aquitard, and the concentration given in the output at the 4 m depth is the concentration in the upper 3 m of the aquifer. It is assumed that this is uniformly distributed in the 3 m and that no contaminant moved lower than 3 m into the aquifer (if the aquifer thickness, h , were to be increased, the concentration in the aquifer would drop).

In the underlying aquifer the inflow of water beneath the up gradient edge of the landfill is given by a Darcy velocity of 20 m/a.

The “base velocity” is the outflow velocity beneath the down-gradient edge of the landfill and corresponds to the inflow velocity (20 m/a) at the up gradient edge plus the inflow from the landfill.

Based on continuity of flow the initial flow in the aquifer, q_{in} , is given by the inflow velocity ($v_{in} = 20$ m/a in this example) multiplied by the thickness of the aquifer being considered ($h = 3$ m in this example) and the width of the landfill (the landfill dimension perpendicular to the direction of groundwater flow, $W = 300$ m in this example), thus:

$$q_{in} = v_{in} * h * W = 20 * 3 * 300 = 18000 \text{ m}^2/\text{a}$$

The flow into the aquifer from the landfill, q_a , is the downward Darcy velocity ($v_a = 0.1$ m/a in this case) multiplied by the length ($L = 200$ m) and width ($W = 300$ m) of the landfill, thus:

$$q_a = v_a * L * W = 0.1 * 200 * 300 = 6000 \text{ m}^3/\text{a}$$

Hence the outflow at the down-gradient edge of the landfill is:

$$q_{out} = q_{in} + q_a = 18000 + 6000 = 24000 \text{ m}^3/\text{a}$$

And the “Base Outflow Velocity”, v_b , is the outflow divided by the width of the landfill ($W = 300$ m) and the thickness of the aquifer being considered ($h = 3$ m), therefore:

$$v_b = q_{out} / (W * h) = 24000 / (3 * 300) = 26.67 \text{ m/a}$$

7.1.4 Case 4: Finite Mass Source

In this example the input data file from Case 3 will be edited to include a source with a finite mass of waste and a leachate collection system. The hydrogeology is comprised of a 4 m thick layer with a finite mass source at the top, and an underlying aquifer at the base with fixed outflow as discussed in Case 3. All of the parameters are the same as in Case 3, except the vertical Darcy velocity will be 0.03 m/a, the horizontal inflow velocity will be 4 m/a and there will be a finite mass top boundary condition. The finite mass top boundary condition requires the input of the Reference Height of Leachate (H_r), Rate of Increase in Concentration (C_r), and the Volume of Leachate Collected (Q_c).

It is assumed in this example that the waste has an average thickness of 6.25 m and a density of 600 kg/m³, and that chloride represents 0.2% of the total mass of the waste. Thus, the total mass of chloride per unit area of the landfill (m_{tc}) is calculated by multiplying the proportion of chloride by the density of the waste and the thickness of the waste.

$$\text{i.e. } m_{tc} = 0.002 * 600 * 6.25 \text{ kg/m}^2$$

A peak concentration (c_o) for chloride of 1000 mg/L (i.e., 1 kg/m³) is assumed. The Reference Height of Leachate is then:

$$H_r = m_{tc} / c_o = 0.002 * 600 * 6.25 / 1 = 7.5 \text{ m}$$

If the peak concentration is reached relatively early in the life of the landfill and the analysis starts at this time, then there will be no increase in concentration with time. The Rate of Increase in Concentration (C_r) would then be zero.

The Volume of Leachate (Q_c) collected is equal to the difference between the infiltration through the cover ($q_o = 0.3$ m/a here) and the exfiltration through the base ($v_a = 0.03$ m/a here), and is given by:

$$Q_r = q_o - v_a = 0.3 - 0.03 = 0.27 \text{ m/a}$$

In this example the inflow in the aquifer at the up gradient edge of the landfill will be 4 m/a and the outflow at the down gradient edge (v_b) is then:

$$v_b = (v_b(\text{in}) \cdot h \cdot W + v_a \cdot L \cdot W) / (h \cdot W) = v_a(\text{in}) + v_a \cdot L / h = 4 + 0.03 \cdot 200 / 3 = 6 \text{ m/a}$$

7.1.5 Case 5: Hydraulic Trap - Finite Mass Source

This example illustrates the use of the program for the case where there is a hydraulic trap (i.e., flow is into the landfill). The parameters are essentially the same as in Case 4, (where there was a finite mass source with a leachate collection system and a fixed outflow base) except that the Darcy velocity has been changed and the base aquifer is now assumed to be only 1 m thick with a porosity of 0.35 and is underlain by a low permeability layer. We also now choose to ignore the width of the landfill and take $W = 1$ m. This is the same as modeling a 1 m strip through the landfill. This width, W , has no effect on the results.

The calculation and values for the Reference Height of Leachate is the same as in Case 4. Again it is assumed that the average infiltration through the cover, (q_o) is 0.3 m/a. For this example the Darcy velocity (v_a) into the base of the landfill is assumed to be -0.001 m/a. The negative value for the Darcy velocity implies that the flow is upward. Neglecting the small volume of groundwater collected the average Volume of Leachate Collected (Q_c) is:

$$Q_c = q_o = 0.3 \text{ m/a}$$

In this example the inflow in the aquifer at the up gradient edge of the landfill will be 4 m/a and the outflow at the down gradient edge (v_b) is then:

$$v_b = v_b(\text{in}) + v_a \cdot L / h = 4 - 200 \cdot 0.001 = 3.8 \text{ m/a}$$

7.1.6 Case 6: Fractured Layer and Sorption

This example illustrates the use of the program for the case where one of the layers are fractured and there is and sorption of the contaminant species. The "barrier" consists of a 1 m thick compacted clay layer overlying a 3 m thick fractured till. A reactive species (i.e., one that will sorb on to the clay) is modelled in this case. The same finite mass source and leachate collection system is used as in the previous examples. A Darcy velocity (v_a) of 0.02 m/a through the deposit and an infiltration through the cover (q_o) of 0.3 m/a are assumed. The Volume of Leachate Collected (Q_c) is then given by:

$$Q_c = q_o - v_a = 0.3 - 0.02 = 0.28 \text{ m/a}$$

As in the previous examples the inflow in the aquifer at the up gradient edge of the landfill is 4 m/a. The outflow (v_b) at the down gradient edge of the landfill is then:

$$v_b = 4 + 200 \cdot 0.02 = 8 \text{ m/a}$$

7.1.7 Case 7: Fractured Rock and Radioactive Decay

This example illustrates the use of the program for lateral migration of a radioactive contaminant in a fractured porous rock with a single set of parallel fractures. It considers advective-dispersive transport along the fractures and diffusion into the rock matrix. The deposit is assumed to extend a considerable distance from the source (effectively an infinite distance) but we are only interested here in what happens over the first 50 m after 30 years..

It is assumed that the source concentration, c_o , is 1 unit and that the half life of the radioactive species is 100 years. The source is considered to have a sufficiently large supply that there is no significant change in source concentration due to mass movement into the rock. However the source does experience radioactive decay.

This example is also being used to illustrate the Maximum Sublayer Thickness Special Feature, for specifying sublayer thicknesses that are greater than 5 units.

7.1.8 Case 8: Diffusion with Initial Concentration Profile

The results of a laboratory diffusion test are analyzed in this example [see Rowe, Caers & Barone, 1988; Barone, Yanful, Quigley & Rowe, 1989]. In this example the diffusion of Potassium in a clay is examined. The clay has an initial background concentration of Potassium of 10 mg/L.

The leachate source has an initial concentration (c_o) of 400 mg/L, and the physical height of the leachate in the reservoir above the soil was 6 cm. At the base of the specimen there was an impermeable barrier (i.e., zero flux).

7.1.9 Case 9: Freundlich Non-linear Sorption

In this example a laboratory test is simulated using diffusion and Freundlich non-linear sorption. The sample is a 7 cm thick clay with an impermeable base and a finite mass source of Phenol. The leachate source has an initial concentration (c_o) of 50 mg/L, and the physical height of the leachate in the reservoir above the soil was 6.5 cm. Parameters for the Freundlich isotherm were obtained experimentally from batch tests, these are $K_f=2$ and $=0.628$.

7.1.10 Case 10: Time-varying Transport

This example illustrates the use of the programs to study time-varying rates of advective-dispersive transport from a landfill, using the Variable Properties special feature. The landfill contains a finite mass of a conservative species, and has a leachate collection system. Initially there is an inward hydraulic gradient causing a hydraulic trap. After 20 years the collection of leachate is terminated and the leachate mound begins to build reaching it's maximum height after another 10 years. The increased leachate mound causes a reversal in the hydraulic gradient, that results in a reversal of the Darcy velocity and the loss of the hydraulic trap.

The analysis starts at time zero which corresponds to the completion of the landfill and the development of a peak leachate concentration (c_o) of 1000 mg/L. It is assumed that the average waste thickness is 6.25 m with a density of 600 kg/m³, and that the contaminant represents 0.2% of the total mass of the waste. Thus the total mass of contaminant per unit area of landfill is:

$$m_{tc} = 0.002 \cdot 600 = 6.25 \text{ kg/m}^2$$

The Reference Height of Leachate (H_r) is then calculated by dividing the total mass of contaminant per unit area (m_{tc}) by the contaminant concentration (c_o).

$$H_r = (0.002 * 600 * 6.25) / 1 = 7.5 \text{ m}$$

It is also assumed that the peak concentration in the landfill is reached relatively early in the life of the landfill, and that the analysis starts at this time. Consequently there is no increase in concentration with time and the Rate of Increase in Concentration (c_r) with time is zero.

The average infiltration through the cover (q_o) is assumed to be 0.3 m/a. If the average exfiltration through the base of the landfill is v_a (which varies with time), then the Volume of Leachate Collected is:

$$Q_c = q_o - v_a = 0.3 - v_a$$

In this example the landfill is situated in a 4 m thick clay, which is underlain by an aquifer. The landfill is assumed to be 200 m long in the direction parallel to the groundwater flow in the aquifer. At the up gradient edge of the landfill the inflow in the aquifer is given by a Darcy velocity of 2 m/a. The outflow Darcy velocity at the down gradient edge of the landfill (v_b) is assumed to be 2 m/a from years 0 to 20, then increasing between 20 and 30 years according to the relationship:

$$v_b = 2 + 200 * v_a$$

After 30 years the outflow Darcy velocity (v_b) is 6.2 m/a.

When using the Variable Properties special feature it is possible to independently specify the diffusion coefficient (D_m) and the dispersivity. In this example the dispersivity is assumed to be zero for inward flow (i.e., $v_a < 0$), and is 0.4 m for outward flow (i.e., $v_a > 0$). The coefficient of hydrodynamic dispersion (D) is then calculated by:

$$D = D_m + \alpha * v_a / n$$

where n is the porosity, in this example 0.4.

7.1.11 Case 11: Time-varying Source Concentration

In this example there is a time-varying source concentration history and diffusive transport of a conservative species (i.e., no sorption) from a landfill. Time zero corresponds to the excavation of a landfill cell, the cell then filled quickly with water to a depth of 6 m. No waste was added to the cell for 7 years. The landfill is situated in a clay that contains chloride in its pore water at a concentration of 120 mg/L. During the 7 years that the cell contained water the chloride began to diffuse out of the clay pore water and into the cell water. Between the years 7 and 10, waste was added to the cell and the source concentration of chloride increased linearly with time reaching a peak value at year 10 of 2100 mg/L. The source concentration of chloride then remained relatively constant between the years 10 and 13. During the years 13 to 15 the source concentration decreased linearly with time to a value of 1180 mg/L at year 15. The source concentration then remained relatively constant again from years 15 to 19. This example will calculate the predicted chloride distribution with depth at year 19.

There is no leachate collection system in the landfill, and the water level in the waste corresponds to the natural water level. The hydraulic gradient is zero, and hence the Darcy velocity is zero. And the clay is sufficiently thick that it can be assumed to be infinite for the time period under consideration.

When using the Variable Properties special feature it is possible to independently specify the diffusion coefficient (D_m) and the dispersivity. In this example the dispersivity is assumed to be zero since there is no flow. Clearly if there is no flow then the value of the dispersivity is not relevant since the coefficient of hydrodynamic dispersion (D) is then calculated by:

$$D = D_m + \alpha * v_a / n$$

The Reference Height of Leachate for this example is the same as the depth of water in the cell (i.e., 6 m). In this example the source concentration is assigned specific values at various times by setting the value of the Reference Height of Leachate very large. Setting the Reference Height of Leachate very large will ensure that the source concentration remains constant during that time interval.

7.1.12 Case 12: POLLUTE vs. Analytical Solution

The results obtained from POLLUTE are compared to those obtained by an analytical solution developed by Tang et al. (1981) for a single fracture system. A conservative contaminant is considered with a constant source concentration of 1. The fractures are 10 μm wide, have a groundwater (seepage) velocity along the fracture of 730 m/a, a dispersivity of zero, and a diffusion coefficient along the fractures of 0.077 m^2/a . In this comparison the fracture spacing is 1 m. Because of the very low matrix diffusion coefficient there is no interaction between fractures over the time frame considered, thus the same result would be obtained if the fracture spacing were increased to 10 m. The Darcy velocity, which occurs along the fractures, can be calculated by multiplying the fractures per m times the fracture width times the seepage velocity:

$$v_a = 10 \times 10^{-6} * 1 * 730 = 0.73 \times 10^{-2}$$

A porosity of 0.05 and tortuosity (the ratio of effective diffusion coefficient to the molecular diffusion coefficient in water) of 0.0000983 were assumed for the matrix material. The matrix diffusion coefficient is then given by multiplying the fracture diffusion coefficient and the tortuosity:

$$D_m = 0.077 * 0.0000983 = 7.5691 \times 10^{-6}$$

7.1.13 Case 13: Comparison with Analytical Method

In this example the results of POLLUTE are compared to those obtained by the analytical solution given by TDAST. TDAST is a computer program for 2-D plane dispersion in an infinitely deep porous media, developed by Javandel et al. (1984). An infinitely thick layer is considered, however for comparison purposes the calculations will be restricted to the first 10 m. Below the layer the bottom boundary is assumed to extend to infinity and have the same properties as the layer above.

7.1.14 Case 14: Primary and Secondary Collection

In this example a landfill with both a primary and a secondary leachate collection system is modelled using the Passive Sink special feature. The landfill contains a finite mass of a conservative contaminant species, and is underlain by an aquifer with fixed outflow. A passive sink is used to model the secondary leachate collection system, which is assumed to be composed of a 0.3 m thick granular layer. The Darcy velocity is assumed to be 0.01 m/a downward from the landfill to the secondary leachate collection system, and 0.0 m/a between the secondary leachate collection system and the aquifer (i.e., the water table is assumed to be at the base of the secondary leachate collection system).

The analysis starts at time zero which corresponds to the completion of the landfill and the development of a peak leachate concentration (c_o) of 1000 mg/L. It is assumed that the average waste thickness is 6.25 m with a density of 600 kg/m³, and that the contaminant represents 0.2% of the total mass of the waste. Thus the total mass of contaminant per unit area of landfill is:

$$m_{tc} = 0.002 * 600 * 6.25 = 7.5 \text{ kg/m}^2$$

The Reference Height of Leachate (H_r) is then calculated by dividing the total mass of contaminant per unit area (m_{tc}) by the contaminant concentration (c_o).

$$H_r = 0.002 * 600 * 6.25 / 1 = 7.5 \text{ m}$$

It is also assumed that the peak concentration in the landfill is reached relatively early in the life of the landfill, and that the analysis starts at this time. Consequently there is no increase in concentration with time and the Rate of Increase in Concentration (cr) with time is zero.

The average infiltration through the cover (q_o) is assumed to be 0.3 m/a. If the average exfiltration through the base of the landfill (v_a) is 0.01 m/a, then the Volume of Leachate Collected is:

$$Q_c = q_o - v_a = 0.3 - 0.01 = 0.29 \text{ m/a}$$

The strata beneath the landfill consists of a 1 m clay layer, a 0.3 m granular layer (i.e., secondary leachate collection system), a 2 m aquitard layer, underlain by a 1 m thick aquifer. The landfill is assumed to be 200 m long in the direction parallel to the groundwater flow in the aquifer. At the up gradient edge of the landfill the inflow in the aquifer is given by a Darcy velocity of 4 m/a.

The outflow Darcy velocity at the down gradient edge of the landfill (v_b) is then by multiplying the landfill length (200 m) by the Darcy velocity below the secondary leachate collection system (0.0 m/a) and adding the inflow, viz:

$$v_b = 4 + 200 / 1 * v_a = 4 \text{ m/a}$$

When using the Passive Sink Properties special feature the deposit is divided into layers which can have vertical and horizontal flows. In the example 3 layers are necessary, the first is from the base of the landfill to the top of the secondary leachate collection system, the second is the secondary leachate collection system, and the third is from the base of the secondary leachate collection system to the aquifer. In the first layer there is a vertical downwards Darcy velocity of 0.01 m/a and no horizontal flow. The second layer has a horizontal flow which is equal to the difference in Darcy velocity between the layers above and below, multiplied by the landfill length and divided by the layer thickness, viz:

$$v_s = (v_{a1} - v_{a2}) * L / h = (0.01 - 0.0) * 200 / 0.3 = 6.67 \text{ m/a}$$

In the third layer there is no vertical or horizontal advective flow, there will however still be diffusive flow.

7.1.15 Case 15: Leachate Collection with Failure

This example is similar to case 14 except the failure of the primary leachate collection system is also modelled using the Variable Properties special feature. Prior to the failure of the primary leachate collection system there is a downward Darcy velocity of 0.01 m/a between the landfill and the secondary leachate collection system. The primary leachate collection system is assumed to fail between 20 and

30 years, causing the leachate mound in the landfill to rise resulting in an increase in the Darcy velocity. After 30 years the collection system has completely failed and the Darcy velocity is now assumed to be 0.1 m/a.

As in case 14 the landfill contains a finite mass of a conservative species, and is underlain by an aquifer with fixed outflow. A passive sink is used to model the secondary leachate collection system, which is assumed to be composed of a 0.3 m thick granular layer. The Darcy velocity is assumed to be initially 0.01 m/a downward from the landfill to the secondary leachate collection system, and 0.0 m/a between the secondary leachate collection system and the aquifer (i.e., the water table is assumed to be at the base of the secondary leachate collection system).

The analysis starts at time zero which corresponds to the completion of the landfill and the development of a peak leachate concentration (c_0) of 1000 mg/L. As in example 14 the Reference Height of Leachate is 7.5 m, and the Rate of Increase in Concentration is zero.

The average infiltration through the cover (q_0) is assumed to be 0.3 m/a. If the average exfiltration through the base of the landfill v_a (which varies with time), then the Volume of Leachate Collected is:

$$Q_c = q_0 - v_a = 0.3 - v_a$$

The strata beneath the landfill, landfill dimensions, and aquifer characteristics are the same as in example 14.

Passive sink layers are divided the same as in example 14, except that the Darcy velocity in the first layer and the outflow in the second layer will be variable. The Darcy velocity in the first layer will be 0.01 m/a between 0 and 20 years, then will increase linearly between 20 and 30 years to 0.1 m/a, and then will be 0.1 m/a. In the second layer the horizontal outflow is equal to the difference in Darcy velocity between the layers above and below, multiplied by the landfill length and divided by the layer thickness, viz:

$$v_s = (v_{a2} - v_{a1}) * 200/0.3 \text{ m/a}$$

In the third layer there is no vertical or horizontal advective flow, there will however still be diffusive flow. When using the Variable Properties special feature with the Passive special feature it is possible to specify the Darcy velocities in both features. The Darcy velocity used by POLLUTE will be the result from the multiplication of the two velocities. For most practical applications, it is recommended that the Darcy velocity be entered as 1.0 in one of the features, and then the actual value entered in the other feature. In this example the Darcy velocity is entered as 1.0 in the Variable Properties special feature, and the actual values are entered in the Passive Sink special feature.

Using the Variable Properties special feature the dispersivity can also be specified, in this example it is assumed to be 0.4 since there is outward flow from the landfill.

7.1.16 Case 16: Monte Carlo Simulation

In this example, Monte Carlo simulation will be used to examine the effect of uncertainty in the service life of a Primary Leachate Collection system. The landfill from example 15 will be used, except the time that the Primary Leachate Collection system begins to fail will vary between 20 and 50 years with a mode of 25 years. Case 15 should be reviewed prior to reading this example, where the implementation of the Variable Properties and Passive Sink special features are described in detail.

The parameters for this example are the same as in Case 15, except for the addition of the Monte Carlo parameters.

7.1.17 Case 17: Landfill with Composite Primary Liner

This example demonstrates how to create a landfill with a composite primary liner, primary and secondary leachate collection systems, and a compacted clay secondary liner. The composite primary liner is composed of a 60 mil (1.5 mm) geomembrane in good contact with a 0.9 m thick compacted clay liner. Small holes with an area of 0.1 cm² and a frequency of 2.5 per hectare (1 per acre) are assumed for the geomembrane. The method proposed by Giroud et al (1992) is used to calculate the flow (leakage) through the composite liner, these calculations are performed automatically by POLLUTE. Below the composite primary liner is a 0.3 m thick granular secondary leachate collection system, overlying a 0.9 m thick compacted clay secondary liner. There is a 3 m thick aquitard under the secondary liner, which overlies a 3 m thick aquifer.

The landfill has a length (L) of 200 m in the direction parallel to groundwater flow in the underlying aquifer. Consideration is being given to a volatile organic contaminant with an initial source concentration of 1500 µg/L, which is assumed to remain constant with time over the time period being examined in this example. The leachate head on the composite primary liner is assumed to be constant at 0.3 m, the head on the secondary liner is assumed to be 0.3 m, and the groundwater level relative to the top of the aquifer is assumed to be 3 m (i.e., at the top of the aquitard).

The flow in the aquifer must be established based on hydrogeologic data and is represented in terms of the horizontal Darcy velocity (the "Base Outflow Velocity") in the aquifer at the down-gradient edge of the landfill (see Example 3 for more discussion of Base Outflow Velocity and Aquifer thickness).

7.1.18 Case 18: Phase Change

In this example a phase change in the secondary leachate collection system is modelled using the Phase Change special feature. The landfill has a secondary leachate collection system and liner which overlies a 1 meter thick aquifer. A phase change occurs in the secondary leachate collection system at the interface between the unsaturated and saturated zones, assumed to be .2 and .1 meters thick respectively.

The landfill contains a constant concentration of DCM, which experiences biological decay in the landfill, primary and secondary liners, and the aquifer. A half-life of 10 years in the landfill and 40 years everywhere else is assumed. No biological decay is assumed to occur in the secondary leachate collection system.

The diffusion coefficient of the DCM in the unsaturated zone of the secondary leachate collection system is assumed to be 300 m²/a, and in the saturated zone to be 100 m²/a (to represent a high degree of mixing in the saturated zone). The phase change parameter for the DCM in the unsaturated zone is Henry's Constant which is assumed to be 0.1 for DCM in this example.

Two layers are used to model the unsaturated and saturated zones of the .3 meter thick secondary leachate collection system. The first layer represents the unsaturated zone and is .2 meters thick. And the second layer represents the saturated zone and is .1 meter thick.

A Darcy velocity of 0.003 m/a is assumed through the primary liner, and 0 m/a through the secondary liner. Thus, for a 500 meter long landfill the outflow rate in the saturated portion of the secondary leachate collection system would be:

$$\text{Outflow Rate} = (500 * 0.003) / 0.1 = 15 \text{ m/a}$$

This example is for a hypothetical landfill and is used to illustrate how to prepare an input file and run an analysis using the Phase Change option. The example is not a prescription for modeling contaminant migration during operation of a landfill. Each landfill has its own unique characteristics and no general prescription can be made. The Phase Change option should only be used by someone with the hydrogeologic background necessary to appreciate the subtleties associated with the physical situation and the steps necessary for appropriate modeling of this physical situation.

7.1.19 Case 19: Multiphase Diffusion Test

In this example a multiphase diffusion test performed by Buss et al. (1995) is modelled. This test involved the migration of toluene from a 'constant' source through a 0.1 cm thick HDPE geomembrane, a 18.2 cm thick airspace and into a 12.3 cm water reservoir (assumed to be well mixed). Based on Buss et al. the geomembrane diffusion coefficient was $6 \times 10^{-8} \text{ cm}^2/\text{s}$ and the phase coefficient was 43.8. From Schwarzenbach et al. (1993), the diffusion coefficient and phase coefficient for toluene in air are $0.088 \text{ cm}^2/\text{s}$ and 0.27 respectively. Based on these parameters the test is modelled for 600 hours and the calculated and observed concentrations in the receptor are provided at the end of this example.

7.1.20 Case 20: Sensitivity Analysis

In this example, Sensitivity Analysis will be used to examine the effect of uncertainty in the service life of a Primary Leachate Collection system. The landfill from Cases 15 and 16 will be used, except the time that the Primary Leachate Collection system begins to fail will range from 15 to 50 years. Cases 15 and 16 should be reviewed prior to reading this example, where the implementation of the Variable Properties and Passive Sink special features are described in detail.

7.2 Migrate Examples

The sections below describe the 13 Migrate examples provided in the Examples project.

7.2.1 Case 1: Subtitle D Landfill

This example illustrates the use of the MIGRATE program to model a U.S. RCRA Subtitle D landfill. The landfill consists of a composite liner and a primary leachate collection system. The composite liner is composed of a 60 mil (1.5 mm) geomembrane in good contact with a 0.9 m thick compacted clay liner. Small holes with an area of 0.1 cm² and a frequency of 1 per acre (2.5 per hectare) are assumed for the geomembrane. The method proposed by Giroud et al (1992) and Giroud and Bonaparte (1989) is used to calculate the flow (leakage) through the composite liner, these calculations are performed automatically by Migrate.

The landfill has a surface and base width of 200 m in a direction parallel to the groundwater flow in the underlying aquifer. Consideration is being given to a volatile organic contaminant with an initial source concentration of 1500 µg/L, which is assumed to remain constant over the time period being examined in this example. The leachate head on the composite liner is assumed to be constant at 0.3 m. The flow in the aquifer must be established based on hydrogeologic data and is represented in terms of the horizontal Darcy velocity (assumed to be 10 m/a in this example) in the aquifer at the down-gradient edge of the landfill.

7.2.2 Case 2: Primary and Secondary Liner Landfill

This example demonstrates how to create a landfill with a composite primary liner, primary and secondary leachate collection systems, and a compacted clay secondary liner. The composite primary liner is composed of a 60 mil (1.5 mm) geomembrane in good contact with a 0.9 m thick compacted clay liner. Small holes with an area of 0.1 cm² and a frequency of 2.5 per hectare (1 per acre) are assumed for the geomembrane. The method proposed by Giroud et al (1992) is used to calculate the flow (leakage) through the composite liner, these calculations are performed automatically by MIGRATE. Below the composite primary liner is a 0.3 m thick granular secondary leachate collection system, overlying a 0.9 m thick compacted clay secondary liner. There is a 3 m thick aquitard under the secondary liner, which overlies a 3 m thick aquifer.

The landfill has a surface and base width of 200 m in the direction parallel to groundwater flow in the underlying aquifer. Consideration is being given to a volatile organic contaminant with an initial source concentration of 1500 µg/L, which is assumed to remain constant over the time period being examined in this example. The leachate head on the composite primary liner is assumed to be constant at 0.3 m, the head on the secondary liner is assumed to be 0.3 m, and the groundwater level relative to the top of the aquifer is assumed to be 3 m (i.e., at the top of the aquitard).

The flow in the aquifer must be established based on hydrogeologic data and is represented in terms of the horizontal Darcy velocity (assumed to be 10 m/a in this example) in the aquifer at the down-gradient edge of the landfill (see Example 4 for more discussion of Base Outflow Velocity and Aquifer thickness).

7.2.3 Case 3: Pure Diffusion

This example illustrates the use of the MIGRATE program for the simple case of pure diffusion of a conservative species (i.e., no sorption). The hydrogeology is comprised of a 4 m thick layer with a constant contaminant concentration source at the top, and an underlying aquifer at the base. There is a sufficiently high flushing velocity in the aquifer that the concentration at the bottom of the layer can be assumed to be zero and the aquifer is not explicitly modelled.

7.2.4 Case 4: Advective Diffusive Transport - Finite Mass

In this example the input data file from example 3 will be edited to include a source with a finite mass of waste and a permeable base stratum (aquifer) with a fixed outflow. The hydrogeology is comprised of a 4 m thick aquitard layer with a finite mass source at the top, and a 20 m thick underlying aquifer at the base.

It is assumed in this example that the waste has an average thickness of 6.25 m and a density of 600 kg/m³, and that chloride represents 0.2% of the total mass of the waste. A peak concentration (c_0) for chloride of 1000 mg/L (i.e., 1 kg/m³) is assumed, and it is assumed that the peak concentration is reached relatively early in the life of the landfill and the analysis starts at this time.

The Volume of Leachate (Q_c) collected by the leachate collection system is equal to the difference between the infiltration through the cover ($q_0 = 0.3$ m/a here) and the exfiltration through the base ($v_a = 0.03$ m/a here), and is given by:

$$Q_c = q_0 - v_a = 0.3 - 0.03 = 0.27 \text{ m/a}$$

Although the aquifer is 20 m thick it is generally unrealistic to model dilution (mixing) of contaminant through the full thickness. The actual thickness that should be modelled depends on the hydrogeologic conditions, the length of monitoring screens, and the local regulations. In this example dilution (mixing) of the contaminant will only be considered in the upper 3m of the aquifer, and hence the aquifer thickness is $h = 3$ m.

Since the aquifer (i.e., the contaminant receptor) is being modelled as a boundary condition the actual deposit thickness that is explicitly modelled is the 4 m thick aquitard, and the concentration given in the output at the 4 m depth is the concentration in the upper 3 m of the aquifer. It is assumed that this is vertically uniformly distributed in the 3 m and that no contaminant moved lower than 3 m into the aquifer (if the aquifer thickness, h , were to be increased, the calculated concentration in the aquifer would drop due to the additional dilution).

In the underlying aquifer the inflow of water beneath the up gradient edge of the landfill is given by a Darcy velocity of 4 m/a. The "base velocity" is the outflow velocity beneath the down-gradient edge of the landfill and corresponds to the inflow velocity at the up gradient edge plus the inflow from the landfill. Based on continuity of flow the initial flow in the aquifer, q_{in} , is given by the inflow velocity ($v_{in} = 4$ m/a in this example) multiplied by the thickness of the aquifer being considered ($h = 3$ m in this example) and the length of the landfill perpendicular to the direction of groundwater flow, $L = 300$ m, thus:

$$q = v * h * L = 4 * 3 * 300 = 3600 \text{ m}^3/\text{a}$$

The flow into the aquifer from the landfill, q_a , is the downward Darcy velocity ($v_a = 0.03$ m/a in this case) multiplied by the width ($W = 200$ m) and length ($L = 300$ m) of the landfill, thus:

$$q_a = v_a * L * W = 0.03 * 200 * 300 = 1800 \text{ m}^3/\text{a}$$

Hence the outflow at the down-gradient edge of the landfill is:

$$q^{out} = q + q_a = 3600 + 1800 = 5400 \text{ m}^3/\text{a}$$

And the "Base Outflow Velocity", v_b , is the outflow divided by the length of the landfill ($L = 300$ m) and the thickness of the aquifer being considered ($h = 3$ m), therefore:

$$vb = q_{out} / (W * h) = 5400 / (3 * 300) = 6 \text{ m/a}$$

The landfill width (W) is measured in the direction parallel to groundwater flow. And the landfill length (L) is the direction perpendicular to groundwater flow, since this is not a 3D analysis this parameter has no effect on the results.

7.2.5 Case 5: Integration Effects

This example (see Figure below) is used to illustrate that the use of MIGRATE should be combined with common sense, while demonstrating the effects of integration. First, the user should estimate the approximate time the concentration front will take to reach a certain position of interest (or the approximate position of the front at a time). This is best done by using a 1-D solution (such as that used in the program POLLUTE). The 1-D solution can then be improved using MIGRATE (2-D solution). Second, the user should be aware that much greater computational effort is required to get accurate 2-D results (because of double integration) than to get accurate 1-D results. The more Fourier and Talbot integration the greater the computation time. Most solutions do not require a large amount of integration, but some do.

7.2.6 Case 6: Integration Effects - Talbot Integration

In this example an attempt is made to eliminate the negative concentrations and flux into the base that occurred in example 5. The first integration parameters one should examine are N and RNU (other Talbot parameters need not be modified). Also, the user may want to examine the effect of Fourier integration if results are to be confirmed.

7.2.7 Case 7: Integration Effects - Gauss Integration

This example attempts to eliminate the negative concentrations in the top 5.6 m of Cases 5 and 6 by using user SELECTED Gauss integration parameters for the Fourier integral. Concentrations in the upper layers are governed by a step function. MIGRATE approximates the step function using a Fourier integral. The amount of Fourier integration can be controlled by the user. Since the Fourier integral is oscillatory it may not approximate a step function very accurately when using a narrow range of integration steps (i.e. NORMAL or FINE integration). Therefore a large number of integration steps may be needed before accurate concentrations are obtained at points where the concentration should be near zero (i.e. we must use a large number of steps if we are interested in trivial results).

7.2.8 Case 8: Buried Landfill

This problem involves calculating the concentration of a pollutant migrating out of a buried landfill. Two lateral positions are investigated to get a better understanding of the movement of the chemical in question.

7.2.9 Case 9: Comparison with TDAST

In this example a comparison is made between MIGRATE and an analytical solution given by TDAST. TDAST is a computer program developed by Javandel et al (1984) and it can be used to solve 2-D plane dispersion problems for an infinitely deep porous media.

7.2.10 Case 10: Fractured Layer and Sorption

This example is used to illustrate the use of the MIGRATE program where one of the layers is fractured and there is sorption of the contaminant species. See example 6 in the POLLUTE User's Guide for the 1½-dimensional equivalent of this example.

The barrier for this landfill consists of a 1 m thick compacted clay layer overlying a 3 m thick fractured till. Sorption of the contaminant species is assumed to be controlled by a distribution coefficient of 1.5 mL/g in the compacted clay and fractured till.

In this example the waste is assumed to have an average thickness of 6.25 m, a density of 600 kg/m³, and that the contaminant species represents 0.2 % of the total mass. A peak concentration of 1000 mg/L is assumed for the contaminant species. And the landfill is assumed to have a width of 200 m in the direction of groundwater flow.

A Darcy velocity (v_a) of 0.02 m/a through the deposit and an infiltration through the cover (q_o) of 0.3 m/a are assumed. The volume of leachate collected (Q_c) is then given by:

$$Q_c = q_o - v_a = 0.3 - 0.02 = 0.28 \text{ m/a}$$

Beneath the fractured till is a 1 m thick aquifer, with a porosity of 0.35. The inflow in the aquifer at the up gradient edge of the landfill is assumed to be 4 m/a. The outflow velocity (v_b) at the down gradient edge of the landfill is then:

$$v_b = 4 + 200 * 0.02 = 8 \text{ m/a}$$

7.2.11 Case 11: Two Landfills

In this example MIGRATE is used to model contaminant migration from two adjacent landfills (see Figure below). The barriers for these landfills consist of a 1 m thick compacted clay layer overlying a 2 m thick silt. Beneath the silt is a 2 m thick aquifer. The objective of the modelling will be to calculate the concentration in the aquifer at the downgradient edge of the two landfill sites, assumed to be 1000 m from the furthestmost edge of the first landfill.

The waste in these landfills is assumed to have a density of 600 kg/m³, and the contaminant species represents 0.2 % of the total mass. A peak concentration of 1500 mg/L is assumed for the contaminant species in both landfills. In the first landfill the waste is assumed to be 15 m thick, and in the second landfill the waste is assumed to be 25 m thick. The first landfill is assumed to have a surface width of 300 m and a base width of 280 m in the direction of groundwater flow. Downgradient from the first landfill, the second landfill is assumed to have a surface width of 600 m and a base width of 580 m.

A Darcy velocity of 0.008 m/a through the deposit is assumed, this velocity is based on the leachate mound in the landfills being 0.3 m above the top of the clay liner and hydraulic conductivities of the clay and silt being 2×10^{-10} m/s and 1×10^{-7} m/s respectively. The volume of leachate collected in both landfills is assumed to be 0.05 m/a. The 2 m thick aquifer is assumed to have a porosity of 0.35, and an outflow velocity at the downgradient edge of the landfills of 12 m/a.

7.2.12 Case 12: Two Landfills - Different Source Histories

The model for two landfills in example 11 is modified for the case where the landfills have different source histories. In this example the second, larger landfill is assumed to be constructed and filled 20 years later than the closure of the first, smaller landfill.

For the purposes of this example the first landfill is assumed to reach its peak concentration after 10 years. During this 10 year period the concentration is assumed to increase linearly as the waste thickness increases. For the purposes of this example the linear increase in concentration is approximated by two steps. After the closure of the first landfill the concentration of the contaminant in the landfill will decrease as contaminant is removed from the landfill.

The second landfill is assumed to be filled over a time period of 20 years (ie. between 30 and 50 years), during which time the concentration in the landfill is assumed to increase linearly. At the end of this 20 year period the concentration in the landfill reaches its peak of 2500 mg/L. After this time period (ie. 50 years from start of model) the second landfill is closed and the concentration of the contaminant begins to decrease as mass is removed from the landfill.

7.2.13 Case 13: Termination of a Leachate Collection System

The termination of the operation of a primary leachate collection system in a U.S. RCRA Subtitle D Landfill is modelled in this example. This landfill will be the same as that modelled in example 1, which will be edited in this example to include the termination of the leachate collection system.

This landfill consists of a composite liner composed of a 60 mil (1.5 mm) geomembrane in good contact with a 0.9 m thick compacted clay liner. During the first 10 years of the landfill operation the concentration of the contaminant is assumed to increase linearly, reaching its peak value at 10 years.

While the primary leachate collection system is operating the downward Darcy velocity was calculated in example 1 to be 5.7×10^{-5} m/a. The primary leachate collection system operation is assumed to be terminated after landfill closure (i.e. at 50 years) and after this time the cover is also no longer maintained allowing the leachate mound in the landfill to rise resulting in an increase in the Darcy velocity. After 70 years the leachate mound is assumed to reach its maximum height of 25 m. The Darcy velocity through the barrier can now be calculated for this new leachate mound height using the Leakage Rate submenu of the Data Entry menu, and is 0.0116 m/a. The Darcy velocity between 50 and 70 years can be linearly interpolated and divided into five steps, with each step represented by a different time period.

Pollute & Migrate

User Guide

Appendix B Research Reports

Appendix B Research Reports

The following research reports provide information on contaminant transport, landfill design, and the use of the POLLUTE and MIGRATE software.

8.1 1-D Pollutant Migration

A technique for the analysis of 1-D pollutant migration through a clay layer of finite depth is presented. This formulation includes dispersive and advective transport in the clay as well as geochemical reactions and permits consideration of the depletion of contaminant in the landfill with time as well as the effect of ground-water flow in a permeable stratum beneath the clay layer. A limited parametric study is presented to illustrate the effect of considering these factors in the analysis. It is shown that for most practical situations the concentration of contaminant within the ground water beneath the landfill will reach a peak value at a specific time and will then decrease with subsequent time. It is shown that the magnitude of this peak concentration and the time required for it to occur are highly dependent upon the mass of contaminant within the landfill and the sorption capacity of the clay. Other important factors which are examined include the thickness of the clay layer, the advection velocity (relative to the dispersivity), and the ground-water flow velocity in any permeable strata beneath the clay layer. The implications of these results for optimizing the design of clay liners is then discussed.



8.2

A Finite Layer Technique for Calculating Three-Dimensional Pollutant Migration in Soil

A technique for the analysis of two- and three-dimensional pollutant migration through a layered soil medium is described. An earlier solution for plane diffusion in a single homogeneous layer of soil is extended using the finite layer method for general three-dimensional diffusion. Particular attention is focused on the effects of horizontal advective velocity and coefficient of hydrodynamic dispersion within the aquifer together with the thickness of the aquifer. A parametric study is presented to demonstrate some characteristics of contaminant migration in a layered soil system, taking into account the fact that the surface concentration does not remain constant because of contaminant transport into the deposit. The advantages of the approach are most pronounced when attempting to determine concentrations away from the landfill at modest to large times.



8.3

A Semi-Analytic Model for Contaminant Migration in a Regular Two or Three Dimensional Fractured Network: Conservative Contaminants

A new semi-analytical solution for the transport of a conservative contaminant species in a fractured medium having a regular two or three dimensional fracture network is presented. The application of the technique and some of the practical implications arising from an examination of contaminant migration in fractured systems is discussed. Particular consideration is given to the effects of Darcy velocity, fracture spacing, matrix porosity, dispersivity and the mass of contaminant available for transport. The implications of uncertainty with respect to fracture opening size and ground-water velocity is also discussed and it is shown that provided one can obtain a reasonable estimate of the hydraulic gradient and hydraulic conductivity for the rock mass, uncertainty regarding the magnitude of the opening size and the groundwater velocity does not have a significant effect on predicted contaminant migration for the class of problems being considered.



8.4 An Efficient Analysis of Pollutant Migration through Soil

The potential for contamination of groundwater is now a major consideration in the design and construction of waste disposal sites in many countries. Often the movement of contaminant from the disposal pit is controlled either by siting the landfill in a natural clayey soil or by constructing a compacted clay liner between the disposal pit and the surrounding soil. The selection of the type and thickness of the liner requires consideration of the expected concentrations at observation points beneath the liner, at the boundaries of the disposal site and possibly, at specific monitoring points outside the site. These contaminant migration analyses can be performed using time-marching finite element techniques, however, to obtain accurate results at both small and large times, this requires a relatively refined finite element mesh (to accommodate high concentration gradients at low times) and considerable computational effort.

Many soil deposits are horizontally layered and it is not really necessary to use the finite element method. In these cases, an alternative finite layer procedure proposed by Rowe and Booker can be adopted for directly calculating the concentration of contaminants of specified locations and times. This approach, which will be described in this chapter, takes account of the fact that the concentration of contaminant within the disposal pit may decrease as mass is transported into the soil while also allowing for the possible presence of a more permeable underlying stratum (aquifer) beneath the clay liner. The technique to be adopted involves taking the Laplace and, where appropriate, Fourier transforms of the governing equations, finding an analytic solution in transform space and then numerically inverting the transforms to obtain the concentrations of contaminant at selected positions and times. The solution will be developed initially for the case of 1D (vertical) advective-dispersive transport in layered soil but allowing for horizontal transport in an underlying aquifer. The procedure will then be generalized to two and three dimensions. The application of these techniques will be discussed and will be illustrated by a number of examples.



8.5

Analysis of Contaminant Transport Through Fractured Rock at an Ontario Landfill

The effects of fracture spacing, fracture opening size, Darcy velocity and dispersion upon the calculated contaminant plume in a fractured shale are examined. It is shown that the calculated contaminant plume, based on a reasonably hydrogeologic input, is consistent with the observed, very limited, extent of the contaminant plume at a 15 year old landfill in Burlington, Ontario. The results demonstrate that matrix diffusion can play a very significant role in the attenuation of contaminant migrating in fractured porous media.



8.6 Background Documentation for POLLUTE and MIGRATE

This document provides supplementary information concerning computer programs POLLUTE and MIGRATE and should be read in conjunction with the Users Manuals for these programs.



8.7 Calculating Leakage through Composite Liner Systems

A new semi-analytic solution for the leakage of fluid through a circular hole in an otherwise essentially impermeable geomembrane underlain by a clay liner is presented. This solution covers the full range of layer thickness between very thin (one-dimensional flow) and infinitely thick (Forchheimer's solution). It demonstrates that, in general, the flow is greater than that produced by the limiting cases. The solution can be used for a wide range of practical problems where the radius of the hole may range from a pinhole to a large quasi-circular wrinkle in a perforated geomembrane (i.e. where the "hole" is considered to be the area where there is no contact between the geomembrane and clay). The solution assumes perfect contact between the geomembrane away from the hole but does allow consideration of hydraulic anisotropy of the clay layer. Using the proposed theory, a very simple, analytic, approximate expression is obtained. This solution can be used in hand calculations to establish the leakage rate in many practical design situations.



8.8 Composite Liners as Barriers: Critical Considerations

The finite service life of engineered components of composite liner systems is a critical consideration in the design of such systems. Four different barriers incorporating composite liners are examined with respect to service life, leakage through the geomembrane, and the hydraulic conductivity of the geosynthetic clay liner.



8.9

Consideration of Uncertainty regarding the Service lives of Engineered Systems in Assessing Potential Contaminant Impact

The modelling of contaminant transport through barrier systems will be discussed in the context of uncertainty regarding the service life of various components of the engineered barrier systems. A technique for performing a stochastic analysis that takes consideration of finite but uncertain service lives of different components of the system is discussed and will be illustrated by a number of examples. The barrier systems to be considered will include conventional clay liner systems that include multiple leachate collection systems, systems involving composite (geomembrane and clay) liners, and systems involving geosynthetic clay liners.



8.10

Contaminant Impact Assessment and the Contaminating Lifespan of Landfills

Some of the factors to be considered in performing impact assessments for proposed municipal and non-hazardous waste landfill sites are discussed. These factors include the effect of the mass of contaminant, infiltration, and attenuation in the hydrogeologic system on the contaminating lifespan of a landfill. The potential impact of fracturing of the soil separating the landfill from an underlying aquifer is examined. The influences of a compacted clay liner and (or) a natural, intact clayey layer below the fractured soil are examined. The concept of developing "triggers" to initiate leachate control measures, and the associated potential impact on groundwater, is discussed in the context of the potential design life of the underdrain system in a landfill.



8.11 Contaminant Impact Due to Clogging

Recent advances in the development of finite layer theory allow the modelling of changes in the operation of an engineered barrier system for landfills. Factors that can be considered include changes in the operation of the system as the primary leachate system clogs, changes in the operation of secondary leachate collection and hydraulic control layers, and changes in the diffusive and hydraulic characteristics of geomembranes. The application of the theory is illustrated with reference to a number of standard barrier system designs and it is shown that for a large landfill some of these may eventually give rise to unacceptable impact when consideration is given to the finite service life of the engineered systems for the conditions examined.



8.12

Contaminant Migration through Fractured till into an Underlying Aquifer

This paper examines the potential impact on groundwater quality of contaminant migration from a landfill site, through a fractured till, and into an underlying aquifer. The paper describes a simple, semi-analytic technique for modelling contaminant transport through the fractured till, including consideration of diffusion of contaminants from the fractures into the till matrix, sorption, and radioactive decay. The model also considers the finite mass of contaminant and dilution due to the flow of groundwater in the aquifer. The model can be readily implemented on a microcomputer. The model allows examination of variations in fracture spacing, fracture opening size, thickness of the fractured zone, diffusion coefficient, dispersivity, effective porosity of the matrix, radioactive decay, Darcy velocity, thickness of the aquifer, distribution coefficient, and mass of contaminant. The paper describes the results of a limited parametric study that, inter alia, examines the effects of uncertainty in fracture spacing, the thickness of the fractured till, and the effective porosity of the till matrix. Some of the practical implications are discussed.



8.13

Effect of multiple contaminant migration on diffusion and adsorption of some domestic waste contaminants in a natural clayey soil

This paper describes laboratory model tests involving the placement of domestic landfill leachate on top of a layer of saturated undisturbed clayey soil and allowing chemical constituents to migrate into the soil by diffusion only. During the testing period (15 days), samples from the overlying leachate were regularly collected and analyzed for the chemical constituents of interest (i.e., Cl, Na, K, Mg, and Ca). At the end of the test, the soil layer was sectioned to determine the pore-water and adsorbed concentration variations with depth for each species.



8.14 Evaluation of the Hydraulic Conductivity of Aquitards

The evaluation of the bulk vertical hydraulic conductivity of an aquitard based on its response to the pumping of an adjacent aquifer is examined using Biot's theory. Consideration is given to the errors in interpretation of the results of pumping tests which arise as a result of the time lag associated with different types of piezometers as well as the length of the piezometer. Factors to allow for correction of these errors are presented. Although these factors are originally developed for isotropic aquitards, they can be used for anisotropic aquitards with appropriate modifications described in the paper. A comparison is made between the results obtained from diffusion theory (as assumed in the development of techniques currently used in practice) and the more rigorous Biot's theory. The application of the technique is illustrated by two examples.



8.15

Fractured till: Its Implications for Contaminant Impact Assessment

Some of the factors to be considered in performing impact assessments associated with proposals to locate landfill sites in fractured till are discussed. These factors include the effect of the mass of contaminant, infiltration into the landfill and the contaminant transport pathway on the contaminating lifespan of a landfill. The effects of fracturing of the till on the potential impact of contaminants on underlying aquifers are examined with respect to a hypothetical case. The influence of both a man-made (compacted clay liner) and natural intact clayey layer in contact with the fractured till is examined. The concept of developing "triggers" to initiate leachate control measures, and the associated potential impact on groundwater, is discussed in the context of the potential design life of the primary engineering (i.e. the underdrain system) in a landfill.



8.16

Geosynthetics: Environmental Applications in Waste Containment

This paper reviews the applications for geosynthetics in waste containment. Consideration is given to geotextiles as filters and separators in otherwise conventional landfill design. The use of drainage mats as a replacement for conventional granular drainage layers, the use of geomembrane liners as a supplement to natural or compacted clay barriers, and finally to a fully geosynthetic design which incorporates geotextiles, geosynthetic drainage mats, geomembranes and geogrids (for reinforcement).



8.17

Laboratory Determination of Chloride Diffusion Coefficient in an Intact Mudstone

An experimental determination of chloride diffusion coefficient in saturated, intact Bison mudstone is described. Laboratory tests simulating one dimensional diffusive transport were performed by placing distilled water directly above a sample of Bison Mudstone having a high initial concentration of chloride in its pore water. Chloride and other species naturally occurring in the pore water were then permitted to diffuse out of the sample and into the distilled water reservoir for a period of up to 34 days. At the end of the test, the sample was sectioned, and the chloride pore water concentration profile measured. Fickian diffusion theory was then used to deduce the diffusion coefficient (D). The diffusion coefficient for chloride at a temperature of 10C ranged from 1.5 to 2.0×10^{-6} cm²/sec, from which a corresponding tortuosity factor (τ) ranging from .15 to .20 can be calculated. Based on pore size measurements, double layer thickness and consideration of the hydrated ionic diameter of chloride, the effective porosity available for chloride diffusion is approximately equal to the total porosity calculated from the moisture content of the rock. For comparison, an attempt was made to obtain the diffusion coefficient for bromide diffusing into the sample, simultaneous with chloride diffusing out. It was found, however, that the concentration profile obtained for bromide could not be fitted by the Fickian diffusion theory, due to interactions between bromide and other species naturally occurring in the rock sample.



8.18 Leachate Characteristics for MSW Landfills

Leachate characteristics from Ontario landfills are compared with typical values for both European and U.S. landfills. The time history of key constituents are examined and the half-life for first order decay is estimated based on the available data. An examination of the mass of chloride in North America's MSW indicates that it likely represents about 0.18% of the total mass of MSW.



8.19 Long-term performance of contaminant barrier systems

This lecture describes the latest findings with respect to the long-term performance of modern municipal solid waste (MSW) landfill barrier systems. Field data relating to the clogging of leachate collection systems and the latest techniques for predicting their performance are examined. It is indicated that the primary leachate collection system may have service lives that range from less than a decade to more than a century, depending on the design details, waste characteristics and mode of operation. Recent data indicate that landfill liner temperatures can be expected to reach at least 30 to 40C for normal landfill operations. With recirculation of leachate the liner temperature increases faster than under normal operating conditions and may be expected to exceed 40C. Temperatures (up to 40 to 60C) may occur at the base of landfills where there is a significant leachate mound. Temperature is shown to have a significant impact on both contaminant migration and the service life of the liner system. Field measurements and theoretical calculations show that composite liners are substantially better than single liners in terms of controlling leakage from landfills. Also, the leakage rates with a composite liner are very small, and diffusion will dominate as a transport mechanism for contaminant that can readily diffuse through a geomembrane (GM). Composite liners involving a GM over a geosynthetic clay liner (GCL) gave rise to substantially less leakage than those involving a compacted clay liner (CCL).



8.20

Modeling of 2D Contaminant Migration in a Layered and Fractured Zone Beneath Landfills

A new 2D finite layer formulation which allows consideration of both vertical and horizontal contaminant migration in systems which may consist of both fractured and unfractured layers is described. The practical application of the theory is illustrated with respect to a number of hypothetical cases. The results indicate that even relatively widely spaced small fractures can have a significant effect on potential impact. It is also shown that when dealing with relatively impermeable tills, significant impact on an underlying aquifer may not occur until after the landfill leachate is at a low strength; but the impact may be quite significant and may last for hundreds of years.



8.21 Movement of Pollutants through Clayey Soil

This paper examines a number of factors which should be considered when attempting to predict the impact of landfill sites on groundwater contamination. The relative importance of transport mechanisms such as diffusion, dispersion and advection are discussed as well as the significance of attenuation mechanisms. Techniques for determining relevant parameters are outlined and the applicability of laboratory techniques for determining diffusion and distribution coefficients is discussed with respect to the observed migration of contaminants beneath the Sarnia Landfill.

Simple but effective models for calculating the migration of contaminant from landfills are discussed and their application illustrated by a number of examples. Finally, factors such as the impact of the leachate collection system and the migration of contaminant from landfills designed to have an inward gradient is examined.



8.22 Municipal Solid Waste Landfilling

The short and long term performance of clayey barriers (the cheapest way to encapsulate waste) is the subject of this paper. Municipal solid waste leachate varies from a moderately saline, slightly organic, slightly acid liquid when fresh to a non-threatening liquid once aged and diluted. Biological activity within the waste is responsible for extensive carbonate and sulphide dumping which tends to clog drainage systems. Concurrent advection and diffusion play major roles in salt and organic transfer through clay barriers. Typical salt fluxes are presented for barriers of differing thickness to illustrate the great importance of diffusion as a transfer process.



8.23 Pollutant Transport Through Barriers

Methods of predicting contaminant transport through saturated and unsaturated clayey barriers are reviewed. Particular consideration is given to the relative importance of advection and dispersion as transport mechanisms, the soil properties controlling transport, transport through saturated and unsaturated soils, contaminant transport through barriers and into adjacent aquifers, and finally, to methods of obtaining solutions to the transport equations. Based on this review, a number of specific observations and recommendations are made.



8.24 Two-dimensional pollutant migration in soils of finite depth

A technique for analyzing two-dimensional migration of contaminant from a landfill into a homogeneous clayey layer is described. The analysis takes account of the fact that the concentration of contaminant in the landfill will decrease as contaminant is transported into the soil. The analysis also allows for advective—dispersive transport within a permeable stratum (aquifer), which underlies the homogeneous layer. Consideration is given to chemical retardation arising from sorption/ desorption of contaminant in the clayey layer. Some of the more important effects arising from the use of a 2-D analysis are illustrated by means of a limited parametric study. It is shown that the diffusion of contaminant from the aquifer into the clayey layer will substantially reduce the concentrations of contaminant in the groundwater away from the landfill. It is also shown that there is a critical velocity in the aquifer at which the maximum concentration at a point occurs. At greater or lesser velocities, significantly smaller concentrations may result. Thus design for limiting velocities is not necessarily conservative. Finally, the results of the 2-D analysis are compared with those from a 1-D analysis and the applicability of 1-D solutions is discussed.



8.25

Waste Disposal Facility Site Selection and Design Considerations

Considerations associated with the selection and design of a suitable waste disposal facility are discussed. These considerations include the potential for protection of groundwater quality, predictability of groundwater movement, and potential for disruption of groundwater users. In the design of a waste disposal facility engineered systems are often incorporated, and the service life of these systems must be considered when assessing their potential impact. The role of modelling in predicting the potential impacts due to the interaction between the hydrogeology and the proposed engineering is discussed. The potential impact of different landfill designs on groundwater quality is examined.



